


65mm

125mm

智能音乐眼镜

使用指南

产品示意图



开关机

开机：打开双腿，开机
关机：合上双腿，关机

蓝牙配对

打开手机蓝牙搜索蓝牙名称为：YK-12 若眼镜与手机(蓝牙设备)配对连接过,则开机后自动连接

设置

蓝牙

蓝牙

现在可被发现为“iPhone”。

设备

YK-12

音乐

暂停/播放：音乐播放模式下，左/右任意一边单击，播放/暂停
下一曲：音乐播放模式下，右腿双击，下一曲
上一曲：音乐播放模式下，左腿双击，上一曲
音量+：左腿长按，音量增加,当音量加到最大时，喇叭发出“咚咚”声音
音量-：右腿长按，音量减小,当音量减到最小时，喇叭发出“咚咚咚”声音

电话

接听来电: 当来电时，单击，接听(左/右任意一边)
结束通话: 通话状态下，单击，结束通话(左/右任意一边)
拒绝接听: 当来电时，双击，听到“嘟”一声，拒接电话(左/右任意一边)

语音助手


语音助手：三击左边腿，进入语音助手

遥控拍照

遥控拍照：打开手机相机状态下，安卓手机，单击镜腿拍照(左/右任意一边)
苹果手机打开相机状态下，三击右边镜腿拍照

充电

磁吸式充电: 充电显示白灯常亮，充满显示灯熄灭



安全警告

- 请将产品放在儿童接触不到的地方。
- 仅可在5°C至35°C环境温度下使用和存放，温度异常可能导致故障。
- 适度控制音量和使用时长，避免听力受损。
- 禁止拆解、撞击、挤压或投入火中;若电池出现鼓胀、漏液，立即停用，以防触电或爆炸。
- 请勿在驾车、骑行、操作机器等需要感知外界声音时使用。
- 雷暴天气请勿使用，以免设备异常并增加触电风险。
- 与心脏起搏器等植入式医疗设备保持至少15厘米距离。

使用注意

- 蓝牙信号受环境影响，无线干扰较多时可能出现信号变弱或断连，属正常现象。
- 长期不使用时，请每3个月充电一次，防止电池过放损坏。
- 清洁和维护前先停止使用，仅用清洁、干燥的软布擦拭。
- 请使用品牌厂商推荐、通过CCC认证、输出电压5V的充电器，禁止使用超过5V的快速充电器，以免损坏产品。

故障排除

1.无法与手机配对？

- 确保眼镜处于配对模式，手机蓝牙已开启。若仍无法连接，请在手机蓝牙设置中忽略该设备，再按说明书重新配对。

2.无法开机？

请先检查眼镜电量是否充足。

3.可以更换电池吗？

- 不可以。本产品内置不可拆卸的聚合物锂电池。

4.10米内断开连接？

- 蓝牙信号易受障碍物干扰，请确保设备间无金属等物体阻挡，并保持在有效距离内。

5.连接电脑或手机后无声？

- 请将电脑音频输出设为蓝牙音频装置，确认电脑蓝牙支持A2DP协议，并检查电脑/手机音量。

6.连接后能否用眼镜控制手机应用？

- 不支持由眼镜直接控制。应用程序的具体功能受其软件设定影响，部分操作可能无法实现。

所有配件

产品X1, 说明书X1, Type-C充电线X1, 眼镜布X1


正面

VueOn Air 1

24g Ultra-Light Smart Glasses

User Manual

Product diagram



ON/OFF

Power On: Open the temples (legs) to turn on the glasses.
Power Off: Close the temples (legs) to turn off the glasses.

Connect

•Open your phone's Bluetooth settings and search for the device named: YK-12
• If the glasses have been previously paired with the Bluetooth device, they will automatically reconnect after powering on.

Settings

Bluetooth

Bluetooth

Now discoverable as"iPhone"

DEVICES

YK-12

Music

Play / Pause: In music playback mode, single-click either the left or right temple to play or pause.
Next Track: In music playback mode, double-click the right temple to skip to the next track.
Previous Track: In music playback mode, double-click the left temple to return to the previous track.
Volume Up: Long-press the left temple to increase the volume. When the maximum volume is reached, the speaker will emit a “dong dong” sound.
Volume Down: Long-press the right temple to decrease the volume. When the minimum volume is reached, the speaker will emit a “dong dong dong” sound.

Phone call

Answer Call: When an incoming call is received, single-click either the left or right temple to answer.
End Call: During an active call, single-click either the left or right temple to end the call.
Reject Call: When an incoming call is received, double-click either the left or right temple to reject the call (you will hear a beep tone).

Voice Assistant


• Triple-click the left temple to activate the voice assistant.

Remote Photography (Camera Shutter)

• Remote Shutter: On an Android phone, with the camera app open, tap either the left or right temple to take a photo. On an iPhone, with the camera app open, triple-tap the right temple to take a photo.

Charging

- Please use the original charging cable and a standard 5V charger (output current ≤ 1A) to charge the device.
- The charging indicator will illuminate during charging and turn off when fully charged.



Safety Warnings

- This product contains a built-in rechargeable lithium polymer battery. Do NOT attempt to replace or remove the battery.
- Use only within a temperature range of 5°C to 35°C (41°F to 95°F). Extreme temperatures may cause battery damage or malfunction.
- Control volume levels and listening duration to prevent hearing damage. Prolonged exposure to high volume can cause permanent hearing loss.
- Do NOT expose the glasses to water, rain, or high humidity. If water enters the device, stop using immediately to avoid electric shock or damage.
- Do NOT use the glasses while driving, cycling, or in environments requiring full attention to safety and ambient sounds.
- Keep the device away from flammable materials and high-temperature environments to reduce fire and electric shock risks.
- This device is not a toy. Keep away from young children. Small parts may present a choking hazard.

Usage Notes

- Due to wireless signal interference, slight audio dropouts may occur in certain environments. This is normal behavior.
- If not used for an extended period, please recharge the battery every 3 months to prevent over-discharge and battery damage.
- Do NOT use the device while it is charging. This may cause overheating or malfunction.
- Please use the original manufacturer's certified charger (output: 5V, ≤1A). Using uncertified chargers is prohibited.

Troubleshooting

1. Cannot pair with phone?

- Please remove the device from your phone's Bluetooth settings, then re-pair according to the instructions in this manual.

2. Cannot power on?

- Please check whether the battery has sufficient charge.

3. Can the battery be replaced?

- No. This product uses a built-in, non-removable polymer lithium battery.

4. Bluetooth connection drops within 10 meters?

- Bluetooth signals can be blocked by obstacles. Please ensure there are no large metal objects between the devices.

5. No sound after connecting to a computer or phone?

- Please set the computer's audio output to the Bluetooth audio device, confirm the device supports A2DP protocol, and check the volume levels.

6. Cannot control phone apps via Bluetooth?

- Direct control via Bluetooth is not supported. App-specific functions depend on the software settings.

Package Contents

- YK-12 Smart Audio Glasses × 1
- Charging Cable × 1
- User Manual × 1
- Glasses Case × 1 (optional, depending on package)

Disclaimer

Specifications and features are subject to change without notice. Please refer to the actual product for the most accurate information.

背面

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.