

14.2x21cm

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

INSTRUCTION MANUAL

Bluetooth audio(WS-1859)

一, charge:1.External DC-5V is used to charge the machine.

2.Solar charging(solar panels and sunlight are 45.Charge for the best.

二, ON/OFF

Switch to " ON " position to turn on, dial to " OFF " position to turn off the machine.

三, “” Flashlights: Short Press 1 block flashlight (the flashlight is the brightest) ,
Short Press 2 block flashlight, Short Press 3 block flashlight flashlight flashes) ,
Short Press 4 block flashlight to close.

四, The Key Operation

1, “M” Short press: Bluetooth / Self- timer /USB/TF/RADIO/AUX switch.

2, “/V-”

Long press: for the volume reduction.

Short press: for a station in radio mode, MP3 mode to the previous song.

The self timer mode, short press “/V- ” button for the self- timer function
(only available for Windows Mobile Phones)

3, “/V+”

Long press: the volume increase.

Short press: Radio Mode for a console, MP3 mode for the next song.

In self-timer mode, short press“ /V+ ”button for the self-timer function
(only for Android)

4, “/ ”

MP3/ Radio / Bluetooth short press PLAY / pause status. Long press for autoscan radio ;

Call, short press“  /  ”Key for " Bluetooth speaker phone / answer " to switch between.

There is an incoming call, short press “ /  ”button to answer the phone,

Long press to reject

Call in the short / long Press “ /  ”button to hang up

Bluetooth static long Press “ /  ”button to dial a telephone

5, “REC/DEL”

Long press start recording (show REC) in wireless, AUX/FM mode and
long press exit recording again。 Short press to play the recording in music
mode and long press to delete the recording

五, The Self-timer function

Press " M " key from the Bluetooth mode switch to the self-timer mode ;

Open the Bluetooth mobile phone, search for " shutter ", and click Connect ;

Open your phone's camera interface, then press“/V-”or “/V+”button to take pictures.

Attachment: Android system requires version 4.2.2 or above, IOS requires version 6.0 or above, other versions are not supported for the being. camera phones have an independent entity keys are generally not supported.