

User Manual

Introductions

Thank you for choosing our company's 4G LTE POC RADIO products.

In order for you to quickly enjoy the convenient brought by this terminal product, please read the User Manual carefully before use.

The pictures in this manual are for reference only. If there is any discrepancy between the pictures and the actual product, please refer to the actual product. If there is any discrepancy between the function described and the actual function of the product, please refer to the actual function of the product.

In accordance with the principle of continuous improvement and sustainable development, our company reserves the right to modify the contents of this manual without any prior notice .We apologize for any inconvenience caused.

I . Instructions

1. Preparation Before Use

- a . Check if all accessories are complete and undamaged.
- b . If the accessories are normal, before use, pls install the SIM card provided by the operator.
- c .If you cannot log in successfully after the starting up, please check if the account is registered properly. If not, please register the terminal account on the management platform. You can use the IMEI/ICCID number as the account for registration. After registration, join the group, and then restart the terminal to use it .

1.1 Installing SIM Card

Open the card slot cover, insert the SIM card into the slot (Pay attention to the direction of the card) and then lock the card cover.

Note: After insert SIMcards successfully, the SIM card and the device will be locked after starting up. If replaced to another device , the SIM card cannot be used normally, you need to contact the card supplier to unbind the SIM card.

Pls do not insert the SIM card into other devices.

2. Basic Operations

2.1 Basic operations

Log in successfully ,enter into the home page of the device .


Intercom PTT: Press and hold on the PTT button to start speaking in the current group;release the PTT button to end the speaking. When a user speaking ,the indicator light turns red. When receiving communication ,the indicator light turns green.

Menu item: On the home page, press the menu key to enter the menu page. Menu items include: group, members, Settings, and so on.

Power switch: Turn on/off .

2.2 Groups

Press the Menu key to enter the menu list, use direction keys to select up or down, View the group



list: Select "Group",enter to the group list page to display all groups . The current group is highlighted.

Switching a group: On the Group list page, select the group you need,press the OK button .



2.3 Member List



Press the menu key ,Scroll up and down to select "member", Then press OK button

enter to the member list that is the current group.

View Member list : View all members of the group and their status:



: Online Online in same group.



: Online but in different group .



: Off-line

2.4 Call type

2.4.1 Single call: Select a member on line ,press PTT, and then release,this is created a single called.

2.4.2 Temporary group call : Select 2 or more members on line, press PTT, and then release , this is created a temporary group. Temporary group can last 30 seconds speaking maximum. If no one speaking for more than a minute ,the temporary Group will automatic disband .

2.4.3 All call : Press PTT speaking , all members in the same group all can receive voice .

2.5. Setting

Before starting used , pls select " setting"and "confirmed , and select "POC Change" and confirmed ,to check whether is the correct platform or not !

2.6 Account (About)

Enter to "Account"can see the device inforamtion .

IMEI : This number is the device's identity

ICCID: This number is SIM card No.

3. Platform

If user use POC Global platform ,The software function see the POC Global Platform instruction book .

3.1 If user is Agent account , pls see Agent user instruction book.

POC Global Platform Web Page Operation Instructions (For Agent User)

3.2 If user is "unit user" , pls see the unit user instruction book.

POC Global Platform Web Page Operation Instructions (For Unit User)

II. Product list

Name	Quantity	Unit	Remark
Charging Cable	1	piece	
Product Qualification Certificate	1	piece	
User Manual	1	piece	
4G LTE POC RADIO	1	piece	
Hand microphone	1	piece	
bracket	1	piece	

Pay attention: The product list is for reference only, if there is any change without notice , please refer to the actual products .

III. Conservation and Cleaning

In order to ensure the good performance of this product and extend its service life, please be familiar with the content as following

1. Conservation

Do not use hard objects to puncture or scratch .

When not used external headset or not charging, please close the jack cover. When move the intercom, please handle with care, Do not grab the antenna directly,

2. Cleaning

Before cleaning, please turn off the terminal device .

After cleaning, Please not use until dry completely .

Please clean the surface of machine by clean and dry lint-free cloth or brush at regularly . When the keys and surfaces of machine are dirty, it can be cleaned with special cleaning agents and non-woven fabrics (Do not use strong corrosive chemicals).

IV. Warranty

If the terminal device has a function failure that is not caused by human, it can enjoy the warranty of the walkie-talkie terminal after our after-sales testing.

V. Attention

Thank you for purchasing our electronic products, please use them correctly and safety. In order to ensure safety , do not use the others power adapter or charging cable to charge. If not ,All consequences shall be borne by the user .

Do not disassemble the product. Wrong operation will damage the terminal device.

Please avoid rain and soak in the water.

If the product accidentally falls into the water, do not charge it. First turn off the power source of the equipment, and wipe it with a dry cloth, and then dry by hair dryer.

Only supported system software from the manufacturer .

Do not use others system , If not ,All consequences shall be borne by the user.

VI. Product Specifications

Basics Parameter	
Charge Type	port
Indicator Light	Initiate speak ,the red light keep on
	Power 20% below ,the red light flash slow
	Listen to voice /play radio, the green light is keep on
	Charging,the red light keep on ;Charging over ,the green light keep on
Operated Environment	Working temperature :-35℃ ~ 75℃

Note : Above data is for reference only ,Any changes will not be notified separately, please refer to actual product .

The 4G LTE POC RADIO Great for off-roading, overlanding, logistics, camping, wilderness rescue, farm and ranch management.

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator and you body.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.