

EYES SPRAY TWIST STUNT VEHICLE

USER MANUAL

Thank you for using our company's toy products. In order to give you a better understanding of this product, please read the following instructions carefully before use. This will bring you a different operating experience.


TAKE CARE (The products in this manual are for reference only. Please refer to the actual product design!)

- Electric control products
This product is suitable for children aged 8 and above. It is assembled/charged by adults and then played by children.
Please use this product under adult supervision.
- Warning: Please do not disassemble or modify this product without authorization. Any modifications may cause the product to malfunction.

PRECAUTIONS FOR USE

1. The product body uses one rechargeable battery, and the voltage can be found in the battery room battery diagram; The handle remote control uses two 1.5V AA non rechargeable batteries;
2. The removal and installation of batteries should be carried out correctly according to the polarity and voltage inside the toy battery room;
3. Non rechargeable batteries cannot be charged;
4. Rechargeable batteries must be charged under adult supervision;
5. Rechargeable batteries should be removed from toys before charging;
6. Different types of batteries or old and new batteries cannot be mixed;
7. Only batteries that are the same or equivalent to the recommended batteries can be used;
8. Use up the battery and remove it from the toy; If not used for a long time, please remove the battery from the toy;
9. The power terminal must not be short circuited;
10. Use a screwdriver to unscrew the screws on the battery compartment cover, install the battery according to the correct positive and negative polarity, use a screwdriver to unscrew the screws on the battery compartment cover, and remove the battery;
11. Maintenance and upkeep: This product is composed of plastic, hardware, and electronic components, and should not be immersed in water. Regularly inspect the wires, plugs, casing, and other components for defects. If any defects are found, stop using until they are fully repaired.

PRODUCT CONFIGURATION (For reference only, optional)



(1)


HOW TO INSTALL BATTERIES

1. Remote control
1. Open the remote control battery cover and follow the positive and negative electrodes in the remote control battery compartment Instructions for installing AA batteries.
2. Cover the battery cover.
2. Remote-controlled vehicle
1. Open the battery cover under the car and connect the rechargeable lithium battery to the power socket Install it into the battery compartment under the car.
2. Cover the battery cover and tighten it with a screwdriver.



HOW TO CHARGE

1. This new lithium battery needs to be charged before it can be used.
2. First, insert the wire plug of the lithium battery into the charger plug, and then insert the charger plug into the socket.
3. Use 3 A 7V charger requires 120 minutes to fully charge the battery.
The charging cable is equipped with an indicator light, and the red light is on during charging and off when fully charged. Do not overcharge, as prolonged charging will not increase the battery level.




AUTOMATIC CODE MATCHING INSTRUCTIONS

1. When the battery is installed on the remote control, the indicator light on the remote control starts to flash. When the remote control car is installed with the battery and the switch is turned on, it enters the connection state. When the connection is successful, the indicator light on the remote control goes out; Note: If the connection is unsuccessful, please repeat the above operation.
2. Each remote control can only be connected to one remote control vehicle, and when the connection is successful, each vehicle will not interfere with each other; Note: Multiple vehicles cannot be connected simultaneously.
3. If the remote control fails to align with the remote control car after one minute, the power indicator light will turn off, and the power switch must be restarted to align.
4. When pairing with other remote controls or remote-controlled cars of the same model, it is necessary to turn off the power supply of the remote control and the remote-controlled car before re pairing.


HOW TO PLAY REMOTE CONTROL CARS

1. Turn on the remote control car switch, turn on the power to play the chirp sound, and play the car start sound and display lights after frequency up.
2. Operate the buttons and directional lever on the remote control to rotate the remote control car forward, backward, left, or right.
3. The seven color gradient light produces a slow flashing gradient effect as the product starts.
4. After use, simply turn off the remote control and the car will automatically enter sleep mode.



⚠ Important reminder

When removing the battery, please press the protruding position of the power socket tightly, as shown in your right hand, and do not forcefully remove it, To avoid damaging the power interface!





⚠ Important reminder

The front and rear wheels of the product cannot be twisted in the opposite direction to avoid breaking the spindle structure! If you need to manually twist, please follow Figure B and hold the center position of the front and rear wheels with both hands to twist in the same direction!


(2)

REMOTE CONTROL FUNCTION DESCRIPTION (For reference only, optional)



OPERATION PROMPT

1. Please ensure that the power switch is in the "ON" position. When you operate it, such as when the power switch is in the "OFF" position, the remote control car is in the off state.
2. When the battery power is depleted, the left and right turns become insensitive, and the forward and backward movements also slow down. At this time, the battery needs to be removed for charging.
3. The remote control car can effectively control a distance of about 30 meters. Beyond this distance, the remote control car may stop or become uncontrollable.



1. Open the cover above the spray device.
2. Add clean water to the water inlet with a water bottle, fill it up, and cover it with a lid.
3. Press the spray key after adding water, and the twist car will spray fog; Without adding water, please do not press Spray key.
4. When adding water, please be careful not to inject batteries or other areas to avoid damaging the vehicle body and parts.

(3)

GENERAL FAULT HANDLING


Symptoms of malfunction	Cause of malfunction	processing method
The vehicle cannot be driven	1. The remote control is not connected or the switch of the remote control car is not turned on. 2. The remote control or remote control car is not properly equipped with the battery. 3. Rechargeable lithium batteries have insufficient power.	1. Turn on the remote control car switch and reconnect the remote control. 2. Install the battery correctly into the remote control or remote control car. 3. Charge the rechargeable lithium battery.
Uncontrolled vehicles Remote control distance is close	1. The power of the battery or rechargeable lithium battery in the remote control is insufficient. 2. There may be sources of interference near the site.	1. Replace the battery inside the remote control with a new one, or charge the rechargeable lithium battery. 2. Change the venue.
Abnormal protection	When the remote control car function is obstructed by external forces and cannot complete the full action of the function, or when the circuit battery is short circuited.	Turn on the power switch again and remotely control the car for power-off protection.

MAINTENANCE MATTERS

1. Do not approach the source of fire, avoid direct sunlight, high temperature and humidity, or keep it in the car for a long time to avoid short circuits and fires in the wiring.
2. When not playing, remove the battery of the car and remote control, and put the remote control car and remote control back into the packaging to avoid damage or deformation during transportation or storage.
3. The remote control car must be gently wiped with a damp cloth.

KIND REMINDER

When the car is moving, please do not touch the wheels of the remote control car with your hands to avoid injury.



Do not play on the roadside or in dangerous places to prevent accidents.



Do not play with the remote control car in the sewage pit.

INSTRUCTIONS


The battery charger used in this toy must be regularly inspected to prevent damage to the wires and other components. If damaged, it must be repaired before use.

(4)

TO CONSUMERS

1. When playing with a remote control car indoors, please be careful not to damage furniture or glass.
2. Please play outdoors in a safe place and do not play with remote control vehicles on roads or in crowds to avoid danger.
3. When playing remote control cars outdoors and hearing thunder, you should immediately stop playing.
4. When the wheels are rotating, do not reach your hands close to avoid injury, and do not get caught in hair, clothes, etc.
5. Do not drive the remote control car towards people.
6. Do not litter or collide with the remote control vehicle.
7. When placing the remote control car, please stay away from sources of fire and high temperatures.
8. This vehicle uses complex electronic circuits and a large number of components. Please do not disassemble or modify the circuit board at will.
9. When the remote control car is covered with soil and dust after playing, it should be gently wiped with a damp cloth.
10. Do not put toys in water, as it may damage electronic components.

GESTURE SENSING OPERATION INSTRUCTIONS



(5)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.