




INSTRUCTION MANUAL

RF emission area



Note:

1. The Remote controller is for indoor use only.
The power On/Off functions and lighting modes can be controlled with either the remote controller or the control box.

2. The remote Controller function Keys are as follow:

- A Press once: On
- Press 2 times: 4 Hours On / 20 Hours Off, with 3 Red flashes
- Press 3 times: 6 Hours On / 18 Hours Off, with 3 Green flashes
- Press 4 times: 8 Hours On / 16 Hours Off, with 3 blue flashes
- Press 5 times: timer Off, with 3 White flashes
- B OFF
- C Brightness increase
- D Brightness decrease
- E Press shortly: Switch to previous steady colour
- F Press shortly: Switch to next steady colour
- G Auto Effects Mode
- H Previous function
- I Next function
- J Speed increase
- K Speed decrease
- L 8 buttons, total 28 Special Effects

3. RF Remote Control Range (Single Unit, Unobstructed): 32ft minimum

Important Note on Multi-Unit Synchronization:

This product features default synchronization when powered on.

The more units you use together, the shorter the effective control range will become.

The above range applies to a single unit in an unobstructed environment (same indoor or same outdoor space, no walls or obstacles blocking the signal).

For multi-unit setups, keep the controller within line of sight and closer to the products to ensure reliable control.

Static colors and Special Effects can be synchronized via the controller/remote within signal range. Each dynamic function key offers multiple distinct effects. For details, see the next page.

4. How to Cancel Synchronization

Step 1: Disconnect power from the products for which synchronization is to be canceled.

Step 2: Plug in one product. Within 5 minutes of power application, press and hold the Left Button (E) on the remote control for 3 seconds to disable synchronization. The product can then be controlled individually via the controller.

Step 3: To disable synchronization for additional products, repeat Step 1 and Step 2 for the remaining products one by one.

Note: For RF remote, after synchronization has been disabled, products must be placed sufficiently far apart or separated by obstructions to prevent interference during remote operation. Otherwise, the products will still receive signals and display identical effects.

5. How to Resynchronize Products with Synchronization Disabled

Step 1: Disconnect power from the products for which synchronization has been disabled.

Step 2: Plug in one product. Within 5 minutes of power application, press and hold the Right Button (F) on the remote control for 3 seconds to enable synchronization. The product can then be controlled synchronously via the controller or remote control.

Step 3: To enable synchronization for additional products, repeat Step 1 and Step 2 for the remaining products one by one.

6. How to Set the Timer Function

Method 1: Via the ON button on the remote control

Press once: On

Press 2 times: 4 Hours On / 20 Hours Off, with 3 red flashes

Press 3 times: 6 Hours On / 18 Hours Off, with 3 green flashes

Press 4 times: 8 Hours On / 16 Hours Off, with 3 blue flashes

Press 5 times: timer Off, with 3 white flashes

Method 2: Via controller

Press once: On


Press & hold for 3 seconds (1st time): 4 Hours On / 20 Hours Off, with 3 red flashes

Press & hold for 3 seconds (2nd time): 6 Hours On / 18 Hours Off, with 3 green flashes


Press & hold for 3 seconds (3rd time): 8 Hours On / 16 Hours Off, with 3 blue flashes

Press & hold for 3 seconds (4th time): Timer Off, with 3 white flashes

The timer function will be cancelled after a power outage.



Number	Button	Steady Color
1	E&F	Red
2		Green
3		Blue
4		Cool White
5		Warm White
6		Purple
7		Orange
8		Multi Color (Red, Green, Blue, Yellow, Purple)
9		Red+Green
10		Red+Cool White
11		Blue+Cool White
12		Red+Green+Cool White
13		Red+Blue+Cool White
14		Green+Cool White
15		Orange+Purple
Number	Button	Special Effects
1	SPARK (white point flash)	Blue+White Sparkle
2		Red+White Sparkle
3		Multi+White Sparkle
4		Red-Green-White chasing
5	CHASE (chasing)	Red-White chasing
6		Red-White-blue chasing
7		Orange-Purple chasing
8	RNBW (rainbow)	Rainbow waterfall
9		Rainbow fade
10	COMBO (twinkle)	Red-Green-White twinkle
11		Red-White-Blue twinkle
12		Orange-Purple twinkle
13	WAVE (wave)	Warm White-cool white twinkle
14		Red-Green-White wave
15		Rainbow wave
16		Orange-Purple wave
17		Blue-White wave
18	TWNKL (flash)	Warm White-cool white wave
19		Multi color flash
20		Warm White-cool white flash
21		Green-White flash
22	SNOW (snow stack)	Orange-Purple flash
23		Cool White snow stack
24		Rainbow snow stack
25	MTR (meteor shower)	Cool White meteor shower
26		Blue-White meteor shower
27		Red-White meteor shower
28		Orange-Purple meteor shower



Switch colors and functions
by pressing the button on the controller.

Number	Category	Description
1	15 Steady Color	Auto Effects Mode
2		Red
3		Green
4		Blue
5		Cool White
6		Warm White
7		Purple
8		Orange
9		Multi Color (Red, Green, Blue, Yellow, Purple)
10		Red+Green
11		Red+Cool White
12		Blue+Cool White
13		Red+Green+Cool White
14		Red+Blue+Cool White
15		Green+Cool White
16		Orange+Purple
17	28 Special Effects	Blue+White Sparkle
18		Red+White Sparkle
19		Multi+White Sparkle
20		Red-Green-White chasing
21		Red-White chasing
22		Red-White-blue chasing
23		Orange-Purple chasing
24		Rainbow waterfall
25		Rainbow fade
26		Red-Green-White twinkle
27		Red-White-Blue twinkle
28		Orange-Purple twinkle
29		Warm White-cool white twinkle
30		Red-Green-White wave
31		Rainbow wave
32		Orange-Purple wave
33		Blue-White wave
34		Warm White-cool white wave
35		Multi color flash
36		Warm White-cool white flash
37		Green-White flash
38		Orange-Purple flash
39		Cool White snow stack
40		Rainbow snow stack
41		Cool White meteor shower
42		Blue-White meteor shower
43		Red-White meteor shower
44		Orange-Purple meteor shower
45	OFF	OFF

For questions and/or assistance, call customer service at 1-800-352-5442 or visit us at the web at www.geholiday.com.
 PRINTED IN CHINA
 GE and the GE Monogram are trademarks of General Electric Company.
 Manufactured and used under trademark license.
 ©2026 Balsam Brands, Inc.

MADE IN CHINA

FCC notices:

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Model: JY-08

Balsam Brands Inc.

50 Woodside Plaza, Redwood City, CA 94061 USA

www.geholiday.com