




To ensure the safe and proper use of this product, please read this manual thoroughly before use and retain it for future reference.

1. Prepare the area designated for installation by ensuring that the surface is clean, flat, and dry. Securely attach the colored permanent outdoor lights to the intended location and press them firmly in place.
2. Connect the controller of the permanent outdoor lights to the permanent outdoor lights in a sequential manner. If not connected properly, it will not function.
3. Connect the power adapter to the electrical outlet, and then attach the adapter to the controller.
4. Download the app on your phone, or remove the plastic film from the remote control to operate the permanent outdoor lights.

2

How to connect to APP

- (1) In the App Store on your iPhone or Google Play on your Android device, search for "iDeal Led."
- (2) Open your mobile browser and scan the QR code to access the download page. Choose the appropriate installation method for your device.
- (3) When you first install the app, a prompt will appear asking, "Allow browser to install apps." Please ensure that you check the "Allow" option.



4

Function of buttons

First and foremost, ensure that Bluetooth and GPS are enabled on your phone.


Open the app and tap on the detected Permanent Outdoor Lights to access the control interface. Press button ① to connect. The Permanent Outdoor Lights will automatically connect the next time you use them.

Tap the button and scroll to the right to confirm that the connection has been successful.

- ② to navigate to the "DIY" interface
- ③ to access the "Scenes" display interface
- ④ to go to the "Collect" display interface
- ⑤ to navigate to the "Cycle" playing interface.
- ⑥ to access the "Camera" color selection interface
- ⑦ to enter the interface of "Rhythm" and sound control.
- ⑧ to go to the "Timer" interface.
- ⑨ to navigate to the "Settings" interface.
- ⑩ Press the "ON" button to turn the string lights system on or off.


If you purchase 2 or more permanent outdoor lights: Connect 2 parts in series by clicking the left button (up to 4 are supported) Connect 2 parts in parallel by clicking the right button (up to 4 are supported)

6




Note: When you first open the app, a prompt will appear asking if the "iDeal Led" option is allowed to access your device's location information. Please select "Allow only when in use."


5



7




8




9




10




11




12




13



14



15



16

