


YINPAGE 音贝奇



—— 真无线主动降噪耳机 ——

Real 1 Pro
使用说明书



【扫码下载“音贝奇”APP】

2. 连接

首次连接设备，请将两只耳机同时取出，打开手机搜索“YINPAGE Real 1 Pro”进行连接。接成功后，后续使用，无需重复连接。

3. 关机

耳机放入充电仓即可关机充电

注意：蓝牙无连接状态，5分钟自动关机



二、功能操作

按键功能	操作	提示音	指示灯
接听/挂断	单击	/	/
播放/暂停	单击	/	/

拒接电话	长按	/	/
下一曲	双击右耳	/	/
游戏模式	双击左耳	游戏模式/ 音乐模式	/
语音助手	三击	/	/
降噪模式	长按	普通/通透/降噪	/
低电报警	当电池电压低于3.2v	和弦音	白灯慢闪 (5秒钟重复一次)
低电关机	当电池电压低于3.1v 耳机将自动关机	和弦音	白灯闪3次
恢复 出厂设置	蓝牙断开状态，长按耳机8秒复位重启，单/双耳均可操作。复位后清除手机配对信息及耳机组码	/	白、冰蓝灯同时亮起15后重启耳机
耳机充电	耳机放入充电盒即可自动充电	/	充电白灯长亮， 充电盒亮冰蓝灯，充满电后耳机转蓝灯30秒后熄灭

充电仓充电	充电仓连接TYPE-C	/	充电时白灯闪， 充满电时白灯长亮， 蓝牙耳机充电冰蓝灯长亮， 低电冰蓝灯闪
-------	-------------	---	--

四、产品安全信息

在使用本产品前请阅读所有的提示和警告，不规范使用将会给产品或人身安全带来损害。

1. 产品内含电池，请勿将本产品暴露在烈日或暖灯等过热环境中。请勿将本产品存放在高温、强光及强磁环境下。

2. 产品不可放置在火源附近等恶劣环境中，禁止敲击，投掷，践踏，挤压或投入火中；若出现鼓胀，请勿使用。

3. 产品使用温度：45℃以下。

4. 请勿违反说明书中不当使用，造成产品损坏或危及人身安全，后果自行承担。

5. 非专业人员严禁分解本产品，否则可能会导致起火，甚至彻底损坏本产品。

6. 请勿使用超出本产品电流负载（用电器），超出负载会自动停止工作。

7. 请定期用干净的棉布对耳机充电触点进行清洁，以避免长期不清洁导致耳机无法充电或开机的情况。

8. 请勿将本产品置于水中（或洗衣机中），若产品出现现

水情况，请等待其自然晾干后再使用。

9.防潮袋，除味珠等配件物料，放至儿童无法接触到的位置，防止误食；切勿置于水中，避免产生激烈化学反应，影响人身及财产安全，后果自行承担。

电子信息产品有害物质声明：

有害物质或元素	塑料部件	金属部件	线路板	线缆
铅	BL	BL	BL	BL
汞	BL	BL	BL	BL
镉	BL	BL	BL	BL
六价铬	BL	BL	BL	BL
多溴联苯&多溴二苯醚	BL	NA	BL	BL

本表格依据SJ/T11364 规定编制。
注：OL =超出限值，BL=低于限值，X=不确定，NA =不适用。
执行标准：GB/T 26572-2011

The diagram illustrates the contents of the package. On the left is a white, oval-shaped earphone case with the 'YINPAG E' logo. To its right are six earbuds arranged in two rows of three; the top row shows three small earbuds and the bottom row shows three medium-sized earbuds. Further right is a black charging cable with a USB-A connector on one end and a small circular connector on the other. On the far right is a white rectangular card, likely the user manual or warranty card, with horizontal lines representing text.

后服务中心，可委托经销商进行包换服务，

3. 您所购买的商品，经本公司检测确定后，可享受12个月（产品质量原因）保修服务，服务方式-客户送修；随机配件为消耗品，不在保修范围。

非保修条例

1. 未经授权的维修、误用、碰撞、疏忽、滥用、事故、改动，或篡改拆除标识、防伪标记；

2. 产品原序列号标签有涂改，替换，撕毁等现象；

3. 质保凭证上的型号，编号与产品实物不符的；

4. 产品超出本公司规定的质保期限；

5. 非正常使用导致外表破损；

6. 外包装及内附的赠品，销售人员承诺的产品之外的服务及附加的配置和赠品；

7. 不当存储：如产品长时间暴露在非正常温度，温度环境中造成的性能损害；

8. 未按操作说明，人为滥用，擅自改装造成产品损坏的，因不可抗力造成的损坏。

保修记录表

尊敬的用户，非常感谢您使用爱奇艺产品，请您认真填写并妥善保管。

本公司保留对该产品服务条例的解释权。

保修卡

经销商信息		用户姓名	
用户姓名		保修内容	
联系电话		保修日期	
邮箱		保修日期	
通讯地址			

售后热线：400-808-2787


 检验员：

PASSED

【制造商】 爱奇艺(深圳)科技有限公司
 【地址】 深圳市龙岗区坂田街道马安堂社区环境南路5号坂田国际中心A栋
 【联系电话】 400-808-2787

警告：仿冒必究
 执行标准：GB 4943.1-2022《音视频、信息技术和通信技术设备第1部分：安全要求》

YINPAGE



— TWS wireless headset —

Real 1 Pro

instructions for use



[Scan the QR code to
download "YINPAGE"the APP]

Fingerprint sensing area
(1/3 position of headphone handle)

Fingerprint sensing area
(1/3 position of headphone handle)

YINPAGE

YINPAGE

2. connect

When connecting the device for the first time, please take out both earphones at the same time, open your phone and search for "YINPAGE Real 1 Pro" to connect. After the connection is successful, there is no need to connect again for subsequent use.

3.Power off

The earphones can be turned off and charged when placed in the charging compartment.

Note: Bluetooth is not connected and will automatically shut down after 5 minutes.



2. Functional operation

Key Function	manipulate	Prompt tone	Indicator Lights
Answer / hang up	click	/	/
Play / Pause	click	/	/

Do not answer the phone.	long press	/	/
next song	Double click on the right ear	/	/
game mode	Double click on the right ear	Game Mode/ Music Mode	/
voice assistant	three-strike	/	/
noise reduction mode	long press	Normal/TTrough/Noise Reduction	/
Low Power Alarm	When the battery voltage is below 3.2v	chord tone	/
Low power shutdown	When the battery voltage is lower than 3.1v, the headset will automatically shut down.	chord tone	White light flashes 3 times
Restore Factory Settings	Bluetooth disconnected state, long press the start button for 8 seconds to reset and enter " " high-level can be operated. Clear cell phone pairing information and pairing from the reset	/	White light blue light for 15s and then restart the headset
Headset Charging	Headphones charge automatically when placed in the charging case	/	Charging in white light long light, charging not light in a bar light fully charged and red light turns to blue light 30s after off

Charging Compartment Charging	Charging compartment connection type-C port	/	The white light flashes when charging, the white light stays on when fully charged, the ice blue light stays on when charging the headset, and the ice blue light flashes when the battery is low.
-------------------------------	---	---	--

3. Product Parameters

Play time	About 8-10 hours	Connection distance	>10M
Standby time	>90 Days	Call duration	About 6-8 hours
Microphone sensitivity	-38[±2] dB	Speaker	10mm
Headphone battery	40mAh	Charging time	≤2 hours
Charging case battery	400mAh	Frequency range	20-20000Hz

FCC ID: 28NT7-REAL1PRO

4. Product safety information

may cause damage to the product or personal safety.

1. The product contains batteries. Please do not expose this product to strong sunlight or overheating environments such as stoves. Do not store this product in high temperature, strong light or strong magnetic environments.
2. The product cannot be placed in harsh environments such as near fire sources. It is prohibited to knock, throw, trample, squeeze or throw it into fire; if it bulges, do not use it.
3. Product operating temperature: below 45°C.
4. Please do not violate the instruction manual and use it inappropriately, causing damage to the product or endangering personal and property safety. You will be responsible for the consequences.
5. Non-professionals are strictly prohibited from disassembling this product, otherwise it may cause a fire or even completely damage the product.
6. Do not use electrical appliances that exceed the current load of this product, if the load is exceeded, it will automatically stop working.
7. Please clean the charging contacts of the earphones regularly with a clean cotton cloth to avoid the inability to charge or turn on the earphones due to long-term uncleaning.

8. Do not place this product in water (or in a washing machine). If the product gets wet, please wait for it to dry naturally before using it.

9. Keep moisture-proof bags, deodorizing beads and other accessories out of the reach of children to prevent accidental ingestion; do not place them in water to avoid violent chemical reactions that may affect personal and property safety. You are responsible for the consequences.


Declaration of Hazardous Substances in Electronic Information Products:

Hazardous substances or elements	plastic parts	metal parts	circuit board	cable
Pb	BL	BL	BL	BL
Hg	BL	BL	BL	BL
Cd	BL	BL	BL	BL
Cr ⁶⁺	BL	BL	BL	BL
PBBS&PBDEs	BL	BL	BL	BL

This form is prepared in accordance with SJ/T11364.

Note: OL = Out of limits, BL = Below limits, X = Not sure, NA = Not applicable.

5. Packing list



The diagram illustrates the components included in the product's packaging. At the top left is the device itself, labeled 'VINPAGE'. To its right is a power cord with a two-prong AC plug. Below the device are two earphone options: a small one and a large one, with a note '(Includes headphones over ear)'. To the right of the earphones is a charging cable with a USB-A connector and a device-specific connector. On the far right is a document labeled 'Instruction manual/warranty card'.

Small, medium
and large ear caps*
(Includes headphones over ear)

Earphones*1

Charging cable*1

Instruction manual/
warranty card*1

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment and/or the antenna is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

6. Warranty policy

Goodness Day 1. From the date of receipt, there is no reason to return the goods within 7 days, and there is a free exchange within 15 days (such as Tmall, JD, etc.). For returns and exchanges that are not related to quality issues, the shipping cost will be borne by the consumer, and for re-shipments, the shipping cost will be borne by the merchant. If there are invoices and gifts, please send them back together.

2. If you purchased from a local store, you can enjoy the 15 day replacement service provided by our company from the date of purchase at the local after-sales service center. If there is no after-sales service center locally, you can entrust a dealer to provide the replacement service. Random accessories are consumables and are not covered by warranty.

Non-warranty regulations

- 1. Unauthorized repair, misuse, collision, negligence, abuse, accident, modification, or tearing and altering of labels or anti-counterfeiting marks;
- 2. The original serial number label of the product shows signs of tampering, replacement, tearing, etc.;
- 3. The model and number on the quality assurance certificate do not match the actual product;
- 4. The product exceeds the warranty period specified by our company
- 5. External damage caused by abnormal use;
- 6. Outer packaging and accompanying gifts, services beyond the products provided by sales personnel

And additional configurations and gifts;

- 7. Improper storage: such as performance damage caused by prolonged exposure of the product to abnormal temperatures or temperature environments;
- 8. Damage to the product caused by failure to follow the operating instructions, human abuse and misuse, unauthorized modification, and force majeure.

Warranty record form

Dear user, thank you very much for using Yinbeiqi products. Please fill it out carefully and keep it properly.

The company reserves the right to interpret the after-sales service regulations for this product.

Warranty Card:

Dealer information			
Username			
Username	Warranty content		
Contact number			
E-mail	Warranty Date		
Mail address			

QC
PASSED

TEL:400-808-2787 Inspectors: _____

[Manufactured] YINBEIQISHENZHENTECHNOLOGY CO., LTD.
 [Address] Building A, Bantian International Center, No. 1 Haancheng South Road,
 Maantang Community, Bantian Street, Longgang District, Shenzhen
 [Contact number] 400-808-2787

Warning: Counterfeiting will be prosecuted
 Implementation standard: GB 4943.1-2022 [Audio/video/information and communication technology equipment—Part 1:
 Safety requirements]