


80mm

180mm

WIRELESS EARBUDS
Instruction Manual

Please read the following carefully before using this device to ensure safe and proper usage.



Battery box

white lights indicate the battery capacity of the charging box.
Charge the battery box: the battery box is charged through the Type-C port.
It needs about 3 hours to get full charged.


Earbuds:

Turn on/off by touch button: when the earbuds are out of charging box, user can turn its on/off by long press the touch button for 3 seconds. When it's turned off, the prompt tone is "power off", and the prompt tone is "power on" when it's turned on. Low-battery mode: when the earbud's remaining power is low, the prompt tone Of "low battery" comes out and the earbud will be turned off after a while. When left&right paired successfully, the prompt tone is "connected". After the earbuds paired with mobile phone successfully, the prompt tone is "connected". After the earbuds paired with mobile phone successfully, the prompt tone is "connected".

Charging mode: put the earbuds in the charging box to enter into charging status.
In charging mode, white indicators will show the battery status of charging box.

Parameters
Model: BTE700
Wireless version: V5.3
Earbud battery: 3.7V 35mAh
Charger box: 3.7V 300mAh
Playing time: about 4 hours (60% volume)
Standby time (after pairing): about 60hs
FCC ID: 2BNTC-BTE700

Wearing Overview



Function of Power button

NO.	Button operation	Status before execution	Status after execution	Prompt tone	LED status
1	Long press for 3 seconds	Power on	Power off	Power off	N/A
2	Long press for 2 seconds	Power off	Power on	Power on	N/A
3	Single click	Paired with iPhone	Enter into "Siri"		
		incoming call	rejection		
		Music playing mode	Play/pause		
		incoming call	Pick up		
		On line	Hang off		
4	Fast double click	Music playing mode	Left earbud: skip to previous song		
			Right earbud: skip to next song		
5	Fast triple click	Music playing mode	Left earbud: increase the volume		
			Right earbud: reduce the volume		

Note:


- The left earbud will pair with right one automatically once its power on. If only one earbud connected with mobile phone, maybe the left&right earbuds haven't successfully paired. Shut off the mobile phone's BT and pair the left earbud with right one again. After left&right earbus are successfully connected, open mobile phone's BT and pair it with earbuds.
- If there is not BT device pair with the earbuds for over 5 minutes, the earbuds will be turned off automatically.
- Don't store the product into high temperature, nearby fire or touch with caustic chemical.
- The headphone isn't waterproof, please don't use it in water or humidity environment.
- Don't disassemble the product by yourself, unprofessional operation might damage the product.
- If don't use the product for a long time, should charge it every month to keep the battery's energy.
- For your safety, don't use the headphone when cross the street or walk on the road of heavy traffic.
- High volume will hurt your hearing, please use the suitable volume and avoid to wear the headphones for long time.
- The high frequency transmitter (such as WiFi, traffic light) will affect the signal of BT and cause it's stuck or broken.

180 x 80mm 70g书写纸 单面单黑印刷

说明书风琴页折法:

WIRELESS EARBUDS
Instruction Manual

Please read the following carefully before using this device to ensure safe and proper usage.



Battery box

white lights indicate the battery capacity of the charging box.
Charge the battery box: the battery box is charged through the Type-C port.
It needs about 3 hours to get full charged.


Earbuds:

Turn on/off by touch button: when the earbuds are out of charging box, user can turn its on/off by long press the touch button for 3 seconds. When it's turned off, the prompt tone is "power off", and the prompt tone is "power on" when it's turned on. Low-battery mode: when the earbud's remaining power is low, the prompt tone Of "low battery" comes out and the earbud will be turned off after a while. When left&right paired successfully, the prompt tone is "connected". After the earbuds paired with mobile phone successfully, the prompt tone is "connected". After the earbuds paired with mobile phone successfully, the prompt tone is "connected".

Charging mode: put the earbuds in the charging box to enter into charging status.
In charging mode, white indicators will show the battery status of charging box.

Parameters
Model: BTE700
Wireless version: V5.3
Earbud battery: 3.7V 35mAh
Charger box: 3.7V 300mAh
Playing time: about 4 hours (60% volume)
Standby time (after pairing): about 60hs
FCC ID: 2BNTC-BTE700

Wearing Overview



Function of Power button


NO.	Button operation	Status before execution	Status after execution	Prompt tone	LED status
1	Long press for 3 seconds	Power on	Power off	Power off	N/A
2	Long press for 2 seconds	Power off	Power on	Power on	N/A
3	Single click	Paired with iPhone	Enter into "Sin"		
		incoming call	rejection		
		Music playing mode	Play/pause		
		incoming call	Pick up		
		On line	Hang off		
4	Fast double click	Music playing mode	Left earbud: skip to previous song		
			Right earbud: skip to next song		
5	Fast triple click	Music playing mode	Left earbud: increase the volume		
			Right earbud: reduce the volume		

Note:

- The left earbud will pair with right one automatically once its power on. If only one earbud connected with mobile phone, maybe the left&right earbuds haven't successfully paired. Shut off the mobile phone's BT and pair the left earbud with right one again. After left&right earbus are successfully connected, open mobile phone's BT and pair it with earbuds.
- If there is not BT device pair with the earbuds for over 5 minutes, the earbuds will be turned off automatically.
- Don't store the product into high temperature, nearby fire or touch with caustic chemical.
- The headphone isn't waterproof, please don't use it in water or humidity environment.
- Don't disassemble the product by yourself, unprofessional operation might damage the product.
- If don't use the product for a long time, should charge it every month to keep the battery's energy.
- For your safety, don't use the headphone when cross the street or walk on the road of heavy traffic.
- High volume will hurt your hearing, please use the suitable volume and avoid to wear the headphones for long time.
- The high frequency transmitter (such as WiFi, traffic light) will affect the signal of BT and cause it's stuck or broken.

WIRELESS EARBUDS
Instruction Manual

Please read the following carefully before using this device to ensure safe and proper usage.



Battery box

white lights indicate the battery capacity of the charging box.
Charge the battery box: the battery box is charged through the Type-C port.
It needs about 3 hours to get full charged.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

折后正面

折后背面

折后尺寸: 60 x 80mm

标准说明书

JMTek

图 号
型 号
料 号

BTE700-SMS-JMT001

BTE700

版 次

第1版

材 料

制图

Sam

颜 色

确认

Steven

单 位

客户回签

mm

日 期

260115

第三角度投影



第 1 张 共 1 张