


90mm

280mm



Wall Speaker Set
Instruction Manual

Please read the following carefully before using the device to ensure safe and proper use.

Package Content:
1x Pair of Wireless Speakers
1x USB-A to Type C Charging Cable
1x Instruction Manual



Instruction:



1	◀	• Press once to switch to previous song. • Press and hold to turn down the volume.
2	M	Press once to switch to FM radio/Bluetooth mode.
3	▶	• Press once to switch to next song. • Press and hold to turn up the volume.
4	⏻/⏸	• Press and hold 1-2 second to turn on / off of the speaker. • Press once to play / pause. • Press once to pick up or ending the phone call. • Press and hold for 1-2 seconds to reject phone call.
5	☀	Short press to adjust the RGB Lights, Total of 7 light mode.
6	Aux-in port	Aux-in mode
7	USB Port	USB mode
8	TF card port	TF mode USB-C
9	Charging port	USB-C charging port
TWS mode		Press and hold 'M' (one of the speaker) for around 3 seconds.

Specifications:

Bluetooth Version	5.4
Battery capacity	1800mAh
Speaker power	5W*2
Bluetooth frequency	2402-2480mHz
Charge time	4-5 hours
Play time	2 hours
Function	Handsfree, TF card, FM,AUX-IN, Bluetooth,support TWS,RGB Light

Pairing Instructions

- Long press ⏻/⏸ 2 seconds to enter the pairing state.
- Turn on the Bluetooth search function of the phone or any other device that you want to connect to, and the phone will show that "BTS60" has been found.
- Select "BTS60" (enter 0000 as pairing password for some phones) it will automatically connect to your phone, you will hear a confirmation sound, meaning the connection is successful.

Please note:

- Make sure the two devices via Bluetooth* are within 30 feet in order for them to be paired. Once the devices are paired successfully, they will reconnect to the device automatically when turned back on as long as your Bluetooth* connection is enabled.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

正面
Side A

背面
Side B


280 x 90mm
70g书纸
双面单黑印刷

说明书折法：



Wall Speaker Set
Instruction Manual

Please read the following carefully before using the device to ensure safe and proper use.

Package Content:
1x Pair of Wireless Speakers
1x USB-A to Type C Charging Cable
1x Instruction Manual



Instruction:



Total of 7 light mode.

1	◀	• Press once to switch to previous song. • Press and hold to turn down the volume.
2	M	Press once to switch to FM radio/Bluetooth mode.
3	▶	• Press once to switch to next song. • Press and hold to turn up the volume.
4	⏻/⏸	• Press and hold 1-2 second to turn on / off of the speaker. • Press once to play / pause. • Press once to pick up or ending the phone call. • Press and hold for 1-2 seconds to reject phone call.
5	☀	Short press to adjust the RGB Lights, Total of 7 light mode.
6	Aux-in port	Aux-in mode
7	USB Port	USB mode
8	TF card port	TF mode USB-C
9	Charging port	USB-C charging port
TWS mode		Press and hold 'M' (one of the speaker) for around 3 seconds.

Specifications:

Bluetooth Version	5.4
Battery capacity	1800mAh
Speaker power	5W*2
Bluetooth frequency	2402-2480mHz
Charge time	4-5 hours
Play time	2 hours
Function	Handsfree, TF card, FM,AUX-IN, Bluetooth,support TWS,RGB Light

Pairing Instructions

- Long press ⏻/⏸ 2 seconds to enter the pairing state.
- Turn on the Bluetooth search function of the phone or any other device that you want to connect to, and the phone will show that "BTS60" has been found.
- Select "BTS60" (enter 0000 as pairing password for some phones) it will automatically connect to your phone, you will hear a confirmation sound, meaning the connection is successful.


Please note:

- Make sure the two devices via Bluetooth* are within 30 feet in order for them to be paired. Once the devices are paired successfully, they will reconnect to the device automatically when turned back on as long as your Bluetooth* connection is enabled.

Wall Speaker Set
Instruction Manual

Please read the following carefully before using the device to ensure safe and proper use.

Package Content:
1x Pair of Wireless Speakers
1x USB-A to Type C Charging Cable
1x Instruction Manual



Specifications:

Bluetooth Version	5.4
Battery capacity	1800mAh
Speaker power	5W*2
Bluetooth frequency	2402-2480mHz
Charge time	4-5 hours
Play time	2 hours
Function	Handsfree, TF card, FM,AUX-IN, Bluetooth,support TWS,RGB Light

Pairing Instructions

- Long press ⏻/⏸ 2 seconds to enter the pairing state.
- Turn on the Bluetooth search function of the phone or any other device that you want to connect to, and the phone will show that "BTS60" has been found.
- Select "BTS60" (enter 0000 as pairing password for some phones) it will automatically connect to your phone, you will hear a confirmation sound, meaning the connection is successful.

Please note:

- Make sure the two devices via Bluetooth* are within 30 feet in order for them to be paired. Once the devices are paired successfully, they will reconnect to the device automatically when turned back on as long as your Bluetooth* connection is enabled.

折后正面

折后背面

折后尺寸：70 x 90mm

第1折痕

第2折痕

第3折痕

标准说明书

JMTek

图号	BTS60-SMS-JMT001
型号	BTS60
料号	70431-0406-01

版次	第1版	材料	
日期	251015	制图	Sam
第三角度投影			

第 1 张 共 1 张