


SIZE:72.727x100mm



USER'S MANUAL

Item: WMA3000

SAFETY PRECAUTIONS

When using your INCIPIO Spin Beats Wireless Speaker, basic safety precautions should always be followed, including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER.
2. Do not allow children or the infirm to play with your speaker without adult supervision.
3. Do not expose your speaker to excessive heat, flames or fire.
4. Do not expose your speaker to high humidity, moisture, or water.
5. Always press all buttons carefully. Do not manhandle your speaker.
6. Do not use in extremely dry environments, as this can lead to static discharge during usage.
7. Do not expose your speaker to extreme temperatures of hot or cold.
8. Do not attempt to repair this product yourself. Contact a qualified service center if your speaker is in need of service.
9. Do not drop, puncture, or expose your speaker to excessive trauma.
10. Your speaker is not intended for commercial use.
11. Do not place near objects that generate a strong magnetic field.
12. Use only the supplied charging cables. Unplug this device when not in use for long periods of time or during lightning storms.
13. Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.

BATTERY WARNING:
-The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
-Do not dispose of in fire or expose to excessive heat.
-Do not crush, puncture, incinerate, or short circuit external contacts.
-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

INTRODUCTION

Thank you for purchasing the INCIPIO Spin Beats Wireless Speaker, item WMA3000. In order to have the best experience, please read this manual carefully before using the wireless speaker.


PACKAGE CONTENTS

- Spin Beats Wireless Speaker
- USB-C Charging Cable
- User's Manual With Warranty Information
- Strap for Spin Beats

FEATURES


- RGB Rhythm Lights
- Spinning Top Style
- Compact Play
- Superior Sound

A CLOSER LOOK




WIRED CHARGING

STEP 1. Insert one end of the included charging cable into the charging port on your speaker.



STEP 2. Insert the other end into a suitable USB charging adapter.



The Charging indicator light will illuminate red while the speaker is charging and will turn OFF when fully charged.

POWERING ON/OFF


Press and hold the Power button for approximately three seconds to power ON/OFF.




Note: It is recommended to fully charge the speaker before first use.

BLUETOOTH PAIRING

Pairing Mode
(Blue Light Flashing)




Once powered on, your speaker will go into pairing mode. The LED Indicator will turn blue and flash rapidly.



Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as "WMA3000."

Paired
(Blue)



Once paired, a tone will sound from the speaker. The LED Indicator will stop flashing and remain blue. Note that the light may flash slowly while music is playing.

USING THE SPEAKER

Multifunction Button
-Press and hold for three seconds to power ON/OFF.
-Press to play or pause a track.

Volume Up/Next Track Button
-Press and hold to increase the volume.
-Press to skip to the next track.

Volume Down/previous Track Button
-Press and hold to decrease the volume.
-Press to skip to the previous track.

Light Mode Button
-Press and hold for three seconds to turn the RGB lights ON/OFF.
-Press to cycle through the available light modes.

Rotation
-The speaker has limited rotating functionality, enabling it to spin using the rotation plates. Handle with care. Do not use excessive force while handling the device.

TWS Pairing
NOTE: Only on certain models can you pair two speakers together.
-Press the Volume Up/Next Track Button twice to pair the speaker with a compatible model.

MAINTENANCE AND CARE

-Use a soft cloth or paper towel to clean your speaker. Never use any harsh chemicals or detergents for cleaning. Make sure your speaker is dry before charging.

-When your speaker is not in use, it should be stored in a cool, dry place.

-Never tug or yank on a cable while it is connected to your speaker. Connect and disconnect cables as carefully as possible.

-Never expose your speaker to high temperatures or extreme cold.

SPECIFICATIONS

BLUETOOTH VERSION: 5.3
WORKING DISTANCE: UP TO 10 METERS
PLAY TIME: UP TO 2-4 HOURS*
BATTERY CAPACITY: 400 mAh,3.7V

*Applicable at 50% of maximum volume. Results will be lower when volume is higher.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. The device shall be operated and installed without restriction.

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered By Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including, but not limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 or visit our website at www.incipio.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai

INCIPIO

©2026 INCIPIO
195 Carter Drive
Edison, NJ 08817
Support: 800 592 9541
www.incipio.com