

FD131无线蓝牙耳机



使用说明书

FD131Wireless
bluetooth headset



user's manual

- 产品规格
- 产品型号: FD131
- 蓝牙版本: Bluetooth V 5.49+BR +EDR+BLE
- 支持模式: a2dp\avctp\avdtp\avrcp\hfp\sp\smplatt\gap\gattlrfcomm\sdpl2cap profile\
- 灵敏度: -90dBm

- 信号距离: ≥15米
- 电池规格: 耳机3.7V/60mA，充电盒3.7V/500mA
- 播放时间: 约12小时
- 通话时间: 约10小时
- 待机时间: 约700小时
- 充电时间: 给充电盒充电约2小时，给耳机充电约2.5小时
- 充电盒给耳机充电次数: 单耳机4次

次功能操作说明

- 1、开机
将耳机从充电盒拿出会自动开机 耳机关机状态下，长按耳机多功能触摸区2秒开机。
- 2、关机
长按耳机 多功能触摸区3秒左右耳机关机，或放入充电仓内自动关机，耳机红色指示

灯长亮。

- 3、开机回连
耳机从充电仓中拿出后会自动开机回连，并自动回连到上次已连接过且开了蓝牙的手机。
- 4、暂停/播放
在音乐待播放状态下，循环短按耳机多功能触摸区，可播放/暂停音乐。
- 5、切换歌曲/音量加减/启用Sir
在音乐播放状态下，快速双击左右耳机触摸区切换下一曲歌曲
- 双击3下右耳机触摸区-音量加(开机默认最大音量)，双击3下左耳机触摸区-音量减(长按耳机触摸区2秒可启用Sir功能)
- 6、来电接听/拒接电话/挂断电话
手机来电时，短按左/右耳机触摸区接听电话、

- 长按2秒拒接电话; 通话中，短按左/右耳机触摸区可挂断电话。
- 7、低电量提示
当蓝牙耳机电量不足时，语音提示“No battery”，电量过低时耳机关机。

- 配对操作
- 关机状态，同时长按左、右耳机触摸键2秒开机，当发现一边无灯闪，一边红蓝灯交替闪烁即代表耳机配对成功，在手机设置打开蓝牙，查看搜索到对应的耳机蓝牙名称，点击耳机名称即可与手机配对成功。

- 充电
- 1、将耳机放入充电仓内，耳机自动充电且红色提示灯长亮，显示屏两侧的跑马指示灯循环跳动，耳机充满电后红色提示灯和跑马指示灯熄灭。
- 2、将Type-C数据一端接5V电源适配器，另

- 一端Type-C接口接入充电盒，即可给充电盒充电，显示屏中间显示当前充电盒电量状态。
- 注意事项
- 1、请在安全的环境下充电，在给充电盒充电时，当显示屏提示满电后请将充电仓与充电线断开，以免在长时间插着充电对充电仓造成损坏。
 - 2、在音乐播放时，请将音乐调至合适音量大小，以免长期在大音量状态下对听力造成影响。
 - 3、尽量避免在有干扰源的地方使用蓝牙耳机，否则有可能对耳机信号产生影响。
 - 4、尽量避免在有磁场的环境中使用蓝牙耳机，以免对耳机的功能产生影响。

Product model: FD131

- Bluetooth version: Bluetooth V5.49+BR+EDR+BLE
- Support mode:
- a2dp\avctp\avdtp\avrcp\hfp\sp\smplatt\gap\gattlrfcomm\sdpl2cap profile.
- Sensitivity: -90dBm

- FCC ID: 2N24FD131
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is installed and used in accordance with the instructions. may energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. It is the responsibility of the user to ensure that this equipment does not cause harmful interference to radio or television reception. If this equipment does cause such interference, which can be determined by turning the equipment off, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reposition or reorient the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the interfering equipment is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

- The device complies with part 15 of the FCC Rules. Operation is subject to the following conditions:
- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- For more information, please refer to the user manual. The user is responsible for compliance and shall void their authority to operate the equipment.

- Volume up (default maximum volume on startup), press and hold the left ear touch area 3 times - Volume down to enable the Sir Function
- 6.Low power prompt
When the battery of Bluetooth headset is low, "No battery" will be prompted by voice and the headset will be turned off when the battery is too low.
- Pairing operation

- Turn it off and press the left and right earphone touch keys for 3 seconds to turn it on. When it is found that there is no light flashing while the red and blue lights flash alternately, it means that the earphone pairing is successful. Set Bluetooth of the mobile phone, check and search the corresponding earphone Bluetooth name, and click the earphone name to successfully pair with the mobile phone.
- Charging
1. Put the earphone into the charging bin, the earphone is automatically charged and the red earphone light is always on, and the racing indicator lights on both sides of the display run circularly. When the earphone is fully charged, the red prompt light and racing indicator lights go out

2. Connect one end of Type-C data to 5V power adapter. The charging box can be charged by connecting the Type-C port at the other end, and the current charging box power status is displayed in the middle of the display screen
- Matters needing attention
1. Please charge in a safe environment, and then charge the charging bin.
- In case of power-on, please put the charging bin after the display indicates full power
- Disconnect from the charging cable so as not to insert the charging pair for a long time
- Damaged caused by charging compartment
2. When playing music, please adjust the music to the appropriate volume
- Size, so as to avoid long-term listening in the state of high volume
10. Influence
3. Try to avoid using this earphone in places with interference sources.
- Otherwise, it may affect the earphone signal.
4. Try to avoid using this earphone in corrosive environment.
- So as not to affect the function of the earphone.