

User Manual: Lockshark

Introduction

Welcome to the user manual for the Locshark, a protective iPad case equipped with advanced features including GPS/Wifitracking, cellular connectivity, and an integrated battery. This manual provides detailed instructions on setup, usage, and management of the casing's features.

Product Overview

The LocShark enhances your iPad's functionality with:

- **GPS Tracking:** Locate your iPad anywhere with cellular coverage.
- **WiFi Geolocation:** Locate your iPad inside the building where a Wi-Fi router is available.
- **Cellular Connectivity:** Ability to track the position anywhere across the USA.
- **Integrated Battery:** USB-C battery charging port.
- **Secure Locking Mechanism:** Protects your iPad with a lock that can only be managed via a secure website and SMS
- **Remote Features:** Track location, lock/unlock the casing from the iPad, monitor battery level, and activate a beep remotely.

Getting Started

Unpacking and Inspection

1. Unpack the Locshark and verify the contents:
 - LocShark iPad Casing
 - USB-C charging cable
 - Quick Start Guide
2. Inspect the casing for any physical damage before use.

Installing the Casing

1. **Align the iPad:** Place your iPad into the casing, ensuring the camera, ports, and buttons align with the casing's cutouts.
2. **Secure the Lock:** Press firmly on the corners until you hear a click, indicating the locking mechanism is engaged.
3. **Verify Lock:** Tug gently to confirm the iPad is securely fastened.

Note: Once locked, the casing can only be removed via the Lochark website (see Unlocking the Casing).

Charging the Casing

1. Connect the provided USB-C cable to the casing's USB-C port.
2. Plug the other end into a USB-C power adapter (not included).
3. A green LED on the casing will light up to indicate charging. It turns off when fully charged (approximately 2-3 hours).

Using the LocShark Website

The LocShark website (www.locShark.com) allows you to manage the casing's features. You'll need to create an account to access these functions.

Setting Up Your Account

1. Visit <https://portal.locshark.com>
2. Click "Sign up" and follow the instructions on the screen.
3. Verify your email via the confirmation link sent to your inbox.
4. Log in to access the dashboard.

Adding your device

1. From the dashboard, select "Add Device."
2. Enter the ICCID and SIM card number that is provided when you purchase the LocShark device

Tracking the Device

3. From the dashboard, select "Locate Device."
4. A map will display the iPad's current location based on GPS and cellular data.
5. Use the "Refresh" button to update the location in real-time (updates every 30 minutes when active and 3 minutes in tracking mode).

Monitoring Battery Level

1. Navigate to "Battery Status" on the dashboard.
2. The current battery percentage of the casing's integrated battery will be displayed.

Activating the Beep

1. Select "Find My Device" from the dashboard.
2. Click "Activate Beep" to trigger a loud, repeating beep from the casing for 30 seconds.

3. Use this feature to locate your iPad in close proximity (e.g., within your home).

Unlocking the Casing

1. Log in to www.LocShark.com.
2. Navigate to “Device Settings” and select “Unlock Casing.”
3. Click “Unlock” to disengage the locking mechanism. You’ll hear a click, and the casing can then be removed.

Warning: Only the registered owner can unlock the casing. Keep your account credentials secure.

Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the casing. Avoid water or harsh chemicals.
- **Storage:** Store in a cool, dry place when not in use.
- **Battery Care:** Charge the casing every 3 months if unused to maintain battery health.

Troubleshooting

- **Casing Won’t Lock:** Ensure proper alignment and press firmly on all corners.
- **Battery Not Charging:** Check the USB-C cable and port for debris. Try a different cable or adapter.
- **Website Not Responding:** Verify your internet connection and try refreshing the page. Contact support@locShark.com if issues persist.
- **GPS Not Updating:** Ensure the casing has cellular coverage. Leave the device active for 48 hours to drain the battery, then charge again to restart the system.

Safety Information

- Do not attempt to forcibly remove the iPad from the casing, as this may damage the device or casing.
- Keep the casing away from extreme heat or open flames.
- Use only the provided USB-C cable or a certified equivalent for charging.
- Ensure the website is accessed via a secure connection (<https://>).

Technical Specifications

- **Battery Capacity:** 5000mAh
- **Charging Port:** USB-C (5V/2A)
- **Cellular:** LTE-M and NBIoT (requires active SIM plan)
- **GPS Accuracy:** ±5 meters (outside building). ±30 meters inside building

- **Dimensions:** Compatible with iPad models (check compatibility at www.LocShark.com)
- **Weight:** 370g
- **Material:** Polycarbonate with rubberized edges

Support

For further assistance, contact our support team:

- **Email:** locshark@gmail.com
- **Website:** <https://www.locshark.com/#contact-email>

Thank you for choosing LocShark. Enjoy the peace of mind that comes with advanced protection and tracking for your iPad!

Warning statements:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must

accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The SAR limit set by the FCC is 1.6 W/Kg. For body-worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal. RF exposure compliance with any body-worn accessory that contains metal was not tested and certified, and use of such body-worn accessory should be avoided.