

EUT Internal Photos

Figure 32
Internal View (With Keyboard)



Figure 33
Internal View




Figure 34
Battery, Front View



Figure 35
Battery, Back View



Figure 36
SUB Board, Front View




Figure 37
SUB Board, Back View




Figure 38
Main Board, Front View (WLAN Combo Card Location)




Figure 39
Main Board, Back View




Figure 40
WLAN Combo Card View




Figure 41
WLAN Combo Card, Without Shield and Back View




Figure 42
WLAN Combo Antenna Position




Figure 43
WLAN Combo Antenna, Front View




Figure 44
WLAN Combo Antenna, Back View




Figure 45
LP160WQ1, Panel, Front View



Figure 46
LP160WQ1, Panel,, Back View



Figure 47
LP160WQ1, Panel, Label View



Figure 48
ATNA60HR10, Panel, Front View



Figure 49
ATNA60HR10, Panel, Back View



Figure 50
ATNA60HR10, Panel, Label View



Figure 51
CPU View




Figure 52
RAM View




Figure 53
Internal View

