

EUT Internal Photos

Figure 36
Internal View (With Keyboard)



Figure 37
Internal View




Figure 38
Battery, Front View



Figure 39
Battery, Back View



Figure 40
SUB Board, Front View




Figure 41
SUB Board, Back View




Figure 42
Main Board, Front View (WLAN Combo Card Location)




Figure 43
Main Board, Back View




Figure 44
WLAN Combo Card View



Figure 45
WLAN Combo Card, Without Shield and Back View




Figure 46
WLAN Combo Antenna Position




Figure 47
WLAN Combo Antenna, Front View




Figure 48
WLAN Combo Antenna, Back View




Figure 49
CPU View




Figure 50
RAM View




Figure 51
Internal View




Figure 52
LP160WQ2, Panel, Front View



Figure 53
LP160WQ2, Panel, Back View



Figure 54
LP160WQ2, Panel, Label View



Figure 55
ATNA60HR10, Panel, Front View



Figure 56
ATNA60HR10, Panel, Back View



Figure 57
ATNA60HR10, Panel, Label View

