

NR5_15 M_Band Edge_Low_BPSK_FullRB



NR5_15 M_Extended Band Edge_Low_BPSK_FullRB



NR5_15 M_Band Edge_High_BPSK_1RB




NR5_15 M_Band Edge_High_BPSK_FullRB




The screenshot displays a Spectrum Analyzer interface with the following components:

- Top Bar:** Includes a "Spectrum Analyzer 1" title, a "+" button, a gear icon for settings, and a "Frequency" dropdown menu.
- Input/Settings Section:**
 - Input:** RF, Coupling: DC, Align: Auto.
 - Input Z:** 50 Ω , Corrections: Off, Freq Ref: Int (S), NFE: Adaptive.
 - #Atten:** 10 dB, Preamp: Off, μ W Path: Standard.
 - PNO:** Best Wide, Gate: Off, IF Gain: Low, Sig Track: Off.
 - #Avg Type:** Power (RMS), Trig: Free Run.
- Frequency Section:**
 - Center Frequency:** 852.000000 MHz.
 - Span:** 4.00000000 MHz.
 - Start Freq:** 850.000000 MHz.
 - Stop Freq:** 854.000000 MHz.
 - AUTO TUNE** button.
 - CF Step:** 400.000 kHz.
 - Freq Offset:** 0 Hz.
- Display Section:**
 - Scale/Div:** 10 dB, Log.
 - Ref Lvl Offset:** 28.00 dB, Ref Level: 28.00 dBm.
 - Signal Trace:** A yellow line representing the signal spectrum, with a peak labeled "1" at approximately -32.0 dBm.
 - Marker Data:** Mkr1 850.280 MHz, -35.301 dBm.
 - Grid:** A grid with major lines every 20.0 dB and minor lines every 2.0 dB.
- Bottom Section:**
 - Center:** 852.000 MHz, #Res BW 100 kHz.
 - #Video BW:** 300 kHz.
 - Span:** 4.000 MHz, #Sweep ~2.01 s (1001 pts).
- Bottom Bar:** Includes a Windows taskbar with icons for Start, Back, Forward, Home, and Search, along with the date and time: Jun 05, 2025, 5:16:21 PM.

NR5_20 M_Band Edge_Low_BPSK_1RB



NR5_20 M_Band Edge_Low_BPSK_FullIRB



NR5_20 M_Extended Band Edge_Low_BPSK_FullRB



NR5_20 M_Band Edge_High_BPSK_1RB



NR5_20 M_Band Edge_High_BPSK_FullRB



NR5_20 M_Extended Band Edge_High_BPSK_FullRB



11. ANNEX A_ TEST SETUP PHOTO

Please refer to test setup photo file no. as follows;

No.	Description
1	HCT-RF-2506-FC064-P