

White noise speaker mini

KW05




Product Overview




Power button:
Turn left to ON, turn right to OFF.
(automatically turn on the gear I light after ON)



Function key



Timed off prompt light



Charging prompt light
Type-c
USB
TF card slot
Audio input port

Function Key Explanation

Volume adjustment button/switch button:
Long press to adjust the volume and short press to switch the previous song.

Volume adjustment button/switch button:
Long press to turn up the volume with the prompt tone when the volume reaches the highest level. Short press for next song.

Natural white noise:
Under the white noise mode, automatically play the song with five songs in total.

White noise for noise:
Under the white noise mode, automatically play the song with five songs in total.

White noise for sleep:
Under the white noise mode, automatically play the song with five songs in total.

Mode switch button:
When it is powered on, it is white noise mode by default. Short press to switch to the Bluetooth mode. Bluetooth name: White noise speaker mini. Short press again to switch to the FM mode. Under such mode, long press the mode button to automatically scan the existing stations, and switch them with up and down music buttons.

Timed off button:
Short press once to turn off the device 15 minutes later; Short press twice to turn off the device 30 minutes later; Short press for three times to turn off the device 60 minutes later; Short press for four times to automatically turn off the device after 90 minutes; Short press for five times to cancel the automatic shutdown.

Light setting button:

1. After ON, click once to switch lighting modes. Gear I is white constant light mode, gear II is monochromatic gradient mode, gear III is colorful gradient mode, and gear IV is light OFF.
2. Long press the key for 8s to reset and restart the speaker.

Projection Light Function

When the equipment light is ON, put the device in a dark space and project the water ripples on the walls.

Troubleshooting

Fail to connect and pair for multiple times.

Turn off the Bluetooth of the speaker and the mobile phone, then re-start the device and decide the connection name: White noise speaker mini;

Interrupted Music playback

- a. The connection distance is out of range or there is barrier between the speaker and the mobile phone;
- b. Whether the mobile phone network is smooth, the speaker battery is low;

Play without sound

Check if the speaker produces the minimum sound;

Unable to startup

When the device is running out of power for a long time (all functions are automatically turned off), plug in the charging cable, charge for 2 hours and try again.

Charging Instructions

- a. Please charge the device with the standard or equivalent power adapter;
- b. When the power is low or insufficient during running, it should be charged as soon as possible;
- c. Do not use the equipment under high temperature and voltage;
- d. When the device is not used for a long time, it is suggested to charge the device once a month to ensure the sufficient battery power and normal use of device when needed.


Charge indicator:

It is red when charged and the light goes out when it is full.

Parameter Description

Product name: White noise speaker mini	Model : KW05
Product size: 115X113X67mm	Battery capacity: 1200mAh
Packing dimensions: 136X122X74mm	Bluetooth play: 4-6h
Product weight: 382g	White noise play: 6-8h
Loudspeaker: 45mm4Q5W	Charging duration: 2-3h
Input voltage: 5V 1A	Output power: 5W
Frequency response: 80HZ-20KHZ	Receiving distance: Within 10M
Executive standa: GB4943.1-2022	Bluetooth version: 5.4

Packing accessories:



Speaker X1
USB cable X1
Manual x1

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.