

V-C Smart Watch EN

Quick Guide To Use

Downloading the APP

Scan the following QR code, download and install the APP.

Hryfine



Download and install the APP

Operating frequency band: 2402 MHz to 2480 MHz
Maximum RF power: 2.56 dBm (For CE certification)
Security information: Complies with the EU RED 2014/53/EU directive.
1. Only use certified chargers. Keep dry. Do not disassemble or expose the battery to sources of fire or high temperatures.
2. Keep the small parts away from children.

- Warning:**
- No activation required. Install Hryfine app and connect wirelessly. All functions are free.
 - Please keep this product away from children to prevent suffocation. Non toy products. Do not use in a crib, bed, or stroller.

Connecting the watch

Open the APP and set up your profile

Go to the "Device", Click "Add Device"

Click on your device in the scanned devices list

Binding completed


- Make sure the Wireless of your cell Phone is turned on
- Show the "MAC" address of your watch in "Settings" - "About".
- When the watch is linked to the APP for the first time, wait for a pop-up message to allow the watch to use Wireless permission (if you have accidentally restored the factory settings of the watch, please repeat the above operation to connect the watch).
- If the watch is turned on for more than 120 seconds without connecting to the APP, the watch will automatically turn off the Wireless. If you want to connect the APP at this time, you need to turn on the Wireless ON/OFF in the "Settings", "Watch" of the watch, and then do the above operation.

Watch charging and activation

Before first use, the watch needs to be charged and activated; the Wireless charging with the connected wireless charging electro-magnetic suction cup on the back of the watch.

"(Please use 5V 1A and below charger to charge the device)"

Watch operating instructions



Watch Features

- Wireless Call**
Open the APP to link the Wireless of the watch, and after synchronizing the phone, you can make, answer or reject calls on the watch.
- Message Reminder**
To push all messages and social media notifications, you must turn on the notification authorization on your phone.
- Sports Mode**
Enter the exercise mode (running, jumping rope, cycling, climbing) section interface and start data monitoring.
- Exercise Record**
Record all exercise data.
- Pedometer**
Counts your pedometer data of the day, clears the data at 00:00am and can be viewed in the APP.

- Remote Shutter**
After the watch is connected to the phone, open the shutter mode of the APP interface, click or shake the watch to take pictures, and the pictures will be automatically stored in the phone.
- Music Players**
After connecting the device, you can remote control the music player on your phone.
- Find Mobile Phone**
When the watch and mobile phone are connected, tap the watch to find the mobile phone, long press the magnifying glass icon, the mobile phone will ring.
- Weather**
It could show the weather info of current and tomorrow on the weather page. Weather info is synced after connecting with the APP. It will not be updated after a long disconnection.
- Stop Watch**
Tap the start button on stopwatch page to start timing, and tap the stop button to stop timing.
- Alarm**
Alarms can be set in the APP or the watch, up to 8 alarms can be set. The watch will display an alarm icon and vibrate at the set time.
- Sedentary Reminder**
Set the sedentary time, when the time comes, the bracelet will vibrate to remind you, and the inter face has a reminder label display.
- Always on Display**
After setting, the watch screen will display the time after it turns off.
- Watch Face Style**
UI style can be set to change.
- About**
Display the MAC address, Wireless name, and version number of the device.
- Brightness**
You can set the brightness level and backlight off time.
- Settings**
You can set the vibration on or off and adjust the volume.
- Language**
After connecting to the APP, you can set the language on the APP or the watch side, and the language will be synchronized.

Why the watch can't receive push notifications?

Phone settings.

- Make sure the message push on/off is turned on in your mobile Phone.
 - Make sure the message can be displayed in the notification bar of your Phone. The device information depends on whether the information can be read in the notification bar of the Phone. If there are no notifications on the Phone, the device will not be able to receive push messages. (You need to find the notification settings in your Phone to turn on/off the multimedia message alerts)
 - Turn on the accessibility settings of your device. (You will need to find the accessibility settings in your Phone settings and turn on the accessibility settings for your device)
- Phone Settings
- Make sure the message push on/off is turned on for your Phone.
 - Make sure the message can be displayed in the notification bar of your Phone. (You need to find the notification setting in your Phone and turn on/off the multimedia message alert)

Warning:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable-exposure condition without restriction.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.