

Wireless Visible Tonsil Stone Removal Kit

【User Manual】



Please read the user manual carefully before use and keep it for future reference

Using Step

Step 1

Scan QR code to download APP(as show). You can also search for "Aisee plus" APP on APP store.



Select normal download



After installation completed, this icon will appear on your mobile phone.

Step 2

Connecting the device WIFI and start to use it.

Before use, make sure the attachment head is installed in place and the device is fully charged.




1

1. Press the button to switch on, the blue light will start flashing, the camera LED light is always on.
2. Open WIFI settings on your phone, find the name " YJB-XXXXXX".



3. Connect the WIFI "YJB-XXXXXX" with your phone, the blue light is always on, the camera light is still on.



4. Return to open the "Aisee plus" APP, click the button of the camera, start to work.



2

NOTE: The WIFI name is "YJB-XXXXXX", "XXXXXX" is the last six digits of the physical address of the WIFI, so each device is different.

Step 3


Low battery and charging

1. When the battery is low, the green light flashes for 20 seconds and then the device shuts down.
2. The red light is on for a long time when charging and goes out when fully charged.

How to Remove Tonsil Stone




- 1.Begin by using the included syringe to gently flush out and loosen tonsil stones.



- 2.After the phone connects to the device,gently probe the crevices of your tonsils for stones using the visual device.


3



- 3.Flush with the syringe a final time to remove any leftover debris.

Product Overview

- 1.Visual Device
- 2.Tweezers Tip
- 3.Loop Tip
- 4.Spoon Tip
- 5.Round Tip
- 6.Steel Pick
- 7.Oral Irrigator
- 8.Charging Cable
- 9.Type-C Charging Interface
- 10.Power Buttons



4

Product Parameter

Product Name	Wireless Visible Tonsil Stone Removal
Input Current	DC 5V/1A
Working Temperature	-10°C ~ + 70°C
Working Frequency	2.4Ghz
Transmission Speed	150MHZ
Transmit Power	12dBm
Transmission Distance	10 Metres
Battery Capacity	250mAh
Camera Resolution	1920*1080
Recording Format	MP4
Recording Frame	15 Fps
Start-up Time	4S
Phone	Android/IOS

Troubleshooting

Malfunction	Solutions
No response at boot	1. Please try several more times according to the correct using steps. 2. Please charge it for 60 minutes with a matching charging cable.
Camera does not light up	Shut down and restart.
APP can't be connected	Uninstall the existing APP, Scan the QR code to install again.
The red indication light flashes	Low power, please charge it.
Product has connected with the APP, but no image	Disconnect the product and the APP, Shutdown and restart the product, then connect with the APP again.
The APP connection is unstable	Shutdown and restart the device, then connect with the APP again.
The APP connection is unstable	Shutdown and restart the device, then connect with the APP again.

If malfunctions still exist after above operation,please try to contact with our customer service. We will give you a satisfactory solution ASAP.

5

Cautions

1. All attachments must be fitted in place to prevent falling.
2. Do not use in an active environment.
3. Children should not use this product alone to avoid accidental injury.
4. Avoid direct sunlight.
5. The product has a built-in rechargeable lithium battery. If the product is seldom used, please recharge it once a month.
6. The temperature of the product will rise slightly (below 35 °C) during use.
7. To ensure safety and a better user experience, please maintain a horizontal sitting or standing position when operating the product.
8. Do not clean the product with water, please use alcohol cotton ball to clean the lens carefully.
9. Avoid using it in places with excessive magnetic field, it will interfere with WIFI signal seriously.
10. Do not use excessive voltage (working power input: DC 5V ±0.2V).

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

6