



Product Instructions



Thank you for choosing our smart door lock.
Please read the instructions carefully before use, thank you!



5. Product Features

1. Door opening:
Fingerprint, password, IC card, key, combo verification. Actual config varies.
2. Advanced Swedish FPC sensor, 360° recognition, self - learning. More use, more sensitive.
3. Password:
4. Double verification:
Configurable. Combo of fingerprint, password, card. Two users needed post - setup.
5. User management:
Admins have full rights. 10 admins allowed. Total storage for fingerprint/password/-card: 200.
6. Doorbell:
"##" key is normal when screen on, doorbell when off.
7. Alarm:
low - voltage, trial - error alarms.
8. Backup power:
Use 5V power bank when battery dies. Replace battery soon.

6. Menu Structure



```

graph LR
    A[After waking up the keyboard, enter the "H" key to enter the settings menu] --> B[1. Administrator settings]
    B --> B1[1. Add an administrator]
    B --> B2[2. Delete the administrator]
    B --> B3[3. Network Configuration]
    C[The system prompts you to enter administrator information] --> D[2. General user settings]
    D --> D1[1. Add a normal user]
    D --> D2[2. Delete ordinary users]
    D2 --> D2a[1. Delete a single user]
    D2 --> D2b[2. Delete all users]
    E[Enter the management menu] --> F[3. System Settings]
    F --> F1[1. Volume settings]
    F1 --> F1a[1. Low 2. Medium 3. High 4. Silent]
    F --> F2[2. Unlock mode]
    F2 --> F2a[1. Single unlocking 2. Combination unlocking]
    F --> F3[3. Other settings]
    F3 --> F3a[1. Time settings]
    F --> G[4. Restore factory settings]
    G --> G1[Press # to confirm]
    H[If no administrator information has been registered, the lock can be opened using any fingerprint on the initial password 12345678.]
  
```

The menu structure is as follows:

- After waking up the keyboard, enter the "H" key to enter the settings menu
 - 1. Administrator settings
 - 1. Add an administrator
 - 2. Delete the administrator
 - 3. Network Configuration
- The system prompts you to enter administrator information
 - 2. General user settings
 - 1. Add a normal user
 - 2. Delete ordinary users
 - 1. Delete a single user
 - 2. Delete all users
- Enter the management menu
 - 3. System Settings
 - 1. Volume settings
 - 1. Low 2. Medium 3. High 4. Silent
 - 2. Unlock mode
 - 1. Single unlocking 2. Combination unlocking
 - 3. Other settings
 - 1. Time settings
 - 4. Restore factory settings
 - Press # to confirm

If no administrator information has been registered, the lock can be opened using any fingerprint on the initial password 12345678.



CC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, this equipment must be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

8. Video Tutorial

Use the scan feature in Google Chrome to scan the QR code below and watch the product installation video.



Installation Tutorial



Function Explanation

9. Download app

Search for "Smart Life" in App Store and other major app stores, or scan the following QR code to download the Smart Life app.

