


AMPHIBIOUS REMOTE CONTROL CAR INSTRUCTION MANUAL



Please read the manual completely before use and save this manual for future reference

REMOTE CONTROL KEY NAME

BG028 AGES 6 +



REMOTE CONTROL BATTERY INSTALLATION:




2 x 1.5V "AAA" batteries (not included)

Open the battery cover on the back of the remote control, put in 2x1.5V AAA size non-rechargeable batteries in the correct direction according to the electrode instructions in the battery box, and then install the battery cover.


FUNCTIONS OF REMOTE CONTROLLER

Forward / Backward:




1. Press the left button above and the car starts to move forward. Press the left button down and the car starts to move backward.

Rotate left / Rotate right:




2. Press the button right to make the car turn right. Press the button left to make the car turn left.

Automatic demonstration



3. Press the demonstration button, the car starts to demonstrate automatically.

Light



4. Long press the light button to turn off / turn on the light. Short press the light button to switch 7 different modes of the light.

PRECAUTIONS




1. Always remove batteries from the toy when it is not being used for a long period of time.
2. Wipe the toy gently with a clean dry cloth.
3. Keep the toy away from direct sunlight and avoid high temperatures.


1. Users under the age of 6 must operate under the guidance of adults, and adult supervision is required when charging.
2. Please take out the battery of the remote control if it is not used for a long time, so as to avoid damage to the product caused by battery leakage.

GESTURE CONTROLLER


Disassemble




watch + watch strap



Gravity sensor switch




Long press 3'S - On/Off





Use 2X1.5v AAA batteries


OPERATION DIAGRAM OF WATCH REMOTE CONTROL



REMOTE CONTROL CAR BATTERY INSTALLATION



USB charging time: about 3 hours
Please fully charge the rechargeable battery before use. Connect the charging battery to the USB charger, and then connect the charging plug to the power supply after the connection is completed.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

