

Wireless Battery Camera

Quick start guide

Model: CP13WB

FCC ID :2BOUK-CP13WB

Catalog

Packing list: (Depending on the product model.) ······ 02
Appearance Introduction ······ 03
Download and Install the App ······ 05
Register an Account ······ 06
Permission Settings ······ 07
Power On and Network Configuration ······ 09
How to add a camera to the APP: ······ 11
Playback: ······ 15
Camera Installation ······ 17
Solar panel installation ······ 21
Device Sharing ······ 23
Indicator Light Status ······ 24
Camera Charging ······ 24
Firmware Upgrade ······ 25
FCC Warning ······ 25
Common Issues and Solutions ······ 26

Packing list: (Depending on the product model.)

1.Camera*1

2.Bracket*1

3.Camera Accessories Pack*1

4.USB Charging Cable*1

5.User Manual*1

6. Solar Panel *1 (Standard for dome cameras)

7.Solar Accessories Pack *1

Appearance Introduction

- High-Definition WIFI Camera - Diagram



- 360° Panoramic WIFI Dome Camera - Diagram



⚠ Note: Please insert the Micro SD card in the direction shown in the diagram. Inserting the Micro SD card in the wrong direction may cause the card slot to be blocked or damaged.

SD Card Slot: Supports local storage with a micro SD card (supports up to 128 GB).

Download and Install the App

The wireless battery camera series supports three power supply methods: built-in battery, wired power supply, and solar panel power supply.

The wireless battery camera series supports connection with Android and iOS platforms.

For the best experience, you can search for "Amitres " in the Apple App Store or Google Store, or scan the QR code below to download the required app and complete user registration.

Scan the QR Code to Download the App

Google Store Download

App Store Download

Register an Account

1.Enter the "Amitres" app registration.

1) On the app login interface, click "Register" .

2) Enter your email to complete the information verification, check the service agreement and privacy agreement below, and click "Register" .



1-1



1-2

Note:When opening the app for the first time, you need to complete the registration process: obtain location information to connect to network devices.

Permission Settings

Tip:App permission settings

When using the app for the first time, please enable the following two permissions during installation.

(1) Allow "Amitres" to access mobile cellular and wireless local area networks, otherwise, you will not be able to add devices.

(2) Allow " Amitres " to receive messages, otherwise, your phone will not receive alarm push notifications when motion detection or sound alarms are triggered.

Below are the operation screenshots for iOS phones. The method to enable permissions on Android phones is basically the same.



2-1



2-2

(1) Pull down the control center.
(2) Turn on Bluetooth.
(3) Turn on " Amitres "



2-3



2-4



2-5

Power On and Network Configuration

- Long press the power button for 3 seconds to switch the camera between on and off states.
- To reset the network, quickly press the power button three times.
- When connecting the camera for the first time, please use the app and follow the prompts to configure and bind the camera.



- High-Definition WIFI Camera - Interface Diagram



- 360° Panoramic WIFI Dome Camera - Interface Diagram

① Long press the power button until the device indicator light turns on or you hear a prompt sound, indicating that the device has successfully powered on.

② Insert the power cable into the device's power interface until the device indicator light turns on and charging is complete.

Log in to the app and follow the prompts to complete the Wi-Fi connection and add the camera (please keep the camera close to the router during configuration).

Note: The camera is only compatible with 2.4 GHz WiFi signals and does not support 5 GHz signals. You can confirm whether your home WiFi is 2.4 GHz by checking the label on your home router.PS: If your router supports both 2.4 GHz and 5 GHz (dual-band), please contact us.



How to add a camera to the APP:

(1) Click "Add Now" or the "+" button in the upper right corner to add a device.

(2)Long press the power button to turn on the device until you hear a prompt sound. If you do not hear the network configuration prompt sound, press the power button three times to reset, check the box, and click "Next."



3-1



3-2

(3)Enable the "Turn On Device" permission function, search for nearby devices via Bluetooth to bind. If the desired device is not found, you can try adding it manually.

(4) Manually add the device by scanning the QR code on the device body to add the device. (The QR code is located on the bottom, back, or side of the device, subject to the actual product).



3-3



3-4



3-5

(5)Select 2.4 GHz WiFi, enter the password, and then click "Next."

(6)Confirm the WiFi name and password again, and follow the pop-up instructions to proceed with the next steps.



3-6


Next, when a pop-up window appears, please select Add Wi-Fi.
Got it

3-7

Android: You can directly select the desired WiFi name on the current page and enter the password.

iOS: Click "Select Network," return to the system settings - wireless local area network, switch to the WiFi hotspot you need to configure, and then return to the app to continue the configuration.

(7) After the device is successfully added, you can view the camera feed in real time.



3-8



3-9

Reminder:
If the device has not been successfully bound for a long time, you can try binding by scanning the QR code. Please ensure the device is powered on, generate the QR code, and align the device lens with the QR code at a distance of 15-30mm to scan and configure the network, then wait for the connection.

15~30cm

Playback:

1.Local Records:

1) Click the "Playback" button in Figure 4-1.
2) Click "Local Playback" in Figure 4-2, select the date and time using the "Time Selector," and move the timeline left and right to watch the playback records.



4-1



4-2

2.Cloud Playback:

1).Click the "Playback" button in Figure 4-3.

2).Click "Cloud Playback" in Figure 4-4, select the date and time under "Cloud Recording," and click "Play" to view the video playback.



4-3



4-4

Camera Installation

Select Height and Position

Hang the camera at a height of 2-3 meters from the ground. This height maximizes the detection range of the camera sensor.



(1) Screw Installation
1.First, use a pencil to mark the wall according to the fixed base hole spacing, then use a drilling tool to drill holes at the marked positions.
2.Insert plastic expansion screws into the drilled holes.
3.Align the base holes with the wall holes, pass the screws through the base holes, and tighten the screws with a screwdriver.



- High-Definition WIFI Camera - Screw Installation Diagram



- 360° Panoramic WIFI Dome Camera - Screw Installation Diagram

What You Need:

Drill (not provided)



⚠ **Installation Notes:**
The installation wall must be able to withstand at least 3 times the total weight of the camera.
Please strictly follow the instructions to tighten the screws to avoid damaging the device.

⚠ **Warning**
To prevent injury, the device must be securely fixed to the ceiling or wall according to the installation instructions.

(2) Nail Free Adhesive Installation: (Depending on the product model)
1. Use adhesive to directly fix the magnetic fixed base (or bracket fixed base) on a flat and smooth surface (no drilling required).
2. After drying, hang the magnetic bracket on the bracket fixed base or attach it to the magnetic fixed base.



- High-Definition WIFI Camera - Nail Free Adhesive Installation Diagram

Nail Free Adhesive Usage Instructions:
1. Clean the surface to ensure it is free of oil.
2. Open the seal, evenly apply the adhesive to the bonding surface.
3. Press and hold to ensure the adhesive fully bonds with the surface.
4. After drying, it is ready to use.

What You Need:

(Nail Free Adhesive)

⚠ Nail Free Adhesive Installation Notes:
Suitable for smooth surfaces: such as glass, tiles, marble, alloy, wood, white walls, etc.
Not suitable for walls: silicone walls, putty walls, wallpaper, or uneven bonding surfaces.

Solar panel installation

1. Keep the installation angle of the solar panel about 30-45° with the horizontal plane, as shown in the figure below.

2. The installation between the solar panel and the camera is shown in the figure below.



Solar panel installation tips
1.Please keep the angle of the solar panel so that it can be directly exposed to sunlight.
2.Please avoid blocking the solar panels.
3.Check the power indicator to make sure it is red (except when the camera is fully charged).
4.In order to ensure the normal operation of the equipment, please adjust the angle of the solar panel to receive direct sunlight for about 4 hours a day.



Evaluate the WiFi Signal at the Installation Location

Please ensure the WiFi signal strength when installing the camera.

The WiFi signal strength is divided into four states: very weak, weak, medium, and strong.
When the camera's WiFi signal becomes very weak or weak, please adjust the camera's position to avoid affecting the mobile viewing experience. You can check the specific signal strength on the settings page.



Device Sharing

When you need to share the camera with other family members or friends, you can use this function. Only the administrator user who first binds the camera can share the camera. You can follow these steps to share:

1. Ask your family members to download the "Amicre IOT" app, register, and log in.
2. In the device list, select the device you want to share, click the "Share" button, or go to the settings page, select "Share Management," click the "Share" button, enter the recipient's phone number, and click "Confirm" to complete the sharing operation.
3. Control Permissions: The administrator can set "View Only" or "Control" permissions when sharing the device.
View Only: The recipient can only use the camera's live broadcast, pan-tilt, and playback functions.
View and Control: The recipient can use the camera's live broadcast, pan-tilt, playback, and configuration functions.



5-1



5-2



5-3

Tip: When your family registers for an APP account, the country selected for registration must be the same as the country you selected.

Indicator Light Status

Mode	High-Definition WIFI Camera	360° Panoramic WIFI Dome Camera
Power On	Blue light on	Blue light on
Network Configuration Mode	Blue light flashing	Blue light flashing
Working Mode	Blue light on	Blue light on
Sleep Mode	Indicator light off	Indicator light off
Charging Mode	Blue and green lights flashing alternately	Blue and green lights flashing alternately
Charging Completed Mode	Green light on	Green light on

Camera Charging

1.Power Supply
When the battery is low, the app will prompt you to charge. Please use a USB cable to connect to a 5V/1A charging adapter to charge the camera. During charging, the camera's blue and green indicator lights will flash alternately. When fully charged, the green light will stay on. It takes about 10 hours to fully charge the camera.

2.Solar Panel
Install the solar panel in a sunny and unobstructed location, keeping the solar panel at an installation angle of about 30-45° to the horizontal plane. If the camera has been offline for a long time, please check if the solar panel is obstructed to avoid insufficient battery power causing the camera to go offline.

Firmware Upgrade

When you connect your camera through the app, it will automatically detect if there is a new firmware available for your camera. If there is a firmware update, you will be prompted to upgrade. You can also manually check for firmware upgrades in the camera settings in the app.

Before upgrading the firmware, please ensure that your camera has sufficient battery or is connected to a power adapter. Do not turn off the camera during the upgrade process.

FCC Warning

(1) This device must not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device has been tested and complies with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

To comply with FCC RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Common Issues and Solutions

1. Q:Camera permission sharing management: How to invite family and friends to use my camera?
A:Open the app, select your camera from the main menu, click the share button on the main interface, enter the share page, and enter the recipient's phone number to share the device (you need to complete the registration process when opening the app for the first time).

2. Q:iOS device needs to connect to a WiFi network that is not currently displayed (the device only supports 2.4G)?
A:On Apple devices with iOS 13 or above, click "Select Other WiFi," return to the system settings - wireless local area network, switch to the WiFi hotspot you need to configure, and then return to the app to continue the configuration.

3. Q:Will the camera light up during night vision?
A:The camera has built-in white light and infrared LEDs. During night vision, you may see a faint red or white light, ensuring clear black and white (infrared) or full-color (white light) video in no-light or low-light environments.

4. Q: What are the WiFi requirements?
A:The current device only supports 2.4 GHz WiFi connections. The camera does not support WEP encryption for WiFi connections. Please set your WiFi authentication method to WPA-PSK or WPA2-PSK (including WPA/WPA2 mixed mode).

5. Q: How far should the camera be placed from the router?
A:Testing shows that the WiFi connection distance can reach up to 150 meters in open areas. The actual distance depends on the WiFi signal strength and surrounding environment (thick walls, high-power electromagnetic devices, and large metal objects may interfere with the WiFi signal). If the camera's connection is weak or unstable, please place the camera closer to the router.

6. Q:How to quickly categorize and view videos?
A: Click the "Playback" button below the video playback to enter the playback page. Select the date and time point in "Local Records" to play and view the video playback. If you have purchased a cloud storage package, you can find the specified record in the "Cloud Events" on the homepage and click to enter "Cloud Records" for playback.

7. Q:What should I do when the device goes offline abnormally?
A:You can open the rubber plug at the bottom of the camera and quickly press the power button three times to reset (reset network settings). If there is no response after resetting, you can use a needle-like object to press (short press) the reset hole to reconfigure the network.

Tip:The product, accessories, and user interface illustrations in the manual are for reference only. Due to product updates and upgrades, the actual product may differ slightly from the illustrations. Please refer to the actual product.

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

TY-APP-IBG-20250402