





3-4



5-1

Long press: Decrease volume.
Short press: Previous song
Double press: Connect to Bluetooth

Long press: Volume up
Short press: Next song
Double press: Switch lighting modes

Can insert USB Flash Drive or TF card to play songs (only supports MP3 format)

Charging port


Light Speaker Battery

Short press: Pause
Double press: Redirect call

Power On
When the speaker turns on, the blue light flashes, and your smartphone or other Bluetooth device should display "LA16." Connect via Bluetooth and play music.


Charging Instructions
When the battery is low, use the included USB charging cable to connect the speaker to a power adapter for charging.

5-2



STEM WIRELESS SPEAKER KIT

DIFFICULTY: ★★★★★
NO:D1001



Patterned side Angle of connection
No patterned side Special attention

[Precautions Before Assembly]


- Make sure no parts are missing and remove the parts from the board in the order of assembly. (If you take out all the parts before assembly, you don't know the order, and it's hard to assemble.)
- Please be careful not to lose small parts.
- Try to avoid removing parts by hand, It is an auxiliary tool for removing parts, used to push out small parts on the wooden board.

[Safety Precautions]








- Burrs on the edge of the wood, please pay special attention to them.
- Since they are made of wood, too much force may break them.
- Keep away from fire and keep in a dry place to avoid damage.
- This product is not waterproof, please do not place in damp place.
- Never put small parts in your mouth as there is a risk of suffocation.
- Keep out of reach of infants.

[After-Sales Service]

- If you accidentally damage any piece during assembly, please contact us. We will send replacement parts free of charge to ensure your puzzle can be completed. If you need an assembly video, please contact us for access.
- Email: service08261@gmail.com



4-1



FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- _ Reorient or relocate the receiving antenna.
- _ Increase the separation between the equipment and receiver.
- _ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- _ Consult the dealer or an experienced radio/TV technician for help.