

YayaCat Acrylic Writing Board

**with Dreamy Rainbow Effect and
Voice-Controlled Intelligent Color-Changing Lights**

**with Mobile Phone Bluetooth Remote Control and
RF Wireless Remote Control**

Instruction & Safety Operating Manual

Table of Contents

Product Overview.....	1
Product Components.....	2
Safety Warnings and Precautions.....	2
Maintenance and Care.....	2
Operating Instructions.....	3
Remote Control Operating Instructions.....	4-5

Product Overview

Thank you for choosing our Acrylic Writing Board! This product is an innovative product that combines an acrylic dry erase board with dreamy rainbow and voice-controlled intelligent color-changing LED lights.

It typically has the following features:

1.Acrylic Dry Erase Board:

- ☆Made of 4mm high-quality acrylic material, with a smooth surface that is easy to write on and erase.

- ☆Can be used as a message board, planning board, or teaching tool, suitable for various occasions such as homes, offices, or schools .

2.Dreamy Rainbow and Voice-Controlled Intelligent Color-Changing Lights:

- ☆Equipped with a voice-controlled intelligent system that can change light colors based on the rhythm, frequency.

- ☆The light colors are rich and diverse, creating a dreamy rainbow effect that adds dynamism and atmosphere to the environment .

Support user customization of light colors, brightness, and other parameters to meet individualized needs .

3.Mobile Phone Bluetooth Control & RF Wireless Remote Control:

- ☆By applying bluetooth control or RF wireless remote control, remote control and intelligent operation can be achieved, allowing users to control the light switch, color changes, voice synchronization, and music-synchronized lighting effects through a mobile APP or a remote control.

4.Combined Application:

- ☆By combining the acrylic dry erase board with the voice-controlled intelligent color-changing lights, it not only fulfills the functions of writing and display but also enhances the visual experience through changes in lighting .

- ☆This innovative product can be applied to various occasions, such as home decoration, office atmosphere creation, teaching activities, etc., providing users with a more intelligent and personalized usage experience.

Product Components

- ☆Acrylic board main unit
- ☆AA battery energy output shell(without battery)
- ☆Remote control (with a button battery inside it)
- ☆8 colors erasable pens specialized for acrylic board
- ☆1 or 2 coral velvet towels(the quantity depends on the board size)
- ☆Bracket
- ☆Silica gel edge protection strip
- ☆User manual

Safety Warnings and Precautions

1.Electrical Safety:

- ☆The power supply suitable for 5V voltage, such as three AA batteries, power banks, computer USB ports, and mobile phone chargers.Please confirm that the power supply voltage matches the product requirements before use.
- ☆Do not use or store the product in damp environments.
- ☆If you find any damage or exposure to the power cord, immediately stop using the product.

2.Remote Control Usage and Battery Safety:

- ☆The remote control contains a button battery.Measures should be taken to prevent children from disassembling and accidentally ingesting.
- ☆When the remote control is not in use, please remove the battery or turn off the remote control's power switch (if available) to save battery life and extend its usage lifespan.
- ☆Do not expose the remote control to high temperatures, humidity, or direct sunlight, as this may affect its performance.

Maintenance and Care

- ☆Regularly clean the writing board surface and remote control to maintain their cleanliness and optimal performance.
- ☆Regularly clean the wiping cloth to avoid scratches on the acrylic surface caused by sand or other particles hiding inside the cloth.
- ☆When not in use for an extended period, please turn off the writing board's power to save energy.
- ☆Applying silicone edge protector(included in the package) can maximize the protection of the surface from scratches caused by the desktop.

Operating Instructions

1.Power On and Off:

☆Use the power button on the mobile phone app or remote control to turn the writing board on or off.

When not in use for an extended period, please turn off the writing board's power to save energy.

2.Remote Control Operation:

☆Refer to the buttons and their functions on the remote control or in this manual's operating instructions.

3.Writing and Display:

☆Use the remote control to select the desired color, brightness, and other parameters. Write on the writing board with the provided specialized pens, and the content will display on the board brightly.

☆To clear the content, wipe the writing board surface with a soft dry cloth or the provided cleaning cloth.

FCC Statement


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Remote Control Operating Instructions

1.The buttons and their functions



2.Battery Replacement Guide



1st step:
Use your fingernail to press
this button to the right
and hold on

2nd step:
Dig this component out

3rd step:
Replace the battery
and push it back to
the remote control