



DLGR-ANCH WIRELESS ANC HEADPHONES QUICKSTART GUIDE

DLGR-ANCH-QUICKSTART

2-SIDE ACCORDION FOLD QUICK START GUIDE

UNFOLDED SIZE: 24 IN (W) X 5 IN (H)

FOLDED SIZE: 6 IN (W) X5 IN (H)

INKS (PAPER ONLY)



APPROVAL

DESIGNER: Ashley Green

REVISION #:

DATE: 5/29/2025

NOTES: Make sure that the name used when bluetooth pairing shows as “DLGR-ANCH” when connecting in bluetooth settings






DO NOT PRINT

DIE LINE


SPOT UV (HIDDEN)

GLUE

FRONT

MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE	MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE	MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE	MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE
 WIRELESS ANC HEADPHONES 1 Type-C USB Charging Cable	FEATURES 1. PADDED HEADBAND Adjustable Comfort While You Listen 2. PADDED EAR CUPS Soft Padded Comfort for Easy Listening 3. ⏻ BUTTON Power On/Off: Press & Hold >3s Active Noise Cancellation On/Off: Press x1 Switch to BT/TF Mode: Press x2 4. < > BUTTON Play/Pause: Press x1 Answer/Hang Up Call: Press x1 Ignore Call: Press & Hold >2s Redial the Last Number: Press x2 5. >> + BUTTON Volume Up: Press x1 Next Song: Press & Hold >2s 6. - << > BUTTON Volume Down: Press x1 Previous Song: Press & Hold >2s 7. LED INDICATOR Blinks to Indicate Power/Battery Status 8. AUDIO PORT Use with Aux Cable 9. CHARGING PORT Use with Type-C USB Cable 10. TF CARD PORT Use with TF Card 	POWERING ON & CONNECTING  POWER ON THE HEADPHONES Press & hold the power button for 3s and the headphone will automatically enter pairing mode. To manually pair the headphones, press and hold the power button for >3s.  CONNECT THE HEADPHONES In the Bluetooth settings on your phone, choose "DLGR-ANCH" to connect.	LED INDICATOR BEHAVIORS  POWER ON POWER OFF BLUETOOTH CONNECTING BLUETOOTH CONNECTED Flashes once every 5 seconds LOW BATTERY CHARGING FULLY CHARGED ANC ON

BACK

MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE	MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE	MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE	MiSound™ ACTIVE NOISE CANCELING BLUETOOTH HEADPHONES QUICK START GUIDE
SPECIFICATIONS • Model No.: DLGR-ANCH • Speaker Size: 40mm • Bluetooth: V5.4 • Frequency: 20-20KHz • Play Time: Up to 50hrs without ANC • Play Time: Up to 35hrs with ANC • Standby Time: Up to 200hrs • Charging Time: Up to 2hrs • Battery: 400mAh • Noise Insulation: 20dB±2 • Charge Connector: USB Type-C 	CUSTOMER SERVICE Please reach out to customer service should you have any questions or concerns. info@viscointl.com Visco - 11 Vreeland Rd., Florham Park, NJ 07932 MiSound™ COPYRIGHT© ALL RIGHTS RESERVED. MiSound™ is a trademark of Visco LLC. All rights reserved. Other trademarks and trade names are those of their respective owners. WARNING: This product can expose you to chemicals including arsenic, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov.	FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which	FCC STATEMENT can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. Rf Warning Statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.