

Filename:	BeatBox Ball USER MANUAL		
Size:	L297 x W210 mm		
Order No. :	/	Barcode:	/
Designer:	Roy/CPM	Last update:	2025-10-28



BeatBox Ball User Manual

Product Specifications

Please keep this information for future use.

Product Size	3,75 × 3,75 × 3,5 inches
Product Weight	0.42 lbs
Product Material	Polyurethane
Packaging Size	3.85 × 3.85 × 4.25 inches
Battery Type	802025
Power (W)	3Ω, 3W
Voltage (V)	3.7 V
Battery Capacity	350mAh
Playback Time	3-8 hours (varies by volume)
Charging Time	1-3 hours
Bluetooth Version	V5.4

BeatBox Ball *1




USB-A to Type-C
Charging Cable *1



SAFETY & CARE INSTRUCTIONS


- Keep away from water. Do not use in or on water.
- Do not bounce near fragile or easily breakable objects to avoid damage.
- Clean with a damp cloth; avoid abrasive cleaners.
- Keep away from extreme heat, cold, or prolonged exposure to sunlight.
- Unplug the charger once fully charged to protect the battery.
- For ages 6+. Adult supervision required. Keep away from pets.
- Avoid throwing with excessive force to protect the internal components.
- Store in a dry, shaded place when not in use.

HOW TO USE?




1. Power On:

- Press and hold the button on the bottom of your BeatBox Ball for **3 seconds**.
- You will hear an audio cue: “Power on”, and a blinking green light indicates that Bluetooth is ready to pair.




2. Bluetooth Pairing:

- Enable Bluetooth on your device and select “BEATBOX” from the list of available devices.
- Once paired, you will hear: “Bluetooth connected successfully”, and the green light will remain solid (not blinking).
- When music starts playing, the green light will turn off.



3. Music Control:

- Press the button once to pause the music. (After 20 seconds of pausing, the green light will turn on and remain solid.)
- Press the button again to resume music.




4. Power Off:

- Press and hold the button for **3 seconds**. You will hear an audio cue: “Power off.”


Note: If your device's Bluetooth is disconnected and the BeatBox Ball remains powered on, the green light will blink. After 5 minutes without a connection, the ball will automatically power off.

HOW TO CHARGE?




1. Connect the Charger:

- Open the charging seal on the bottom of your BeatBox Ball.
 - Insert the Type-C end of the provided charging cable into the charging port.
- *Use only the supplied cable, as third-party cables may cause malfunctions.



2. Power Source:


- Plug the USB-A end of the cable into a power adapter (DC 5V/1A or 5V/2A).



**Fully charged.
Red to Blue light**

3. Charging Indicators:

- While charging, a red light will appear and remain solid.
 - Once fully charged, the light will turn blue.
- *Charging typically takes 1-3 hours.



4. Disconnect the Charger:


- Remove the charging cable after the ball is fully charged and close the charging seal.

PARTY MODE:

HOW TO CONNECT TWO BEATBOX BALLS?



1. Turn on the first BeatBox Ball and connect it to your device via Bluetooth.



2. Turn on the second BeatBox Ball. It will automatically connect to the first ball and your device.

**Two Balls,
One Amazing Sound
Experience!**

- 1) Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.
- 2) NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Unique Identifier

Trade Name: BeatBox Ball

Model No.: NSBEATBOX

Responsible Party - U.S. Contact Information

Flash Sales, Inc

4401 NW 167th Street

Miami, FL 33055, USA

Attn.: Dennise Heinsen

Tel No.: 305-830-2900

Email address:

d.heinsen@flashsales.com

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 yrs.

Contains small lithium battery.
Keep away from children - Harmful if swallowed.
If swallowed seek medical attention immediately.



Designed & imported by
Flash Sales, Inc.

Patent Pending

ITEM# NSBEATBOX

MADE IN CHINA
CONFORMS TO ASTM F963,
CPSIA, CA PROP 65 & EN71

NOT INTENDED FOR PETS - THIS IS NOT A CHEW TOY