


V29D说明书 80*100mm


V29D Wireless Karaoke Speaker

What's in box

1×Speaker
1×AUX in cable
1×TYPE-C Charging Cable
1×Manual



Button Illustration



- ① On/Off/Light Switch/Force Shutdown
② Mode Switch/ BT Disconnect/Factory Reset
③ EQ Switch
④ TWS
⑤ Play/Pause
⑥ Volume -/Previous Track
⑦ Volume +/Next Track
⑧ AUX in
⑨ TF Card Port
⑩ Type-C Port
⑪ USB Port

Instructions

Button	Operation	Instruction	Prompt & Light Status
	Power On	Press "On/Off" button for 2s to power on the speaker and enter BT mode. If a TF card or Aux-in cable is already plugged in, the speaker will automatically play audio from the connected device.	Prompt can be heard. Blue light flashes for BT pairing mode.
	Power Off	Press "On/Off" button for 2 seconds again to power off the speaker.	Prompt can be heard. Light Off
	Lighting Effect Switching	When the device is powered on, press briefly to switch lighting effects or turn off the lights.	
	Force Shutdown	Long press for 8 seconds to shut down the speaker in case having a malfunction.	
	Mode Switch	After powering on, short press "Mode" button to switch to BT/U Disk/TF Card/AUX mode.	Prompt can be heard.
	BT Disconnect	In BT mode, long press "Mode" button for 3 seconds for BT disconnection.	Prompt can be heard.
	Reset	Long press "Mode" button for 8 seconds to restore factory settings.	Prompt can be heard.

	EQ Switch	Press briefly to switch EQ modes. The default EQ mode upon startup is Full Range. Full Range - 3D - Bass Boost - Loop.	White light indicates 3D mode; green light indicates bass mode.
	TWS	With the speaker powered on, briefly press the "TWS" button to enter/exit TWS mode (the button pressed briefly is on the primary unit).	Prompt can be heard.
	Play/Pause	In BT/U Disk/TF Card/Aux mode, short press to pause, short press again to continue playing.	
	Answer the Phone	In BT mode, when there is an incoming call, short press to answer the call.	Prompt can be heard.
	Reject	Long press for 2 seconds to reject a phone call.	
	Hang Up	During a phone call, short press again to hang up.	
	Redial	In BT mode, double press to redial the last number from the incoming calls.	
	Voice Assistant	In BT mode, long press for 3 seconds to activate voice assistant of the phone.	Prompt can be heard.

Automatic power off:

If there is no BT nor microphone connection, the speaker will power off automatically after 10 minutes without operation.

If there is a BT or microphone connection, the speaker will remain powered on.

Low battery warning function

- Low Battery Alarm:**
When the battery level is lower than 20%, a prompt tone will sound as a low battery alarm, and the red charging indicator will flash.
- Automatic Power Off at Low Battery:**
When the battery level drops below 10%, the speaker will power off automatically.

Charging the speaker

- Red charging indicator is on when charging the speaker.
- Red charging indicator is off when the speaker is fully charged.

	Volume Down	Short press to decrease the volume.	
	Previous Track	Long press for previous track.	
	Volume Up	Short press to increase the volume.	Prompt for max volume.
	Next Track	Long press for next track.	

U Disk / TF card mode


After plugging in an U Disk / TF card, a prompt tone will sound, and the speaker will automatically play audio from the U Disk / TF card.

AUX in mode

When connected via a 3.5mm audio cable to an audio source, the speaker will automatically play audio from the device.

Charge a phone

The speaker can charge your phone for emergency.
The output is 5V/1A.



TWS pairing process


- Initial Setup:**
Ensure both "V29D Pro" speakers are powered on and not paired with any Bluetooth devices.
- Select Master Speaker:**
Designate one speaker as the master speaker.

- Enter TWS Pairing Mode:
Briefly press the "TWS" button on the master speaker to enter TWS pairing mode. The other speaker will automatically become the slave speaker.

- Pairing Confirmation:
If TWS pairing succeeds, both speakers' yellow TWS indicator lights will remain solid.
The master speaker's blue Bluetooth indicator will flash, indicating readiness to connect Bluetooth devices.
Search for Bluetooth devices on your phone and select "V29D Pro" to connect. Once connected, both speakers will synchronously play the same audio source.

- Exiting TWS Mode:
Briefly press the "TWS" button on either speaker to exit TWS mode.

- Automatic TWS Re-pairing:
If both speakers are powered off while in TWS pairing mode, they will automatically re-pair upon restarting.



Friendly reminder

If a charger adapter is used to charge the speaker, please make sure it is CE certificated.

Precautions

- Never use abrasive cleaners to clean this product.
- Never heat this product or place it near open flames, such as stoves.
- Never expose this product to direct sunlight for extended periods.
- Never place this product in fire to prevent explosion.
- Do not attempt to disassemble or modify this product, as it contains no serviceable components.
- Do not submerge this product in water.
- If storing this product for an extended period, keep it in a dry environment away from extreme temperatures, humidity, and dust.
Charge the speaker at least once every month to prolong battery life.

Warning Message

- Do not expose the device to high temperatures, sources of fire, or water to avoid risk of explosion or fire.
- Use only chargers and accessories recommended by the manufacturer to avoid damaging the device or causing danger. If the battery expands, leaks, or is damaged, please stop using it immediately and contact a professional for assistance.
- Child safety warning: "This product contains small components and is not suitable for children under 3 years old." Children aged 12 and below require adult supervision.
- Adapter compatibility requirements: Use an adapter that complies with the IEC62368-1 2023 standard, and use an FCC (Federal Communications Commission) approved charger.



Points de collecte sur www.quefaire-demaisdechets.fr
Privilégiez la réparation ou le don de votre appareil !

FCC STATEMENT :
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
ISED WARNING:
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).
Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
- French:
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
1) L'appareil ne doit pas produire de brouillage;
2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.