




设计版本号	产品名称 Product name		比例 scale	日期 Date	设计师 Designer	审核 Audit	
Rev_V1_EN	DR-HHM016S_美规快速指南		1: 1	20251014	Beryl	Alyssa/Matias	
	材质印刷与 技术要求	材质要求：157g铜版纸 双面覆哑膜 印刷要求：双面彩色印刷 上下风琴折页		字体 Fonts	Manrope	尺寸 Size	单页尺寸：160*130 mm R: 8

图纸设计禁止修改，尺寸刀模图为准



IMPORTANT SAFETY INSTRUCTIONS

DO NOT
Block or cover the nozzle while in operation.

DO NOT
Touch or hold the plug or power cord with wet hands.

DO NOT
Let children or pets play with this appliance.

General Safety

- Children should be supervised to ensure that they do not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
- This is not a toy. This is an electrical appliance and must be operated and maintained by an adult. In addition to the water to be reported, only any additional liquids advised by the manufacturer for cleaning or fragrance shall be used.

Operation Safety

- Always place this appliance on a firm, flat and level surface to avoid dropping or tilting.
- Always place this appliance 12 inches (30 cm) away from the wall or wooden furniture.
- DO NOT move this appliance while it is on.
- DO NOT attempt to repair any part of this appliance. The inside of this appliance contains no user serviceable parts. All servicing should be performed by qualified personnel only.
- DO NOT leave water in the reservoir when the appliance is not in use.
- DO NOT permit the area around the humidifier to become damp or wet. If dampness occurs, turn the output of the humidifier down. If the humidifier output volume cannot be turned down, use the humidifier intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
- DO NOT immerse in water or any other liquids.
- DO NOT use the appliance until the base is installed.
- DO NOT insert your fingers, pencil and any other objects into the grilles or openings while in operation.
- WARNING:** Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 2 days.
- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
- Unplug the appliance during filling and cleaning. Unplug and clean the humidifier before storage. Clean the humidifier before next use.

13. Empty the tank and refill every third day. Before refilling, clean it with fresh tap water or cleaning agents. Remove any scale, deposits, or film that has formed on the sides of the tank or on interior surfaces, and wipe all surfaces dry.

14. The product shall be filled with clean water to prevent the water pump from being blocked.

Electricity Safety

- Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
- Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging/unplugging.
- DO NOT operate the appliance with a damaged cord or plug. Discard the appliance or return to an authorized service facility for repair.
- Do not run cord over furniture. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic areas and where it will not be tripped over.
- WARNING:** To reduce the risk of fire or electric shock, do not use the appliance with any solid-state speed control device.
- If the appliance cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to force the plug into the outlet.

FOR HOUSEHOLD USE ONLY

READ AND SAVE THESE INSTRUCTIONS

⚠ WARNING

- Replace with new batteries of the same type when replacement is required.
- Remove the batteries when the remote control is unused for long period of time.
- Do not attempt to dismantle the batteries.
- Do not dispose the batteries in fire, batteries may explode or leak.
- Chemical burn hazard. Keep batteries away from children.
- Do not mix old and new batteries and do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-cad, Ni-mh, etc.) batteries.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, including interference that may cause undesired operation.

Please note that changes or modifications to this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to residential installations. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the manufacturer can eliminate all interference in a specific installation. If interference is experienced, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the operator's head and the antenna. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

DREO CUSTOMER CARE

12-MONTH LIMITED WARRANTY

What is Covered

DREO warrants to you that your product will be free from original defects in materials and workmanship for a period of twelve (12) months from the date of your purchase, when you use your product for intended purposes in accordance with this User Manual.

Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

What is Not Covered

This limited warranty only applies to the original purchase of your product and is non-transferable. This warranty is only valid if your product is used in the country in which you originally purchased it. In addition, this warranty will not apply, and DREO will not be liable for any costs, damages, or repairs, in connection with any of the following:

- Accidents or use of your product with inappropriate force;
- Damage or destruction caused by wrong voltage or unstable electric current;
- Normal wear and tear;
- Careless operation or handling, misuse, abuse, neglect, and/or failure to maintain or use your product in accordance with this User Manual;
- Any part(s) or component(s) altered, modified and/or damaged products;
- Reduction in battery discharge time due to battery age or use (as applicable);
- Products with altered or removed serial numbers;
- Clearing any obstructions from the product;
- Damages from retailers and distributors not authorized by DREO to sell this product;
- Defects caused by a retailer and/or distributor damages from shipping or handling by any third party not authorized by DREO to ship or handle your product;
- Defects caused by or resulting from repairs, service, transport, maintenance, or alteration to your product or any of its components by anyone other than an authorized authorized DREO;

Any service and customer support that DREO provides to you under this limited warranty will not extend the duration of this limited warranty.

Warranty Limitations and Exclusions

ANY IMPLIED WARRANTIES RELATING TO YOUR PRODUCT, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE AND ARE OTHERWISE DISCLAIMED. THE LIMITED WARRANTY SHALL BE THE SOLE REMEDY OF THE PURCHASER/USER OF THE PRODUCT, AND DREO SHALL NOT BE LIABLE FOR ANY ALLEGEDLY DEFECTIVE OR DAMAGED PRODUCT EXCEPT TO REPAIR OR REPLACE IT IN ACCORDANCE WITH THE LIMITED WARRANTY. DREO WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR COMPENSATORY DAMAGES OR LOSSES OF ANY NATURE THAT YOU MAY INCUR IN CONNECTION WITH YOUR PRODUCT.

Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction.

Limited Remedies


If your product fails because of an original defect in material and/or workmanship during the warranty period, DREO will repair or replace (in DREO's sole discretion) your product.

To obtain warranty service on your product, contact us at support@dreo.com or at (888) 290-1688 (available from Monday-Friday, 9:00 AM-5:00 PM PST/PDT) for further instructions.

IN THE EVENT OF AN ORIGINAL DEFECT IN MATERIAL AND/OR WORKMANSHIP TO THE EXTENT PERMITTED BY LAW, THE REMEDIES SET FORTH IMMEDIATELY ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES.

© DREO PTE. LTD. 112 ROBINSON ROAD, #03-01 ROBINSON 112, SINGAPORE 068902

折页压痕线



图层使用规范：

- 备注信息图层为非印刷区域，展示印刷物料基础信息。
- 刀板线、备注工艺、尺寸层展示印刷工艺部分。
- 画面信息层展示印刷展示图片与文字。

*电子文档为Adobe Illustrator制作

文件格式：model规格类目日期.AI（可为编辑原始文档）

文件格式：model规格类目日期.pdf（为文件转曲不可编辑文档）

审稿
检查事项
会签以“√”形式确认
(负责部门/明确确认)

审稿检查事项

商标规范
字符高度
工艺材质
颜色标识

产品文案
条码检查
厂址
全成分
警告标语
执行标准
产品尺寸

外/内箱尺寸

OEM信息*

产品包装信息

请相关部门确认产
品、包装等信息！

*OEM信息：
委托方及被委托方
信息（名称、地址、
邮编、电话、生产
许可证、卫生许可
证）

设计师	审核	产品负责人	法规	采购	