


设计版本号	产品名称 Product name		比例 scale	日期 Date	设计师 Designer	审核 Audit	
Rev_V0_EN	DR-HPF015S_美规UG		1: 1	20251120	Rachel	Laura	
	材质印刷与 技术要求	铜版纸158G，覆哑膜		字体 Fonts	Manrope	尺寸 Size	160mm x 130mm
Hesung innovation 和生创新							

*此页删除不做印刷

图纸设计禁止修改，尺寸以实际刀模图为准



IMPORTANT SAFETY INSTRUCTIONS

READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.

DO NOT cover the air inlet and outlet while in operation.

DO NOT use the appliance near flammables and combustibles.

General Safety

- Children should be supervised to ensure that they do not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
- Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock or personal injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Operation Safety

- Place the appliance on a flat, dry surface before use.
- Do not immerse in water and any other liquid.
- Do not use the appliance until the noise is installed.
- Do not start your finger, pen etc. or any other objects into the grille while in operation.
- Do not dismantle, repair, or modify. All servicing should be performed by qualified personnel.
- Ensure that the appliance is switched off from the supply mains before removing the guard.

Electricity Safety

- Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
- Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging/unplugging.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run on under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not tuck or conceal turntable or appliances. Arrange cord away from traffic area and where it will not be tripped over.

折痕线，不印刷

When using the appliance for the first time, remove the wraps and attach the parts by following the steps below




Table Fan Assembly (Optional)

1. Do not operate the appliance if the base has not been installed. 2. Please exercise caution and handle the base with care during installation.

1. Do not operate the appliance if the base has not been installed. 2. Please exercise caution and handle the base with care during installation.

LED Display & Control Panel

WiFi Connection

Turbo Mode, Natural Mode, Sleep Mode, Auto Mode

Bluetooth, Vertical Oscillation, Horizontal Oscillation, Timer

Power Button On/Off, Increase Button 1/2 Speed, Decrease Button 1/2 Speed, Working Mode Button, Timer Button, Select to set a timer (0-12h), Horizontal Oscillation Button (on/standby/normal), Long press 5 seconds to start network settings and device pairing, Vertical Oscillation Button (on/standby/normal), Turbo Mode Button On/Off

- WARNING:** To reduce the risk of fire or electric shock, do not use the fan with any solid-state speed control device.
- WARNING:** To reduce the risk of fire, electric shock or injury to persons, do not use replacement parts that have not been recommended by the manufacturer (e.g. parts made at home using a 3D printer).
- WARNING:** If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The appliance shall not be modified by users, such as by adding supplemental filters to the appliance.
- The appliance is only to be used with the power adapter provided with the appliance. Turn off the appliance before plugging.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FOR HOUSEHOLD USE ONLY READ AND SAVE THESE INSTRUCTIONS

Battery Replacement

- Remove the battery cover in the direction indicated by the arrow.
- Replace with two new AAA 1.5V batteries. Make sure that the positive(+) and negative(-) terminals are positioned correctly.
- Push the battery cover back into place.

WARNING

Replace with new batteries of the same type when replacement is required. Remove the batteries when the remote control is unused for long period of time. Do not attempt to dismantle the batteries. Do not dispose the batteries in fire, batteries may explode or leak. Do not mix old and new batteries and do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-cd, Ni-mh, etc.) batteries. Always purchase the correct size and grade of battery most suitable for the intended use. Replace all batteries of a set at the same time. Clean the battery contacts and also those of the device prior to battery installation. Remove used batteries promptly.

This remote has no RF circuit.

DREO CUSTOMER CARE

12-MONTH LIMITED WARRANTY

What is Covered

DREO warrants to you that your product will be free from original defects in materials and workmanship for a period of twelve (12) months from the date of your purchase, when you use your product for intended purposes in accordance with this User Manual. Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

What is Not Covered

This limited warranty only applies to the original purchaser of your product and is non-transferable. This warranty is only valid if your product is used in the country in which you originally purchased it. In addition, this warranty will not apply, and DREO will not be liable for any costs, damages, or repairs, in connection with any of the following:

- Accidents or use of your product with inappropriate force.
- Damage or destruction caused by wrong voltage or unstable electric current.
- Normal wear and tear.
- Careless operation or handling, misuse, abuse, neglect, and/or failure to maintain or use your product in accordance with this User Manual.
- Any partial or complete alteration, modification or dismantled products.
- Reduction in battery discharge time due to battery age or use (if applicable).
- Products with missing or damaged serial numbers.
- Cleaning any damages from the product.
- Purchases from retailers and distributors not authorized by DREO to sell this product.
- Defects caused by or resulting from damages from shipping or handling by any third party not authorized by DREO to ship or handle your product.
- Defects caused by or resulting from repairs, service, improper maintenance, or alteration to your product or any of its components by anyone other than a supplier person authorized by DREO.

- Display will flash 60/1/2/3 indicating the vertical angle 0°/45°/70°/100°.
- Display will flash 60/1/2/3/4/5 indicating the horizontal angle 0°/30°/60°/90°/120°/150°.
- When turned off, display will show while your fan is resetting to its original position.
- Long press the and to turn on/off the Child Lock.

Working Modes	
Normal Mode	Fan runs at the fixed speed.
Auto Mode	Fan automatically increases speed when room temp is higher and decreases speed when temp is lower.
Turbo Mode	Fan runs at the maximum speed.
Natural Mode	Fan speed goes up and down intermittently to replicate the natural breeze.
Sleep Mode	Balance comfort and noise by automatically decreasing fan speed as you fall asleep. Speed decreases once every 20 minutes, two times at most per use.

Connecting to the DREO App

Scan the QR code to download the DREO app.

Search "DREO" on Google Play or the App Store.

This appliance supports WiFi and Bluetooth control. When the appliance disconnects from an active WiFi connection, it will automatically switch to Bluetooth connection.

Launch the DREO app.

To use "Smart WiFi Connection", sign in or create account by following in-app instructions.

1. Hold for 5 seconds to start connection settings. Tip: The WiFi icon will keep flashing when pairing.

2. Tap to add device and select TurboPoly™ Fan 7555. Tip: Enable Bluetooth and plug in the appliance.

3. Now you can control the appliance on your app! Tip: To restart network setup, hold again for 5 seconds.

4. *To learn more, please read the full user manual on www.dreo.com

Any service and customer support that DREO provides to you under this limited warranty will not extend the duration of this limited warranty.

Warranty Limitations and Exclusions

ANY IMPLIED WARRANTIES RELATING TO YOUR PRODUCT, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE AND ARE OTHERWISE DISCLAIMED.

THE LIMITED WARRANTY SHALL BE THE SOLE REMEDY OF THE PURCHASER OR USER OF THE PRODUCT, AND DREO SHALL NOT BE LIABLE FOR AN ALLEGEDLY DEFECTIVE OR DAMAGED PRODUCT EXCEPT TO REPAIR OR REPLACE IT IN ACCORDANCE WITH THIS LIMITED WARRANTY. DREO WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, INDIRECT, CONSEQUENTIAL, OR CONSEQUENTIAL DAMAGES OR LOSSES OF ANY NATURE THAT YOU MAY INCUR IN CONNECTION WITH YOUR PURCHASE OR USE OF YOUR PRODUCT.

Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction.

Limited Remedies

If your product fails because of an original defect in material and/or workmanship during the warranty period, DREO will repair or replace (in DREO's sole discretion) your product.

To obtain warranty service on your product, contact us at support@dreo.com or at (888) 290-1688 (available from Monday - Friday, 9:00 AM - 5:00 PM PST/PDT) for further instructions.

We're Here to Help!

(888) 290-1688 Mon-Fri, 9:00am-5:00pm PST/PDT

support@dreo.com

www.dreo.com

DREO PTE. LTD.

112 ROBINSON ROAD, #03-01 ROBINSON 112, SINGAPORE 068902

正面

背面

	裁切线
	正折线
	反折线
	出血位
	粘胶区域
图层使用规范：	
1、备注信息图层为非印刷区域，展示印刷物料基础信息。 2、刀板线、备注工艺、尺寸层展示印刷工艺部分。 3、画面信息层展示印刷展示图片与文字。	
*电子文档为Adobe Illustrator制作	
文件格式：model规格类目日期.AI（为可编辑原始文档） 文件格式：model规格类目日期.pdf（为文件转曲不可编辑文档）	

审稿 检查事项 会签以“√”形式确认 (负责部门明确确认)				
审稿检查事项				
商标规范				
字符高度				
工艺材质				
颜色标识				
产品文案				
条码检查				
厂址				
全成分				
警告标语				
执行标准				
产品尺寸				
外/内箱尺寸				
OEM信息*				
产品包装信息				
请相关部门确认产品、包装等信息！				
*OEM信息： 委托方及被委托方 信息（名称、地址、 邮编、电话、生产 许可证、卫生许可 证）				
设计师	审核	产品负责人	法规	采购