


正面

V1


Ring Remote for Phone



F3



What can this remote do?

A. Shorts Video Scrolling like TikTok/YouTube etc
B. eBook Turning Pages
C. Phone Camera Remote



Mode selection
O - Power on/off
T - Function A and B
C - Function B and C

How to wear the ring remote




wear on index finger

USB C Port point to outside

wear on middle finger (preferred)

Connect with phone/tablet


1.Power on the remote, led blue flash, ready topair



Power on/off



2.Activate phone wireless

3.Find 'F3' on the list and click to connect, once paired, the led will be off



Settings Needed before use if iPhone or iPad

Need turn on Accessibility: 【Settings -> Accessibility -> Zoom -> On】



step 1

step 2

step 3


Feature A: Shorts Video Scrolling

1. Set remote to T mode



2.Button instruction as below


(1) Video in portrait mode




Single press: previous video
Long press: Volume +
Double click: exit profile, back to video

Double click: Pause/Play
Single press: swipe left to check profile

Single press: next video
Double click: Like the video
Long press: Volume -




(2) Video in Landscape mode



Double click: next video

Single press: previous video




反面

*Record Reels in Shorts APP

1. Access to reels recording via hand

2. Trigger the video via middle button as below details



Tigger button

APP	Tiktok	Youtube	Instagram	Facebook
Video/Photo triggler	Long press	Long press	Long press	Long press
Camera flip	Tripple press	Tripple press	Tripple press	Tripple press


Notice:
1. Some phones/tablets may not supported, for examples Samsung S6 Lite Tablet not support YouTube
2. For camera flip, some App support camera flip during video recording, some NOT
3. If want to use zoom function, need to change mode to C mode, once zoom done, need to change back to T mode

Feature B: eBook Turning Pages

The remote compatible with most ebook app like Amazon kindle app, Libby, Google play books, Wattpad. For some ebook app, please check the turning pages settings, like Wattpad, default is scrolling, need to change it Paging.

1. Use as page turner, you can choose T or C mode


A. Shorts Video Scrolling like TikTok/YouTube etc
B. eBook Turning Pages
C. Phone Camera Remote




Mode selection
O - Power on/off
T - Function A and B
C - Function B and C

2.Below is the button instruction in different mode


in T mode




Double click previous page
Single press next page



in C mode




Single press previous page
Single press next page




Feature C: Phone Camera Remote

1. Set remote to C mode



2.Below is the button instructions



Single press: swipe left
Long press: Zoom in

Single press: photo/video triggler
Double click: camera flip
Tripple click: camera flip (Pixel 6 series)
Long press: camera flip (Pixel 7/8/9 series)

Single press: swipe right
Long press: Zoom out

FCC information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
--Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF exposure:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.



FCC ID: 2BPGR-F3

Specification

Product name: ring remote for phone

Model: F3

Pairing name: F3

Wireless range: 10 meters

Battery capacity: 55mAh

USB charging interface: USB C

Material: Plastic

Product size: 35*30*18mm