

A

Clicker

Power on/off

Click button

LED indicator  
led red flash when charging  
led off when full charged

USB-C charging port

Clip

Turn on/off

LED indicator  
Led red flash when charging  
Led off when full charged

Touch point

USB-C charging port



3

4



Clip on and start reading

Clip touch point on frame      Clip wrongly, NOT WORK



### 1. How to re-pairing?

If clip and clicker not paired, or if you have 2 sets with your family, all they paired wrongly, power on the clicker, and long press the power button of the clip until led twice blink, at this time single press any button of the clicker and you can see led of clip will blink, then they has been paired.

### 2. Page Turner not work?

2.1) Check if the clip and clicker paired, press any button of clicker, the led of clip will blink. If not, then not paired, check above for re-pairing

2.2) Some old kindle 7/8 may not support. If page turner works with your phone, then page turner no issue, it not support your kindle model

2.3) Make sure both clip and clicker in awake status

### 3. Not work with Kindle APP?

please turn off 'Continuous Scrolling' 【Aa - Layout- Continuous scrolling】 If other ebook app, check the app setting, for example Adobe PDF, set view settings to 'Single Page'

### 4. The clip cover the text?

4.1) you can change the margin settings 【Aa - Layout - Margins】

4.2) you can change the clip position as below

Rechargeable Battery capacity (clip): 120mAh  
Rechargeable Battery capacity (clicker): 55mAh  
Charging time: 2 hours  
Battery input rate: 5V2A  
Wireless range: 10 meters  
Material: Plastic

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

**NOTE:** This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

**RF exposure:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

|      |              |      |            |
|------|--------------|------|------------|
| 产品名  | F4翻页遥控器说明书A版 |      |            |
| 制作人  | 黄奕菲          | 制作日期 | 2025/7/28  |
| 版本   | V1           | 尺寸   | 尺寸:7*5.5cm |
| 材质   |              |      |            |
| 版本日志 |              |      |            |
| V2   |              |      |            |
| V3   |              |      |            |