

Apple Find My

1. Open the “Find My” app.
2. Tap the Item tab then tap “Add Item.”
3. Tap “Other Supported Item.”
4. Once the item appears, tap “Connect.”
5. Name the item and select an emoji. Tap “Continue.”
6. Register the item to your Apple ID then tap “Finish.”
7. The charger will now show up in the Find My app.



Android Find Hub

1. Turn on Location Services in the Settings on your device.
2. Open the “Find Hub” app.
3. Tap the Item tab then tap “Connect.”
4. Follow the on-screen instructions.
5. The charger will now show up in the Find Hub app.



FIND HUB DECLARATION

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements.

Google, Android, and Find Hub are trademarks of Google LLC.

Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices [devices or phones] and in certain countries for age-eligible users.

FIND MY DECLARATION

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC WARNING STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

International Support

To download this User’s Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at:
www.iLiveElectronics.com

Para descargar este Manual del Usuario en Inglés, Español y Francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en:
www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en Anglais, Espagnol ou Français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur:
www.iLiveElectronics.com



WARNING: Risk of cancer and reproductive harm from exposure to DEHP.

See www.P65Warnings.ca.gov

Contact Information

Website: www.iLiveElectronics.com

Email Support: proinfo@dpiinc.com

Email Parts: partsinfo@dpiinc.com

Phone Support: 1-888-999-4215

Warranty

For Warranty Information and the most up-to-date version of this User’s Guide, go to:
www.iLiveElectronics.com.



**Protect for Today
Sustain for Tomorrow**

Specifications are subject to change without notice.
Copyright © 2026 Digital Products International (DPI, Inc.)
All other trademarks appearing herein are the property of their respective owners.

ILIVE[™]
ELECTRONICS



**10K Power Bank
with Wireless Charging**
User's Guide for Model IPCQ10006 v3502
SKU IPCQ10006B

Features

- Wireless charging
- USB-C port for charging
- Built-in USB-C cable
- Digital battery display
- Supports Find My and Find Hub


Includes

- USB-C to USB-A charging cable
- User's guide

Specifications

- Type-C Input: 5V/3A 9V/2. 22A 12V/1. 67A (MAX:20W)
- Type-C Output: 5V/3A 9V/3A 12V/2.5A 15V/2.33A 10V/2. 25A (MAX:35W)
- PPS: 3. 3-11V/3. 2A (MAX: 35W)
- Type-C Cable Input: 5V/3A 9V/2. 22A 12V/1. 67A (MAX: 20W)
- Type-C Cable Output: 5V/3A 9V/3A 12V/2.5A 15V/2.33A 10V/2. 25A (MAX:35W)
- PPS:3.3-11V/3.2A (MAX:35W)
- Qi2 25W wireless inductive charging
- The total battery capacity is 10000mAh.

Overview & Controls



1. Wireless Charging Pad

2. Built-in USB-C Cord

3. USB-C Port

4. Power Button
Press and hold for 5 seconds to power on Find My/Find Hub. Press Twice to check current Find My/Find Hub Status

5. Battery LED Indicator

Power On/Off

The power bank will power on automatically when connected to a device. Press the **Power Button** once to display the current battery level.

Battery Status

The number on the **Battery LED indicator** shows the remaining power level of the bank as a percentage out of 100. Please charge the power bank when the battery level drops to 25.

Tips for Use

- Do not leave the power bank in very hot or very cold environments.
- The power bank generates heat while charging. Use only in a dry, well-ventilated area.
- Don't leave the power bank unsued. Use it at least once every 2-3 months to maintain battery health.
- Use a quality charger with the correct output (e.g., 5V/2A) to avoid damaging the internal circuits.
- Charge the power bank to about 50-60% before storing.
- Protect the power bank from exposure to moisture, rain, and liquids.
- Avoid drops, strong impacts, or punctures.


Charging the Power Bank

To charge the power bank, plug the USB-C charging cable (attached or additional included) into the **USB-C Input** on the power bank and a powered-on computer or UL certified USB power adaptor (not included) and standard power outlet.

Charging time is approximately 3–4 hours.


Note: The charging time above is based on using a 5V/2A charging adapter (not included) and the included charging cable. Using a fast charging adapter and/or standard charging cable will result in significantly longer charging times.

To maintain battery health, only charge the powerbank and your devices separately.



Charging your Devices

Connect your device to either the **Wireless Charging Pad, Built-in USB-C Cord, or USB-C port via USB-C to USB-A cable.**



Find My/Find Hub Operation

Power On

Press and hold the **Power Button** for 5 seconds until you hear a chime. Follow your phone's process for Find My/Hub to connect the power bank.

Check Status

Press the **Power Button** 2 times. If the power bank chimes, the power bank's Find My/Hub feature is on. If it does not chime, it is off.

Power Off

Quickly press the **Power Button** 5 times. The power bank will chime and Find My/Hub will turn off.

Note: Wireless charging works while this feature is off.

Factory Reset

Quickly press the **Power Button** 4 times. The power bank will chime. Then, press and hold the **Power Button** for 8 seconds, until you hear another chime.

Note: After removing from Find My/Hub perform a factory reset before pairing it with a new phone.

Important: Once paired/linked to a user's account, the Find My/Hub device cannot be set up by another user until the owner removes it from their account.