

Light-up costumes

INSTRUCTIONS

Please read this instruction manual carefully before use.

06HC04

Other Considerations:

1. a) Ensure the batteries are installed correctly according to polarity (+ and -).
2. b) "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
3. c) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

WARNING: Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body seek immediate medical attention.

The packaging and instruction manual must be retained since it contains important information.

This toy is only to be connected to equipment bearing either of the following symbols:




Instructions

Battery box:

1. Buy 3 pack of 1.5V AA batteries by yourself
2. Find the battery box at the WAIST OF THE SKIRT
3. Use screwdriver to loosen the screws on the battery box, then slide the battery cover in the indicated direction
4. Open the battery box and install the battery, pay attention to the positive and negative poles, the wrong side battery installation will cause no light to work
5. Close the battery box and tighten the screws
6. Plug in the USB and turn on the switch to use it




Slide in the direction of the arrow Open battery box



Schematic diagram of the direction of the positive and negative poles of the battery.

Remote control:

1. Buy 2 Pack batteries by yourself, battery type is 1.5V AAA
2. Use screwdriver to loosen the screws on the remote, then open the battery cover
3. Install the battery, pay attention to the positive and negative poles, the wrong side battery installation will cause it cannot work
4. Close the battery box and tighten the screws
5. Turn on the switch (The best use distance is no more than 5 meters)
6. The remote control buttons are as shown in the figure:



Warning:

1. If you find that the remote control is not sensitive, please replace the battery in time
2. When using the remote control, you need to aim at the USB port of the light string on the skirt. The space between the remote control and the USB port cannot be blocked, otherwise the remote control may not be able to control the light string
3. If you don't understand how to operate the remote control, please refer to the video in the purchase link.

Mobile APP:

1. Scan the QR code on the USB with your mobile phone to download the APP
2. Open the APP, turn on the Bluetooth of your mobile phone, and a light strip will be displayed.
3. Click it to control the light

Other consideration :

When the light color is not correct ,switch the RGB sequence until the red, green and blue colors match the current device display

Care instructions:

- After use, unplug the USB socket and remove the battery from the battery box

- USB not touch the water
- Hand wash only, but the USB needs to be protected from the water
- DO NOT BLEACH
- DO NOT DRY CLEAN



Safety precautions:

1. "Warning! Keep away from fire."
2. Avoid exposing the clothing to
3. high temperatures, high pressure,
4. or extreme cold to prevent damage
5. to the battery or circuitry.



BATTERY SAFETY INFORMATION

In exceptional circumstances batteries may leak fluids that can cause a chemical burn injury or ruin your product.

To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.

- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak

Protect the environment by not disposing of this product with household waste(2002/96/EC). Check your local authority for recycling advice and facilities.

Caution: "Warning! Not suitable for children under 36 months. Choking and Suffocation hazard" Long cord. Strangulation hazard.



Screwdriver Use Only For Installation:

WARNING: The screwdriver is not a toy. Adult use only. Take away the screwdriver from children.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.