

G90说明书

尺寸：110mm x 160mm


80g书写纸，黑白印刷，折页，双面印

料号：416-00G90091-W0R



USER MANUAL

2.1 Channel PC Soundbar Speaker



Model: G90

IMPORTANT

Please read this manual carefully before operating the soundbar, keep this user manual for further reference.

Important Safety Instructions



1. Read these Instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Special note: When placing your unit on a lacquered or natural finish, protect your furniture with a cloth or other protective material.

Additional Warnings:

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.
L'appareil ne doit pas être exposé aux écoulements ou aux éclaboussures et aucun objet ne contenant de liquide, tel qu'un vase, ne doit être placé sur l'objet.

Caution marking is located at the rear or bottom of the apparatus.
Attention marquage est situé sur le panneau arrière ou inférieur de l'unité.
The marking information is located at the rear or bottom of apparatus. Le marquage est situé sur le panneau arrière ou inférieur de l'unité.

FCC Warnings

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.




This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts.

1

What's in the box

Make sure you read all the safety information before you use this product.




PC Soundbar Speaker



AUX Audio Cable



Power Adapter



USB Cable




User Manual


2

Overview

PC Soundbar Speaker




RGB Indicator



Short press volume- (The status light flashes when the volume is reduced and remains on at the minimum)
Long press: Play the previous song on the USB drive.

Short press to switch Input (BT, AUX, USB).
Long press in Bluetooth mode to disconnect the Bluetooth connection



DC in

USB in (Supports audio transmission, use the included USB cable to connect to devices with USB audio transmission ports; support USB flash drive play)

AUX in


* Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

3

Sound Bar LED Indicator

The LED indicator on the sound bar gives you information about the status of the sound bar.

AUX	Green light	BT	Blue light
USB	Yellow light	EQ1	Red light
EQ2	Blue light	EQ3	Green light



AUX: Green light

PC/USB: Yellow light

BT: Blue light

EQ1 red light(MUSIC)
EQ2 blue light(MOVIE)
EQ3 green light(GAME)


4

Connect to a PC

4a

USB Cable Connection

1. Connect your speaker to the USB port of your PC or console via USB cable included.
2. Press the "USB" button on the side to switch to USB input.




Tips: Connecting your speaker's USB port to a PC or laptop via a Type-C port for sound output is not supported.

4b

USB Flash Driver Connection

1. Connect your USB drive to the USB jack on the sound bar. (Without any operation, the light will go out after 15 seconds, and any key can wake up.)
2. Press the "USB" button on the sound bar and switch to the yellow light USB state.
3. Play music to test.




Kindly Note: only for USB flash drive to play MP3 music and update firmware.

4c

AUX

1. Choose line in cable (3.5mm to 3.5mm) connect the sound bar to your PC. (Without any operation, the light will go out after 15 seconds, and any key can wake up.)
2. Turn on the sound bar and press the "AUX" button to switch to the LED state, and the indicator is green.




3.5mm to 3.5mm cable (supplied)

4d

BT

The BT connection

1. Press the "BT" button on the sound bar to switch to the BT state, then the "blue light" flashes. (Without any operation, the light will go out after 15 seconds, and any key can wake up.)
2. Turn on BT on the BT device. (see the device's manual for more information)
3. Select "G90" from the device BT list, connect it. When your BT device is connected, The LED light will stop blinking.
4. Play music from the BT device to test the sound bar.



* You cannot connect more than one BT device at a time.

* If your device requests a password, enters the default "0000".

* Only work with the device which can output BT signal, it can not work with some devices can not output BT signal such as headphones.

* Press the "BT" button on the sound bar for 3 seconds to reset the BT.

when the connection fails or "G90" cannot be found in the device list.

5

Specifications

Model	G90
Power Supply	DC15V
Speaker	2.25" x3
Volume Level	0~50
BT Version	5.3
Distortion	<1%
Product Weight	1.4 kg
Product Dimension	405(L)x 90(D)x 75(H) mm

6

RGB Lights

Color Change Button:
Click: White light -> Purple light -> Blue light -> Orange light -> Pink light -> colorful breathing light -> colorful flow light
(The lighting effects in this flowing light mode gradually change from the middle to both sides) and switch in a loop successively.
Double-click: Rhythm 1 (run from both ends to the middle)
> Rhythm 2 (run from the middle to both ends)
> Turn off Rhythm in a loop

For more information, please follow us:

Web: www.wohomeshop.com
Email: support@wohomeshop.com

NOTE: One year warranty, 45 days money back guarantee, lifetime technical support, 100% satisfaction service, please feel free to contact us for any questions.