

User Manual

Voter Registration and Authentication Device

Model: VIU Tablet 100 R2

Smartmatic International Corp.

Table of Contents

Table of Contents	1
Read me first	2
Getting started	3
Device layout	3
Buttons	3
Package contents	4
Power on your device	4
Power off your device	4
SIM Card & TF Card Installation	5
NFC Card Reading	6
Fingerprint Capturing	6
Copyright Information	

Read me first


This device provides mobile communication and media services using **SMARTMATIC**'s latest standards and technological expertise. This user manual and the information available contain details about the device's functions and features.

- Please read this manual before using the device to ensure safe and proper use.
- Descriptions are based on the device's default settings.
- Some content may differ from your device depending on the region, service provider, or device's software.
- **SMARTMATIC** is not liable for performance issues caused by apps supplied by providers other than **SMARTMATIC**.
- **SMARTMATIC** is not liable for performance issues or incompatibilities caused by edited registry settings or modified operating system software. Attempting to customize the operating system may cause the device or apps to work improperly.
- Software, sound sources, wallpapers, images, and other media provided with this device are licensed for limited use. Extracting and using these materials for commercial or other purposes is an infringement of copyright laws. Users are entirely responsible for illegal use of media.
- You may incur additional charges for data services, such as messaging, uploading and downloading, auto-syncing, or using location services. To avoid additional charges, select an appropriate data tariff plan. For details, contact your service provider.
- Modifying the device's operating system or installing software from unofficial sources may result in device malfunctions and data corruption or loss. These actions are violations of your **SMARTMATIC** licence agreement and will void your warranty.

Getting started

Device layout

The following illustration outlines your device's primary external features.



Buttons

Button	Function
Power Key	• Press and hold to turn the device on or off. • Press to lock or unlock the device. The device goes into lock mode when the touch screen turns off.
Overview	• Tap Overview to see your recent apps, and tap an app to reopen it. • To remove an app from the list, swipe it left, right. • To scroll the list, swipe up or down.
Home	• Tap to return to the Home screen.
Back	• Tap to return to the previous screen.

Package contents

Check the product box for the following items:

- Main Device
- Power Adapter
- USB Cable
- User Manual



- The items supplied with the device and any available accessories may vary depending on the region or service provider.
- The supplied items are designed only for this device and may not be compatible with other devices.
- Appearances and specifications are subject to change without prior notice.
- You can purchase additional accessories from your local retailer. Make sure they are compatible with the device before purchase.
- Availability of all accessories is subject to change depending entirely on manufacturing companies. For more information about available accessories, please contact us.

Power on your device


- To turn your device on, hold down the Power key until the device powers on. It will take a few seconds before the screen lights up.
- Unlock your device with a swipe, PIN, password or pattern before the Home screen can display if you've set a screen lock in Settings.

Power off your device

To turn your device off, hold down the Power key until the Device options appear, then select Power off.


SIM Card & TF Card Installation

1. Remove the screw and take out the cover, the card sockets will be shown.



- Be careful not to damage your fingernails when you take out the cover.
- Do not bend or twist the plastic cover excessively. Doing so may damage the cover.


2. Put the SIM card into the socket correctly. Be sure the SIM card is in right position.



Note: On dual SIM capable devices, both SIM1 and SIM2 slots support 4G networks. However, if your SIM1 and SIM2 are both LTE SIM cards, the primary SIM supports 4G/3G/2G networks, while the secondary SIM can only support 3G/2G. For more information on your SIM cards, contact your service provider.


NFC Card Reading

1. Put the NFC card over the designated area and hold.



Fingerprint Capturing

1. Place your finger on the fingerprint area of the device and hold. Be sure that your finger is in right direction.



Copyright Information

Copyright © 2026 **Smartmatic International Corp.**

This manual is protected under international copyright laws.

No part of this guide may be reproduced, distributed, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or storing in any information storage and retrieval system, without the prior written permission of **Smartmatic International Corp**

Manufacturer: **Smartmatic International Corp.**

Address: Whitepark House, White Park Road, Bridgetown, Barbados BB11135

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information:

This Tablet meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Tablet has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the Tablet kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the Tablet. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.