




Installation
Video

USER MANUAL



Model: ZWJ-H-4

Floor Lamp With Shelves

After-sales Email: service@aidierlight.com

Manufacturer: Zhongshan Aidier Intelligent Technology Co., Ltd.

Address: 2-901, No. 32, Jianye Road, Torch Development Zone,
Zhongshan, China




RoHS




I. Package List


What's inside the package?




Shelf with light
***3pcs**




Shelf without light
***1pcs**




Anti-tip-kit
***1pcs**




Power*1pcs




User manual
***1pcs**



Tube A*3pcs



Tube B*6pcs



Tube C*3pcs

Each model of tubes is individually packaged. When unpacking, please sort and place the pipes by their model to **avoid mixing them up**.

II. Assembling the floor lamp with shelves

Please scan the QR code to watch the installation video tutorial on **YouTube**.





Installation Video


Attention: Begin assembling the shelves by following sequence:
shelf 3→shelf 2→shelf 1→shelf 0.

This sequence is crucial for the proper functioning of the floor lamp.


Preparation before installation



Loosen the nuts on the shelves and remove all the nuts from all the shelves.




Remove the black protective foams from **Shelf 0** and **Shelf 3**.




Remove the yellow parts form **Shelf 1** and **Shelf 2**.

INSTALLATION STEPS

01



Step1: Locate **shelf 3** and place it with the side marked with number facing upwards. Locate **Tube C**, fully insert the **unthreaded end** of the Tube C into the shelf.



02



Step2: Locate **3 nuts** and pass the nuts through Tube C, then tighten the nuts to secure it to the shelf, **making sure the nuts are fully tightened**.

03




Step3: Locate **Shelf 2** and thread it through Tube C (With the side marked with number facing upwards).

04




Step4: Locate **3 nuts** and pass the nuts through tubes to secure to the shelf 2. Making sure shelf 2 remains level before tightening the nuts.

05



Step5: Locate Tube B and connect the **Internal threaded end** of Tube B to Tube C.

06



Step6: Locate Tube B and connect the **Internal threaded end** of Tube B to Tube B.

07




Step7: Locate **Shelf 1** and thread it through Tube B (With the side marked with number facing upwards).

08




Step8: Locate **3 nuts** and pass the nuts through tubes to secure to the shelf 1. Making sure shelf 1 remains level before tightening the nuts.

09




Step9: Locate Tube A and connect the **Internal threaded end** of Tube A to Tube B.

10




Step10: Locate **3 nuts** and pass the nuts through tubes (the smooth narrow ring face upward).

11




Step11: Locate **Shelf 0** (With the side marked with number facing upwards) and fully inserted the tubes into the **Shelf 0**. Then tighten the nuts to secure them to the **Shelf 0**.

12



Step12: Flip the floor lamp 180 degrees.


13





Step13: Secure the anti-tip bracket to Shelf 3 and place the floor lamp in the desired location. Drive screws through the bracket and into the wall to secure the floor lamp to the wall.

14 Important Installation Details to Check Before Powering On!!!

- (1) Make sure all stainless tubes are fully connected and tightened;
- (2) Make sure the stainless steel tubes are fully inserted into the nuts of shelf 3 (Please unscrew the nuts to check);



- (3) Make sure all the nuts under all shelves are fully tightened;
- (4) Make sure the shelves are in the order of **0-1-2-3** from bottom to top.
- (5) Plug the power into the power socket on Shelf 1;




After plugging in the power, all lights of the floor lamp will **light up in white together**, which means the floor lamp work normally

If the lights of floor lamp are malfunctioning or some are not lighting up, please try **disassembling and reinstalling step by step**, ensuring that each step is properly completed. If you need help, please contact service@aidierlight.com to get after-sales support.

Adjusting Shelf Heights

Attention: Please make adjustments with the **power unplugging**, otherwise it may affect the normal functioning of floor lamp.



Our floor lamp with shelves is adjustable, and the height of each shelf can be customized to your needs.

1. Unplug the power supply;
2. Loosen the shelf's nuts;
3. Then move the shelf up or down to the desired position;
4. Make sure the shelf is level;
5. Tighten the nuts to secure the shelf at the adjusted height;
6. Plug the power back in, the floor lamp will function normally.

III.Touch Button Control

Warm and White Lights Mode

1. **Long press** the button  for 3 seconds to turn on the light.
2. **Quickly double tap** the button  to change the color temperature (switch between white, neutral and warm light)
3. **Long press** the button  again for 3 seconds to turn off the light.

RGB Lights Mode

1. **Long press** the button  for 3 seconds to open the RGB light.
2. **Quickly double tap** the button  to switch to different dazzling color effects.
3. **Long press** the button  for 3 seconds to close the RGB light.

Music Sync Mode

1. When the lights are on, **press and hold** the   two buttons simultaneously to activate the music sync mode.
2. **Long press** the button  switch to white lights, then long press the button  again to turn off all the lights.

How to solve the Touch buttons malfunction:

Step1-Unplug the floor lamp's power adapter, leave the floor lamp idle for 10 minutes;

Step2-Plug the power back. Long press the lighting button  for 3 seconds.

If warm white lights turn on, the buttons are functioning properly.

If the buttons still don't respond, please repeat the two steps again.

IV. Tuya Smart APP Control

1. Download Tuya Smart APP on your phone and register to log in.



Tuya Smart App



Smart life App

2. Connect Floor Lamp with shelves to Tuya Smart App.





2.1 Activate floor lamp with shelves

Please activate the device before connecting to the app. After powering on, with the lights off, simultaneously **long press** the buttons   until the lights start flashing.

2.2 Add Device

(1) Tuya Smart App and the device are connected through WI-FI. When adding a device, please connect your phone to **2.4GHz Wi-Fi**. (5GHz Wi-Fi is not supported.)

(2) Click “+” in the upper right corner of the homepage, “Add Device”, click "ATOM-Z1" to connect the device, you can successfully add.



V.Troubleshooting

We have summarized some common issues for your reference. Please follow the guidelines below for troubleshooting. Scan the QR code to watch troubleshooting videos.



Troubleshooting
Videos

If you encounter a problem that cannot be resolved, please reach out directly to us via **service@aidierlight.com** for after-sales support and assistance.

For any issues with the lighting of the floor lamp, please **first check the installation** to ensure it is properly assembled. Then proceed with troubleshooting to the corresponding issue below.



Installation check:

(For detailed diagrams, please refer to page 7)

- (1)Unplug the power;
- (2)Make sure all stainless tubes are fully connected and tightened;
- (3)Make sure the stainless steel tubes are fully inserted into the nuts of shelf 3 (Please unscrew the nuts to check);
- (4)Make sure the shelves are in the order of **0-1-2-3** from bottom to top.
- (5)Make sure all the nuts under all shelves are fully tightened;
- (6)Plug the power back into the power socket on Shelf 1;

If the issue is still not resolved, please refer to the following troubleshooting steps.

Trouble1: Touch buttons malfunction

Solution: **Step1**-Unplug the floor lamp's power adapter, leave the floor lamp idle for 10 minutes;

Step2-Plug the power back. Long press the lighting button for 3 seconds. If warm white lights turn on, the buttons are functioning properly. If the buttons still don't respond, please repeat the two steps again.

Trouble2: Lights flickering or not lighting up

Solution: **Step1**-Unplug the floor lamp's power, and check the installation;
Step2-Plug the power back. Turn on the lighting of floor lamp, then turn off the lighting by long press the lighting button .
Step3-Press and hold   two buttons simultaneously until the lights flashes white 3 times. At this point, the floor lamp is reset to factory settings.,

Trouble3: The floor lamp cannot connect to the Tuya app

Solution: **Step1**-Check if your phone is connected to the **2.4GHz Wi-Fi**,
5GHz Wi-Fi is not supported;
Step2-Make sure to put the floor lamp into pairing mode: press and hold   two buttons simultaneously until the light starts flashing.

Percautions for Using the Floor Lamp:

1. Do not shake the floor lamp.
2. Unplug the power and disconnect the electricity before adjusting the shelves and stainless steel tubes.
3. Make sure each shelf remains level, and avoid placing too many or overly heavy items on the shelves.

The incorrect operations above may cause **poor contact** in the floor lamp, which could affect the normal functioning of the lights.

If you encounter any issues, please feel free to contact us via **service@aidierlight.com**. We will do our best to assist you and provide a satisfactory solution.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.