



User Manual

FONVOI Luggage Locator

Model: F001SBAGBK





Please refer to this manual
before using the product

FONVOI Luggage Locator supports Apple Find My and Google's Find Hub, allowing you to track your luggage and check its status during travel. It securely attaches to suitcases and helps you quickly locate your bag at airport baggage claim. The tag also includes a slot for a name and contact card, making identification and recovery easier if your luggage is misplaced. During initial setup, you can select your preferred network. However, the finder cannot operate on both networks simultaneously. Once a network is selected, the other is automatically disabled. To switch networks, you must perform a factory reset on the finder.

Before you start

- Before you begin, ensure Bluetooth is enabled on your Android™ or iOS device, and that the device has internet access via Wi-Fi or cellular service.
- Locate the button on the front side of the Luggage Locator as shown below.



Caution

The button on the Luggage Locator is a physical mechanical button, not touch-sensitive. A light tap will not trigger any action, please press it firmly with your fingertip.

When pressed correctly, the finder will emit confirmation sounds (as described in the subsequent sections) and you will see the LED flash. If you don't hear the sound or see the LED flash, the button may not have been pressed properly. It is intentionally designed to prevent accidental activation or unintended operation, so it may feel unfamiliar at first. Don't hesitate to apply a bit of force when pressing it.


Charging Instructions

Luggage Locator supports wireless charging. To charge the device, simply place it on a compatible wireless charger. A small circular indicator light on the device will show the charging status:

- Red light — Charging in progress
- Green light — Fully charged

The charging area is located on the back of the device, as indicated in the image below. Please ensure the charging surface is clean and properly aligned for optimal charging performance.

Note: Wireless charging pad is not included in the package.



Get started with an iOS device

- Place your finder next to your iOS device and press the button once to activate it. If activation is successful, you will hear a beep.
- On your iOS device, open the Find My app. Tap the **Items** tab, then tap **Add Item**. Select **Other Supported Item**. (If you've previously added items, tap the "+" button first, then choose **Add Other Item**.)
- Once the Find My app detects your finder, follow the on-screen instructions to add it to the Find My app.

Get started with an Android device

- Place your finder near your Android device (Make sure your Android device is awake and unlocked) and press the button once to activate it. If activation is successful, you will hear a beep.
- Wait for a half-screen notification to appear, then follow the on-screen instructions on your Android device to add the finder to Find Hub app.

Locate your finder and valuables

- After adding the finder to Apple's Find My or Find Hub app, attach it to your valuables. You can then use the corresponding app to locate both the finder and the item it's attached to.

Instructions

1.Enable the finder: Press the button once. A confirmation beep will sound.

2.Disable the finder

- 1) Quickly press the button twice. A confirmation beep will sound.
- 2) Press and hold the button for five seconds. A beep will sound.
- 3) Release the button. Two confirmation beeps will sound.

3.Factory reset

- 1) Quickly press the button twice. A confirmation beep will sound.
- 2) Immediately after you hear the confirmation sound, press and hold the button. After holding it for 5 seconds, the device will begin emitting a single beep sound once per second, for a total of five beep sounds.
- 3) Continue holding the button, and release it immediately after you hear a double beep sound. If the operation is successful, the device will beep four times.

After resetting, you can link the Carbon Finder to a different Google or Apple account. However, if you want to link it to a new Apple account, you must also remove it from its previous Apple account on your iOS device.

Locate your finder when it's nearby

- 1) Open the Apple Find My app or Find Hub app, then tap your Luggage Locator from the item/device list.
- 2) Tap "Play Sound" to make your finder beep.
- 3) Once you've located it, stop the beeping by either using the app or pressing the button once on the finder.

Locate your finder when it's faraway

- 1) Open the Apple Find My app or Find Hub app, then tap your Luggage Locator from the item/device list.
- 2) The current location of your finder will appear on the map, along with a timestamp showing when it was last located.

Enabling "Notify when left Behind"(only available on Apple Find My)

- 1) Open the Apple Find My app and select your Luggage Locator from the list.
- 2) Under Notifications, enable the **Notify When Left Behind** option.
- 3) You'll receive a notification if you leave your finder behind and it goes out of the Bluetooth range of your iOS device.

Enabling "Notify when Found"(only available on Apple Find My)

- 1) Open the Apple Find My app and select your Luggage Locator from the list.
- 2) Under Notifications, turn on the **Notify When Found** toggle.
- 3) You'll receive a notification with the location when your Luggage Locator is detected by another device on the Apple Find My network.

Note: "Notify When Found" can only be activated when your finder is out of the Bluetooth range of your iOS device.

Enabling "Mark as lost"if your Luggage Locator is lost(only available on Find Hub)

- 1) Open the Find Hub app and select your Luggage Locator from the list.
- 2) Tap **Mark as lost** and follow the on-screen instructions to fill the contact information.
- 3) You will be notified if the Find Hub network locates your lost Luggage Locator.

Specification

Model	F001SBAGBK
Bluetooth version	5.4
Dimensions	102*68*5.2mm (4.02*2.68*0.21inches)
Weight	48g (1.69oz)
Battery Type	Lithium-ion battery, Rechargeable, 3.7V 155mAh
Charging type	Wireless charging
Compatible system	iOS 14.5, macOS 10.15 or above Android 9 or above

Compatibility, Legal and Credit Line

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch. To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS. Apple, Apple Watch, Find My, iPhone, iPad, iPod touch, iPadOS, Mac, macOS, watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Find Hub helps you find and connect to what matters in a single, secure place. Find your lost phone or other important belongings quickly. You can also use Find Hub for seamless location sharing with friends & family for peace of mind.

This product has been certified by Google to meet Find Hub network accessory specification. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements.

Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices and in certain countries for age-eligible users. Google, Android, and Find Hub are trademarks of Google LLC.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 28PZX-F001SBAG

SAFETY WARNING

Do not charge the battery out of recommended temperature range of 10°C and 45°C. Waste lithium batteries shall not be discarded at will. Please dispose of them according to local laws and regulations.



Made in China