




User Manual

Model:F003

Smart Finder



Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc., registered in the U.S. and other countries. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc., registered in the U.S. and other countries. The trademark "iPhone" is used with a license from Apple Inc.

Find My User Manual

Quick explanation

1. Power on: Press and hold the button for 5 seconds, the device will beep and turn on. (How to confirm if the device is turned on: Double click the device button, and the device will make a sound indicating that it is turned on and does not need to be restarted)
2. Open the built-in app on the Apple phone system: search;
3. Selection: Items;
4. Select: Add item;
5. Selection: Other supported items;
6. During the process of searching for items, a device with the words A Tag 03 will appear;
7. Click on the device found in the app and name it.
8. After naming, you can connect and use the device function:
 - A. Call the device, click play sound, and the device will emit music.
 - B. Search for network assistance: When the device is away from Bluetooth distance, it cannot connect in the app. You can choose loss mode or enable it. Enter the contact's phone number, etc.

If there is an iPhone near the lost device, the owner's search app can receive notifications and the latest location.

9. Remove device: To remove a device in the app, you can choose to remove an item.

10. When the device is removed, the device does not automatically turn off, but remains paired. If a re-pairing is not performed within 10 minutes, the device will exit the pairing state. If you need to re-pair the device at this time, click the device button once and the device will sound. At this point, the device enters pairing mode and can be paired with the application again.

Equipment operation instructions

1. Power on (the device enters the power-on mode from the power-off sleep mode): If the device is in the power-off sleep mode, press and hold the button for 5 seconds, and the device will give a prompt tone to indicate that the device is powered on. When powered on, the device is in pairing mode and enters a timeout state after 10 minutes.
2. Device status confirmation: Double click the device button twice. When the device is not paired with the search app, the device will emit a prompt sound; When the device is paired and connected to the search app, the device emits a beep sound once; When the device is paired with the search app but not connected, the device emits a long prompt sound; The above situation indicates that the device is in a powered on state. If the device has no sound, it is in shutdown sleep mode. Press and hold the button for 5 seconds to turn it on.
3. When pairing mode times out, the device enters pairing mode again: when the device is removed, the device sounds a tone, and the device does not turn off, but is in pairing mode. After turning on or removing the device, if it is not re-paired within 10 minutes, the device will exit pairing mode (at which point the device cannot be paired with the search app). If you need to pair a device, click the device button once. The device emits a tone. At this point, the device enters the state Pairing mode allows re-pairing with the search application.
4. How to query the serial number: Press the button 6 times in a row within 2 seconds, the device will sound a tone, and then the
5. Restore factory settings: After the equipment is powered on, press the equipment button for 4 consecutive times. The device emits a tone.

After 2 seconds, it will make a "drip, drip, drip" sound. Do not release the button. Continue to press and hold the button for approximately 8 seconds until the device beeps again. When the button is released, the unit will be reset to factory settings.

6. The device enters the power-off sleep mode from the power-on state: When the device is in the power-on state, press the button 5 times in a row within 2 seconds, the device will sound a tone, and then the device will enter the power-off sleep mode.

Find Hub User Manual

Quick explanation

1. Power on: Press and hold the button for 5 seconds, the device will beep and turn on. How to confirm if the device is turned on: Double click the device button, and the device will make a sound.
2. Open the built-in application of Android mobile phone system: Find Hub;
3. After the pop-up window appears, select Connect;
4. Choice: Agree and continue;
5. After naming, you can connect and use the device function: click to play sound, and the device will emit music.
6. Remove device: You can choose to remove the product.

Equipment operation instructions

1. Power on (device enters power on mode from shutdown and sleep mode): Press and hold the button for 5 seconds, and the device will emit a prompt sound indicating that the device has been turned on.
2. Restore factory settings: After the device is turned on, click the device button 4 times in a row, and the device will emit a prompt sound. When you hear the device prompt sound, continue holding down the button for about 8 seconds until the device rings again, release the button, and at this point, the factory reset is complete.
3. Shutdown: After the device is turned on, press the button 5 times within 2 seconds. The device will emit a prompt sound and enter the shutdown sleep mode.

4. Open recognition mode: Find the button on the Find Hub and quickly press it 6 times within 2 seconds

About Find Hub

1. How is the device designed to discourage unwanted tracking?

If any Find Hub network accessory separated from its owner is seen moving with you over time, you'll receive unknown tracker alert on your phone which tells you how to find it, disable it and what to do next.

2. What is Find Hub network? And how does it work?

The Find Hub network provides a simple and secure way to locate compatible items using the Find Hub app on your Android™ device. Simply pair your compatible product with the Find Hub app to view alongside other Android devices. Find Hub helps you find and connect to what matters in a single, secure place. Find your belongings quickly and safely – even if your devices are offline. Plus, seamlessly and securely share your location with friends & family for peace of mind. All of your device location information remains private and safely stored.

3. Why doesn't the Fast Pair popup appear on my phone to add the device?

Try below steps to add device manually to your Find Hub app.

- 1 Make sure that your phone has Bluetooth and Location turned on.
- 2 Verify that your phone is connected to a Wi-Fi or mobile network.
- 3 Make sure your phone is within 0.5 meters (1.6 feet) of the device.
- 4 Navigate to Settings > Google > Devices & Sharing > Devices > check Scan for nearby Device is ON.

Note: If you ignore Fonvoi Tag popups twice or frequently, or pair and disconnect from tags frequently, it may trigger the banning logic, which is designed to prevent unnecessary Fonvoi Tag popups. To fix this, you can wait for the Fonvoi tab to pop up and turn it back on, or restart your phone.



Works with
Apple Find My



Works with Android
Find Hub

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Google, Android, and Find Hub are trademarks of Google LLC. Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ on select devices [devices or phones] and in certain countries for age-eligible users.

Note:

· If the device is powered on but Google Find Hub cannot detect it, restore the device to factory settings. it still cannot be found, restart your phone to locate the device.

FAQ:

1. How to confirm if the device is turned on?
Double click the device button. If the device emits sound, it indicates that the device is in working condition; If the device does not respond, it will be in a shutdown state. Press and hold the button for 5 seconds to turn it on.


FCC Caution. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules . These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may

cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment

How to Replace the Battery
The product can't be recharged. When the battery low, you will receive a notification from the app. Please follow the steps below to replace the battery.

1. Insert the tool into the port and gently lever it to release the buckle between the two shells until a gap appears.
2. Open the plastic cover, remove the old battery, and insert a new CR2032 3V lithium coin battery with the positive side facing up. A prompt tone will sound once the battery is properly connected.
3. Replace the cover, ensuring that the tabs align with the slots on the device.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

⚠ WARNING	
• INGESTION HAZARD: This product contains a button cell or coin battery • DEATH or serious injury can occur if ingested. • A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. • KEEP new and used batteries OUT OF REACH of CHILDREN • Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.	

Regulatory Safety Information



WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN
Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour

European Union-Disposal Information The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste.
■ When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

- A Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- B Even used batteries may cause severe injury or death.
- C Call a local poison control center for treatment information.
- D Battery type : CR2032.
- E Nominal battery voltage : 3 V.

- F Non-rechargeable batteries are not to be recharged.
 - G Do not force discharge, recharge, disassemble, heat above 60 °C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
 - H Ensure the batteries are installed correctly according to polarity (+ and -).
 - I Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
 - J Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.
 - K Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Risk of fire and burns.
Do not recharge, disassemble, heat (-20°C+70°C) or incinerate.

Article 12
Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

Article 14
The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations.

The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.