


Wireless Charging Power Bank with Earbuds



User Manual



Understanding the Power Bank and Earphones



Charging Contacts
Please keep clean
Avoid dirt to prevent malfunction

Wireless Charging Indicator Light

1. Cellphone in wireless charging: LED turns to red
2. Cellphone in quick charging: LED turns to green
3. Cellphone in wireless and quick charging: LED turns to green
4. When there are foreign objects, LED flash red color.

Power On/ Battery Level Indicator: White
100% 75% 50% 25%


Note: To ensure reliable charging When handling the earbuds, avoid accidental touches.

Charging Contacts

Microphone

Charging the Power Bank

When charging the power bank, one light stays on indicating 25% charge, two lights for 50%, three lights for 75%, and four lights for 100%.





Charging a Phone or Earphones with the Power Bank

Charging Phones

You can charge your devices through two methods.

1. Wireless charging can be done with wireless charging compatible phones. Place the mobile device onto the charging pad. Position the device as close to the center as possible. While connected the power bank indicator light will turn on, with a solid red light indicating normal wireless charging operation, a flashing red light indicating poor wireless charging or foreign objects, and a green light indicating fast charging.

2. Wired charging can be done for devices with a USB-C port. Use either a common USB-C to lightning cable or a USB-C to USB-C. Connect the two devices. The indicator light will turn on when successfully connected.


Function 3: Magnetic Stand

Use with iPhone 12 series or above, or phones with magnetic charging cases. You can also use the provided adhesive magnetic ring to make any phone case magnetic.

Charging Earphones

Place the earphones into the charging dock. Make sure the charging contacts connect. While charging, the earphones LED will glow red color. When fully charged the earphone's LED will glow blue color. After a minute it will no longer glow.

Note: The earphones will automatically charge when inserted.



POWERING ON/OFF

1. **Turning ON/OFF the Power Bank Case**

To turn ON, press the power button or place a mobile phone with wireless charging capabilities on the charging pad to automatically boot up the power bank.

To turn OFF press the power button once. The power bank will also automatically turn OFF after ten seconds of not being in use.

2. **Turning ON/OFF the Earphones**

When first using your earphones, place them into the case. When you remove them from the case, they will automatically turn ON.

When off, press and hold the multifunction buttons on both earphones for about 3 seconds to turn ON

When you place them back into the case, they will automatically turn OFF.

When on, press and hold the multifunction buttons on both earphones for about 5 seconds to turn off.

Note: If the LEDs on the earphones do not turn on when they are removed from the case, charge the case and try again. If the earphones do not pair together automatically, reset them.

~ Stay Phunkee