

E9 Pro 使用说明书

- 

中文说明：开发板出厂前，蓝牙工厂烧录了默认数据，请查看：DuDu_Pairing_code，每部设备
 中文说明：开发板出厂前，蓝牙工厂烧录了默认数据，请查看：DuDu_Pairing_code，每部设备
蓝牙1：充电状态下长按蓝牙键，充电完成后蓝牙灯亮，充电过程中蓝牙灯闪烁
蓝牙2：建议先充电再插线，插线电压为：DC5V+0.25V，充电电压为100mA-500mA；
TF卡插拔：第一次开机请以蓝牙模式，低电压状态下，插拔TF卡功能时，蓝牙保持待机，有
 电话可以正常使用；
 1. 蓝牙插拔后，双击电源键，将蓝牙T卡插拔，蓝牙灯闪烁三次，同时伴有
 提示音：TF card mode/TF卡模式（蓝牙静默工作）；
 2. 插拔后，双击电源键，将蓝牙T卡插拔，蓝牙灯闪烁一次，同时伴有
 提示音：Bluetooth mode/蓝牙模式（TF卡功能静默工作）；
 3. 长按电源键暂停时，蓝牙灯亮；

1. 耳机使用内置式可拆卸充电电池, 请尝试从耳机中取出电池, 以避免耳机, 长期不使用耳机时, 请将其存放于干燥通风的地方, 并每隔两个月给其充电一次。
2. 当耳机使用时间达 1 小时 15 分钟, 每分钟会有电量提示音: 提示音: 电量不足。提示音会自动关机, 此时请充电。
3. 将充电线插入交流电源插座。
4. 充电时红灯常亮, 如充电未开始, 请断开电源与耳机的连接, 然后将其重新与耳机重新连接一次。充满电后, 红灯熄灭, 红灯常亮。
5. 实际使用时间因使用频率和音量等使用习惯的不同, 使用方法和环境等因素而存在差异。

- 长时间使用大量量；
- 无论音量大小，使用耳机都影响您对周围环境的感知，使用耳机时多加注意；
- 切勿吸烟、进食耳机或将其浸入盐水中；耳机应远离火和高压设备；
- 不适合三岁以下儿童使用，包含小零件；
- 请勿将其召回为生活垃圾，应将其送至当地相应的电子设备回收站；
- ★若用户因违反以上警告内容造成的人身财产损失，本公司不承担任何责任。

品 牌	_____
产品名称	鲁都牌无线耳机
产品型号	RD Pro
生产日期	_____
检 验	合格
检 验 员	_____

该设备已评估符合一般射頻暴露要求。该设备在便携式暴露条件下使用不受限制。

E9 Pro User Manual

-

[illegible]

Before using any charger to charge this headset, please check whether the specifications marked on the charger meet the requirements (it is recommended that the output voltage of the charger is DC5V + 0.25V, and the output current is: 100mA~ 900mA). Excessively high charging voltage is very likely to damage the Bluetooth headset.

Warning: Only use the charger that has been certified and is matched with this device. Using a charger of other specifications may void the approval and warranty terms of the device, and may pose a danger. If the product is shipped with a charging cable from the factory, it is necessary to connect the product that has passed the 3C certification to a computer to charge it. It is prohibited to severely connect the product, as severe impact may damage the electronic mainboard and the battery.

To remove the battery from the headset to avoid damaging the headsets. When the headset is not used for a long time, store it in a dry and **workless place** and charge it once every 1-2 months.

① When the battery is low, the red light on the earbuds flashes once every second. If possible, there will be a low battery alert sound "DuDuDu" indicating that the earphone's battery is running low. If you continue to use it, it will automatically shut down. At this time, you need to charge it. Insert the connection plug of the charger into the earphone jack.

② Plug the charger into an AC power source.

③ When charging, the red light is constantly on. If charging has not started, please disconnect the power supply and disconnect the connection between the device and the earphone. After the connection is disconnected, the device is fully charged, the red light goes out, and the low light remains on constantly.

④ The actual talk time and standby time may vary depending on factors such as the usage settings, usage methods, and environment of the mobile phone.

• The correct wearing position of the earphone speaker is the cheek bone at front of the ear, do not put the speaker in the ear.

• Listening to loud music for a long time may cause discomfort, please try to use a moderate volume to avoid prolonged use loud volume all the time.

• Reduce the volume to a moderate level to protect your hearing and reduce the risk of the surrounding environment, so please pay attention when using headphones.

• Do not touch, sit on the headband or immerse it in salt water, keep the headset away from fire and high-voltage equipment;

• Not suitable for children under three years old, combine small parts;

• Do not put it into household waste, but take it to the appropriate local recycling point for electrical and electronic equipment;

• If the user violates the above warning content and causes personal and property losses, the company will not bear any responsibility.

The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can emit radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Name: _____
 Email: **22.Pug** _____
 Roll No: _____
 Date: _____
 Page: _____