


骨传导无线耳机

使用说明书

健康 · 舒适 · 释放双耳


按键功能概述



- 1. 磁吸充电
- 2. 音量+键
- 3. 电源键
- 4. 音量-键
- 5. 麦克风
- 6. 呼吸灯

释放双耳，放心自由，听音乐的同时还能聆听外界的声音；听音乐，打电话，玩游戏，立体声音，音质音效，清晰震撼；是您办公、外出、驾驶的最佳选择！

外观展示



控制说明

开机: 长按电源键3秒开机，右蓝灯常亮3秒后右蓝灯和红灯交替闪烁，提示音: Power on, Bluetooth mode, Pairing/开机，蓝牙模式，等待连接；
关机: 开机状态长按电源键5秒，右红灯闪烁后关机，提示音: Power off/蓝牙正在准备关机；
连接蓝牙: 设备搜索到"H70 Pro"，点击配对，连接成功后左右蓝灯5秒闪一次，提示音: Connected/蓝牙已配对成功；
断开蓝牙: 设备主动断开蓝牙或超距离断开蓝牙，右红、蓝灯交替闪烁，提示音: DuDu, Pairing/嘟嘟，等待连接；
播放/暂停: 音乐暂停状态下，单击电源键播放，播放音乐左右蓝灯1秒闪一次；音乐播放状态下，单击电源键暂停；
音量增加/减小: 音乐播放状态下单击音量+/音量-按键，最大音量时提示音: 噤；
上一曲/下一曲: 音乐播放状态下双击音量-/音量+按键；
语音助手: 蓝牙连接状态下长按2秒音量-按键进入语音模式，再长按2秒抬手退出；
接听/挂断/拒接: 来电状态单击电源键为接听，通话状态单击电源键为挂断，来电状态长按2秒音量+按键为挂断；
恢复出厂设置: 开机蓝牙状态下，连续5击电源键，右红灯闪烁3下，嘟嘟声后清除配对信息，恢复出厂设置成功，右红、蓝灯交替闪烁进入配对状态，提示音: DuDu, Pairing/嘟嘟，等待连接；
中英文切换: 开机蓝牙状态下长按音量+按键切换中英文，默认中文，提示音: English/中文；
充电: 1. 充电状态下右红灯常亮，充电完成后蓝灯常亮，充电过程中自动关机；
2. 建议充电器规格，输出电压为: DC5V+/-0.25V，输出电流为100mA-500mA；
音乐灯: 蓝牙和TF卡音乐播放时连续3击电源键打开/关闭左右蓝色呼吸灯，打开状态下，播放音乐左右蓝灯1秒闪；
TF卡功能: 1. 第一次开机默认蓝牙模式，任何状态下，切换TF卡功能时，蓝牙保持连接，有电话时可以进行通话；
2. 蓝牙播放下，双击电源键，转到TF卡播放，此时右蓝灯长亮3秒后，左右蓝灯


每1秒闪烁一次，同时伴有提示音: TF card mode/TF卡模式(蓝牙静态工作)；
3. TF卡播放下，双击电源键，转到蓝牙播放，暂停状态左右蓝灯每5秒闪一次，同时伴有提示音: Bluetooth mode/蓝牙模式(TF卡功能静态工作)；
4. TF卡播放暂停时，左右蓝灯常亮；
5. 读写TF卡内容，数据线连接电脑->读盘(右红、蓝灯常亮)，读盘完成后断开数据线，关机；
6. TF卡支持多种音频解码格式播放(MAV, WMA, FLAC, MP3等)；
7. TF卡播放状态下切换蓝牙，再次切换回TF卡模式继续播放当前歌曲(记忆功能)；
8. TF卡模式下，来电通话结束继续播放当前位置；
9. 恢复出厂设置后歌曲重新从第一首播放，关机后开机接着当前歌曲播放。
多点连接: 1. 连接手机A，关闭手机A的蓝牙功能；
2. 耳机处于等待连接状态，连接到手机B；
3. 再打开手机A的蓝牙，可以同时连接手机A。

充电器和电池


充电器和电池
使用任何充电器给本耳机充电前请检查充电器的规格标注是否符合要求(建议充电器输出电压为DC5V+/-0.25V，输出电流为:100mA-500mA)，充电电压过高极有可能损坏蓝牙耳机。
警告: 仅可使用经过认证与此配套的充电器，使用其他规格的充电器可能违反对设备的认可和保修条款，并可能导致危险，如果出厂是配充电线出货的，需连接通过3C认证的充电器或电脑给其充电，禁止对本产品严重碰撞，严重撞击有可能损坏电子主板及电池。
为电池充电
本耳机使用内置式不可拆卸充电电池，请勿尝试从耳机中取出电池，以免损坏耳机。长期使用耳机时，请将其存放于干燥通风的地方，并每隔两个月给其充电一次。
1. 低电量时耳机右红灯1秒闪一次，每1分钟会有低电量提示音: 嘟嘟，表示耳机电量不足。继续使用会自动关机，此时需要充电。

- 将充电器插到交流电源插座上。
- 充电时右红灯常亮。如充电未开始，请断开电源与耳机的连接，然后将其重新与耳机重新连接再试一次。充满电后，红灯熄灭，蓝灯常亮。
- 实际通话时间和待机时间可能与手机的使用设置、使用方法和环境等因素而存在差异。

佩戴说明



将耳机挂在颈后，两侧扬声器贴在面颊骨调整佩戴的舒适度。



请勿过度扭曲或弯曲后支架以免损坏内部导光元件。

产品规格

音乐播放时间-----标准状态: 约5小时	喇叭阻抗-----8Ω±15%
待机时间-----90小时	麦克灵敏度----- -38±3db
充电时间-----2.5小时	蓝牙连接距离-----10米
BT版本-----6.0	

重要说明

- 本款耳机扬声器的正确佩戴位置为耳朵前方的面颊骨处，请勿将扬声器置于耳内；
- 长时间听大音量的音乐可能会带来不适感，请尽可能使用中等左右的音量，避免长时间使用大音量；
- 无论音量大小，使用耳机都将影响您对周围环境的感知，使用耳机时多加注意；
- 切勿乱扔、坐压耳机或将其浸入盐水中；耳机应远离火和高压设备；
- 不适合三岁以下儿童使用，包含小零件；
- 请勿将其归类为生活垃圾，而将其送往当地相应的电器电子设备回收站；
- ★若用户因违反以上警告内容造成的人身财产损失，本公司不承担任何责任。


FCC声明:

本设备符合美国联邦通信委员会规则第 15 部分的规定。其运行需满足以下两个条件:
(1) 本设备不得产生有害干扰;
(2) 本设备必须能够接受所接收到的任何干扰, 包括可能引起非预期运行的干扰。
警告: 未经负责合规事宜的一方明确批准所做的更改或修改将可能使用户失去设备的运行权限。
注意: 此设备已通过测试, 符合 FCC 规则第 15 部分中关于 B 类数字设备的限值要求。这些限值旨在为住宅安装提供合理的抗干扰保护。
该设备会产生电磁辐射并可能发射无线电频率能量, 若未按照说明正确安装和使用, 可能会对无线电通信造成有害干扰。不过, 并不能保证在任何特定安装中都不会出现干扰情况。如果该设备确实对无线电或电视接收造成了有害干扰, 可以通过关闭设备并重新开启来判断干扰是否存在。若存在干扰, 建议用户尝试以下一种或多种方法解决:
调整或重新安装接收天线的位罝。
增大设备与接收器之间的距离。
将设备接入与接收器不同的电路端口。
咨询经销商或有经验的无线电/电视技术人员寻求帮助。

射频警告说明:

该设备已通过评估, 符合一般射频暴露标准。该设备可在便携式暴露环境中正常使用, 不受任何限制。


Overview Of Button Functions



- 1. Magnetic charging port
- 2. Volume+ button
- 3. Power button
- 4. Volume- button
- 5. Microphone
- 6. Breathing Light

Release your ears, rest assured and free. Listen to the sound of the outside world while listening to music, listen to music, make calls, play games, stereo sound, real sound effect, clear and shocking. It is the best choice for your office, going out and driving!

Appearance display



Bone conduction wireless headset

H70 Pro
User Manual

Health · comfort · Release the ears

Control Description


Power On: Press and hold the power button for 3 seconds to turn on the device. After the right blue light stays on for 3 seconds, the right blue light and the red light will flash alternately. The prompt tone is: Power on, Bluetooth mode, Pairing.
Power Off: While powered on, press and hold the power button for 5 seconds. The right red breathing light flashes, then the device shuts down with the prompt: "Power off. Blue -tooth is preparing to shut down."
Bluetooth Pairing: The device detects "H70 Pro". Click on "Pair", and the connection is successful. After that, the left and right blue lights flash once every 5 seconds with a voice prompt: "Connected".
Disconnect Bluetooth: The device actively disconnects Bluetooth or for a very long distance, Bluetooth is disconnected, with the red and blue lights flashing alternately, and the prompt sound: "DuDu, Pairing".
Play/Pause: When the music is paused, click the power button to play. The left and right ice blue lights flash once every second. When the music is playing, click the power button to pause.
Volume Increase/Decrease: Click the volume +/volume - button when the music is playing. When it reaches the maximum volume, there will be a prompt sound of "Du".
Previous Track/Next Track: Double-click the volume +/volume - button when the music is playing.
Voice Assistant: Long press the volume - button for 2 seconds to enter the voice mode when the Bluetooth is connected. Then long press the volume + button for another 2 seconds and raise your hand to exit.
Answer/Hang Up/Reject a Call: Click the power button to answer an incoming call. Click the power button to hang up during a call. Long press the volume + button for 2 seconds to reject an incoming call.
Restore Factory Settings: During the power-on and Bluetooth state, continuously press the power button 5 times. The right red light will flash 3 times, followed by a beeping sound. Then the pairing information will be cleared and the factory settings will be restored successfully. The right red and blue lights will alternate flashing to enter the pairing state. The prompt sound is: DuDu, Pairing.
Chinese-English Switch: Long press the volume + button while the device is powered on and Bluetooth to switch between Chinese and English. The default language is Chinese. The prompt sound will be "English"/"中文".

Charging: 1. When charging, the right red light remains constantly on. After charging is complete, the blue light remains constantly on. During charging, the device will automatically shut down.
2. It is recommended that the charger has the following specifications: the output voltage is DC5V+/-0.25V, and the output current ranges from 100mA to 500mA.
Music Lights: When playing music via Bluetooth or TF card, continuously press the power button three times to turn on/off the left and right blue breathing lights. In the on state, the blue lights flash once every second on the left and right sides when playing music.
TF Card Function: 1. When the device is powered on for the first time, the default mode is Bluetooth mode. In any state, when switching to the TF card function, the Bluetooth connection will be maintained, and it will not affect calls.
2. When playing with Bluetooth, double-click the power button to switch to playing from the TF card. At this point, the right blue light will remain on for 3 seconds, then the left and right blue lights will flash once every second, accompanied by a prompt sound: TF card mode (the Bluetooth is in a static working state at this time).
3. When playing from the TF card, double-click the power button to switch to Bluetooth playback. The left and right blue lights will flash once every 5 seconds, accompanied by a prompt sound: Bluetooth mode (the TF card function is in a static working state at this time).
4. When the TF card playback is paused, the left and right blue lights will remain on constantly.
5. Read and write the content of the TF card. Connect the data cable to the computer -> read the disk (the right red and blue lights remain on constantly), after the reading is completed, disconnect the data cable and turn off the device.
6. Supports MP3/WAV/FLAC/APE/WMA.
7. When switching to Bluetooth from the TF card playback mode, and then switching back to the TF card mode to continue playing the current song (memory function).
8. In the TF card mode, when the incoming call ends, it will continue to play the current location.
9. After restoring the factory settings, the songs will start playing from the first one again.
After turning off the device and turning it on again, it will continue to play the current song.
Multi-point Connection: 1. Connect to mobile phone A, then turn off the Bluetooth function of mobile phone A.
2. The headphones are in the state of waiting for connection. Connect them to mobile phone B.
3. Then turn on the Bluetooth of mobile phone A. Now both mobile phone A and mobile phone B can be connected simultaneously.


Chargers and Batteries

Chargers and Batteries
Before using any charger to charge this headset, please check whether the specifications marked on the charger meet the requirements (It is recommended that the output voltage of the charger is DC5V +/- 0.25V, and the output current is: 100mA - 500mA). Excessively high charging voltage is very likely to damage the Bluetooth headset.
Warning: Only use the charger that has been certified and is matched with this device. Using a charger of other specifications may violate the approval and warranty terms of the device, and may pose a danger. If the product is shipped with a charging cable from the factory, it is necessary to connect a charger that has passed the 3C certification or a computer to charge it. It is prohibited to severely collide the product, as severe impact may damage the electronic mainboard and the battery.
Charging the Battery
This headset uses a built-in non-removable rechargeable battery. Please do not attempt to remove the battery from the headset to avoid damaging the headset. When the headset is not used for a long time, store it in a dry and ventilated place and charge it once every two months.
1. When the battery is low, the red light on the right side of the earphone flashes once every second. Every minute, there will be a low battery alert sound: "DuDu", indicating that the earphone's battery is running low. If you continue to use it, it will automatically shut down. At this time, you need to charge it. Insert the connection plug of the charger into the earphone jack.
2. Plug the charger into an AC power socket.
3. When charging, the right red light is constantly on. If charging has not started, please disconnect the power supply and the connection between the device and the earphone, then reconnect them and try again. After the device is fully charged, the red light goes out and the blue light remains on constantly.
4. The actual talk time and standby time may vary depending on factors such as the usage settings, usage methods, and environment of the mobile phone.

Wearing Instruction



Hang the earphones behind the neck, and the speakers on both sides are attached to the cheekbones to adjust the wearing comfort



Do not twist or bend the rear headband excessively. Avoid damage to internal light guide elements

Product Specifications

Music playing time-----Standard status: About 5 hours	Speaker impedance-----8Ω±15%
Standby time -----90 hours	Mike sensitivity----- -38±3db
Charging time -----2.5 hours	Connection distance ---10m
BT version -----6.0	

Important

- The correct wearing position of the earphone speaker is the cheek bone in front of the ear, do not put the speaker in the ear;
- Listening to loud music for a long time may cause discomfort, please try to use a moderate volume to avoid prolonged use of loud volume all the time;
- Regardless of the volume level, the use of headphones will affect your perception of the surrounding environment, so pay more attention when using headphones;
- Do not throw, sit on the headset or immerse it in salt water; keep the headset away from fire and high-voltage equipment;
- Not suitable for children under three years old, contains small parts;
- Do not sort it into household waste, but take it to the appropriate local recycling point for electrical and electronic equipment;
- ★If the user violates the above warning content and causes personal and property losses, the company will not bear any responsibility.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.