


Quick Start Guide

Guide de démarrage rapide

Guía de inicio rápido



Smart Watch
Model: Pebble Round 2

Getting Started

Pour commencer

Configuración inicial

Follow these steps to set up your Pebble

Suivre les étapes suivantes pour configurer votre montre Pebble :

Siga estos pasos para configurar su Pebble

1 Visit qr.repebble.com from your smartphone and download the "Pebble" app.

Se rendre sur le site qr.repebble.com à partir du smartphone, et télécharger l'application "Pebble".

Dirijase a la página qr.repebble.com desde su smartphone y descargue la aplicación "Pebble".

2

Connect USB charging cable to Pebble on any USB connection.

Connecter la montre Pebble à un port USB à l'aide du câble de chargement USB.

Conecte el cable de carga USB al Pebble en cualquier conexión USB.

3

Press and hold the power button on the watch.

Appuyez sur le bouton d'alimentation de Pebble

Mantén pulsado el botón de encendido en el reloj

operating temperature:
charge: 0 - 45 °C
discharge: -20- 60 °C



4

Pair your Pebble to your smartphone via Bluetooth.

Coupler la montre Pebble à votre smartphone via Bluetooth.

Conecte su Pebble a su smartphone mediante Bluetooth.

5

Follow the instructions on your smartphone app to upgrade firmware and start using your Pebble !

Suivre les instructions sur l'application smartphone afin de mettre à jour le micrologiciel, et commencer à utiliser la montre Pebble !

Siga las instrucciones de la aplicación de su smartphone para actualizar el firmware y empiece a utilizar su Pebble .

Learn more about your Pebble at www.repebble.com

Pour en savoir plus sur la montre Pebble , consultez le site www.repebble.com

Obtenga más información sobre su Pebble en www.repebble.com

About Pebble

À propos de Pebble

Acerca de Pebble

Charge your Pebble using a standard USB port.

Charger la montre Pebble au moyen d'un port USB standard.

Cargue su Pebble utilizando el puerto USB estándar.

Your Pebble is water resistant up to 20 m and features a scratch resistant surface.

Votre montre Pebble est résistante à l'eau jusqu'à 20 m et sa surface résiste aux rayures.

Su Pebble es resistente al agua hasta 20 m y dispone de una superficie resistente a los arañazos.

Clean with a soft, moistened cloth. If necessary, use isopropyl alcohol or mild detergent to clean.

La nettoyer avec un chiffon doux et humide. Si nécessaire, utiliser de l'isopropanol ou un détergent doux pour la nettoyer.

Limpiar con un paño suave y húmedo. Si fuera necesario, añada alcohol isopropílico o un detergente suave para limpiar.



The device meets the EU RoHS criterion. Please refer to IEC 62321, EU RoHS Directive 2011/65/EU and revised directive.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION
The device has been evaluated to meet general RF exposure statement.
The device can be used in portable exposure condition without restriction
-- Risk of explosion if the battery is replaced by an incorrect type;
-- disposal of a battery into fire or a hot oven, or mechanically

crushing or cutting of a battery, that can result in an explosion;
-- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
-- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

If you experience discomfort or skin irritation when wearing your smart watch, then we recommend you try cleaning your device. Sometimes residue or foreign materials build up around your device and may aggravate your skin. It's also possible that you are not wearing the watch correctly. We recommend making sure to clean and adjust your watch regularly for a more comfortable fit.

Caution:
• If you experience skin irritation when wearing your watch, please refrain from wearing, and wait two to three days to see if your symptoms ease. If symptoms persist or worsen, please consult a physician.
• If you have eczema, allergies or asthma, you may be more likely to experience a skin irritation or allergy from a wearable device.

Wear and Care
Some users may experience skin irritation when using this product. To reduce the potential for irritation, please follow four simple wear and care tips: (1) keep it clean; (2) keep it dry; (3) do not wear it too tightly, and keep the wearing gap as one finger; (4) after long-term wearing, remove the device in time to relax the wrist; (5) after exercise, if your wrists sweat, please clean and dry your wrists and watches before wearing again. The residual sweat components will corrode the watch. It is recommended to regularly use soap or hand sanitizer to clean the watch. In case of skin allergy, please take off your watch and seek medical advice in time.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
1) L'appareil ne doit pas produire de brouillage;
2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

*Do not attach the magnetic part of the charging cable to other metals to avoid short-circuiting the contacts of the charging cable.
SAR compliance is based on a separation distance of 0 mm between the unit and the body of the user
SAR compliance is based on a separation distance of 0 mm between the unit and the body of the user
La conformité du das est basée sur une distance de séparation de 0 mm entre l'unité et le corps de l'utilisateur

Responsible Party
Name and company of U.S. agent: Core Devices LLC
Physical U.S. address of agent: 2261 Market Street STE 22843, San Francisco, California United States 941144
FRN of U.S. agent: 0037172152
Email address of U.S. agent: eric@repebble.com, ericmigli@gmail.com
Contact NO.: (585) 648-3187