

Magnetic Grip Stand Power Bank

USER MANUAL

Please read this user manual carefully before using the product.

Overview

This is a MagSafe-compatible power pack featuring charging technology like Power Delivery. By pairing it with your original charging cable or the included cable, you can charge any device, from smartphones, tablets to gaming devices.



Packing List

- Magnetic Grip Stand Power Bank
- USB-C to USB-C cable
- User Guide

Features&Specification

- MagSafe Compatible
- Power Delivery
- Built-in Video Stand
- USB-C Input / Output
- High density Lithium-Polymer cell

Specification

Product Name:	Magnetic Grip Stand Power Bank
Model:	M01
Battery Capacity:	10000mAh (37Wh)
Wireless charging:	15W/10W/7.5W/5W
TYPE-C 1 input:	5V/2.4A,9V/2A,12V/1.5A (MAX)
TYPE-C 2 input	5V/2.4A 9V/2A,12V/1.5A (MAX)
TYPE-C1 output:	5V/2.4A,9V/2.22A,12V/1.67A (MAX)
USB-A output:	5V/2.4A, 9V/2A, 10V/2.25A, 12V/1.5A (MAX)
TYPE-C 2 output:	5V/2.4A, 9V/2A, 10V/2.25A, 12V/1.5A (MAX)
Wireless charging:	15W/10W/7.5W/5W
Multi-port simultaneous output (total output power)	15W (MAX)
Product Size:	10.9*7*2cm
Product Weight:	180g

Important Safety Instructions

When using this product, basic precautions should

always be followed including the following:

- 1) Store product in a cool and dry place.
- 2) Do not store the product in hot or humid environments.
- 3) Do not dispose of the product in heat or fire.
- 4) Do not clean the product with harmful chemicals or detergents.
- 5) Please store it out of the reach of little children.
- 6) Misuse, dropping, or excessive force may cause product damage.
- 7) Using a power supply or charger that is not recommended or sold by the product manufacturer may result in a risk of fire or personal injury.
- 8) Do not use connectors once the terminals are bent.
- 9) When connecting the connector, check the insertion direction and insert the connector directly.
- 10) Operating temperature should be between 32 ° F to 113 ° F / 0°C to 45°C
- 11) The power USB interface of this product is specially used for charging and powering USB devices. Please do not use this product for other purposes.
- 12) If the battery is hot or abnormal, please discontinue use immediately.
- 13) Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or personal injury.
- 14) If the product is not being used a long time, it should be charged and discharged every three months.
- 15) The product may feel warm when charging the device, which is a normal operating situation and should not be a cause for concern.

Safety Information

Before installing and using the product, please read the instructions thoroughly and retain them for future reference.

Do not expose this battery to moisture or submerge it in liquid.
Keep battery dry at all times.

Do not attempt to open or disassemble the product, such action will void the warranty.

This battery is meant for use in conjunction with the appropriate mobile device. Please check your device packaging to determine whether this battery is compatible with your particular mobile device. Manufacturer is not responsible for any damages to any mobile device incurred through the use of this product.

Avoid dropping and extreme temperature. Improper use of this product may result in product damages, excess heat, toxic fumes, fire or explosion, any which Skinarma are not held responsible.

Do not store battery in high temperature environment, including intense sunlight heat.

Do not place battery in fire or other excessively hot environments.

Be cautious of excessive drops, bumps, abrasions or other impacts to this battery.

If there is any damage to the battery such as dents, punctures, tears, deformities or corrosion, due to any cause, discontinue use and contact manufacturer or dispose of it in an appropriate manner at your local battery recycling center.

Caution: If powerbank is not working while charging, check to see if the cable is firmly connected, or if your device's charging cable is working. Do not puncture or open the powerbank or expose it to water, fire or high temperature. If a bulge appears on the powerbank, stop using

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction