

Instruction Manual



CAPACITIVE TOUCH SCREEN

Main interface

English

● ACCESSORY LIST

- 1.Bracket x2
- 2.64GB TF card x1
- 3.Cigarette lighter x1
- 4.1080P reversing camera x1
- 5.AUX cable x1
- 6.User Manual x1

● Description of "touch" on the icons



- 1.Touch to turn off the screen
- 2.Touch to play Application Interface
3. Touch for settings
- 4.Touch to enter the app interface
5. Touch for bluetooth
- 6.Touch for the audio out
- 7.Touch for playback



8. Touch to enter CarPlay
9. Touch to enter Android Auto

● Description of the status-bar icons



1-----2-----3-----4-----5

- 1.If this icon appears in the status bar at the top of the main screen, it indicates that FM transmit mode is enabled.
- 2.If this icon appears in the status bar at the top of the main screen, it indicates that a TF card is inserted.
- 3.If this icon appears in the status bar at the top of the main screen, it indicates the screen brightness level.
- 4.If this icon appears in the status bar at the top of the main screen, it indicates the volume level.
- 5.If this icon appears in the status bar at the top of the main screen, it indicates that Bluetooth is connected successfully.



6-----7

- 6.Touch the icon to return to the main screen.
- 7.Touch the icon to go back.

● Additional operating instructions

Touch the recording screen on the main interface to switch between front/rear camera.

DVR



- 1.Touch to enter the DVR interface.



2-----3-----4-----5-----6-----7

- 2.Touch to stop recording.
- 3.Touch to mark as important video.
- 4.Touch to take a photo.
- 5.Touch to open the saved video list.
- 6.Touch to turn off voice recording.
- 7.Touch once to switch to the rear camera; tap again for front/rear split-screen view.



1.DVR recorded video save list.

2.Touch to open the important video save list.

3.Touch to open the saved photo list.



4.Touch to switch to the rear-view saved video/photo list.

5.Touch to select items from the list.

6.Touch to delete the selected items from the list.

Audio Out

Touch "Audio Out" in home menu to enter Audio Out interface.



1.Touch to output audio through the speaker.

2.Touch to Carplay/Android Auto audio through the phone's Bluetooth.

3.Touch to turn on FM transmit.

4.Touch to output audio through the AUX.


BT Music




1-----2-----3-----4

1. Touch to go to Previous song
2. Touch to play or pause music
3. Touch to go to the next song
4. Touch to adjust volume

Installation



Do not connect the speaker leads of the power cord to the car battery; otherwise, the unit will be seriously damaged.
BEFORE connecting the speaker leads of the power cord to the speakers, check the speaker wiring in your car.



This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Class B device:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

CE

The maximum SAR value is 0.712W/kg when the device is used close to the user.

Product Warranty Card

Warranty Period:

This product is entitled to 12 months of free repair service from the effective date of purchase.

Warranty Scope:

Under the premise of complying with the usage regulations, any performance failure caused by manufacturing defects of the product itself can enjoy free repair services.

Disclaimer Clause:

The following situations are not within the scope of warranty liability:

1. Damage caused by force majeure (such as earthquakes, fires, floods, typhoons, etc.);
2. Malfunctions caused by improper use, maintenance, and storage by consumers;
3. Damage caused by unauthorized personnel dismantling, repairing, or modifying without the authorization of our company;
4. The warranty certificate does not match the product information or the certificate has been altered or missing;
5. The product has exceeded the agreed warranty period;
6. Appearance wear and natural aging of consumables caused by normal use.

Service Channels:

If you need technical support or warranty services, please contact us through the following methods:

Customer Service Email: info@tianshi-digital.com

Service website: <https://tianshi-digital.com>

We suggest that you prioritize initiating service requests through the official customer service channel of the original purchasing platform.

Purchase Date		Serial Number	
Product Model		Contact Email	