

105g铜版纸/单面彩色印刷/折叠尺寸:60*65mm

Manual



The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Google, Android, and Find Hub are trademarks of Google LLC. Find Hub network requires location services and Bluetooth to be turned on.Requires cell service or internet connection. Works on Android 9+ on select devices [devices or phones] and in certain countries for age-eligible users.


Getting Started

1. Check For Updates

To use the Apple Find My app to locate your Item Locator, the latest version of iOS, iPad OS, or macOS is recommended.

2.Power On

Pull the plastic tab to enable battery contact, it should beep once indicating it is powered on. If you don't hear the beeps, press the button to power on, then you will hear the beeps and will be in pairing status.



3.Introduction

3.1 For IOS system


Open Find My APP on your supported iPhone or iPad.



Step1. Select the "Items" tab then Tap the "Add Item" tab. +symbol (Figure 1)



Step2. Tap "Other Supported Items".



Step3. Make sure your Item Locator is close to your phone. Wait... until you see "TAG ONE", then tap "Connect". Follow the pop-up to fill name and select an emoji; then tap "Continue". There will be a request to add your Item Locator to your ID, then tap "Continue". Tap "Finish" and your Item Locator will be set up.





Function Introduction

Locate your Item


- Find Item Locator
- Tap "Play Sound" to make your Item Locator beep when it is nearby.
- Find your Item Locator's location

Your Item Locator's last known location will appear on the map as emoji you choose during set up, tap "Directions" to navigate to the last known location.



Find Item When Out of Range


- Enable the "Notify When Left Behind" toggle, you will receive a notification when you leave your Item Locator behind and it is no longer in range of your device.
- Enable the "Notify when Found" toggle, when your Item location is seen by another Find My enabled device, you will receive a notification of its updated location.
- Note: "Notify When Found" can only be activated when your Item Locator is out of range.



When Your Item is Lost

Under "Lost Mode", tap the "Enable" tab, a screen detailing Lost Mode will pop up, tap "Continue". You can enter your phone number or email address and tap "Next". You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode"

- Note: When "Lost Mode" is enabled, "Notification When Found" is automatically enabled.
- Note: When "Lost Mode" is enabled, your Item Locator is locked and cannot be paired to a new device.



Remove your Item Locator


- Ensure "Lost Mode" is disabled, tap "Remove Item" tab, a summary will open, tap "Remove" to confirm.

Reset your Item Locator


- After successfully removing th Item Locator from the APP, pres the Item Locator's function button four times rapidly, and then hold it a fifth time until yo hear a ringing chime, the Item Locator is now reset and ready to pair to a new device.

3.2 For the Android system


step1. Click on Connect on the pop-up window




step2. Select "Agree and continue"



step3. Turn on device location



step4. Select "Open app"



Function Introduction




Locate your Item

- Find Item Locator
- Tap "Play Sound" to make your Item Locator beep when it is nearby.
- Find your Item Locator's location

The ringtone volume indication on the ringing page changes correspondingly based on the distance from the device.

Your Item Locator's last known location will appear on the map as emoji you choose during set up, tap "Directions" to navigate to the last known location.



Product Lost and Found Search

Click "Mark as lost" on the APP interface, and fill in your contact information according to the prompts. The product will be locked. As soon as the product is located, the user will receive a notification.

How to replace the Battery:

- Use your fingernails at the small gap on the side of your Item Locator to carefully open the case.
- Replace the battery with a new CR2032 battery 3V. (Positive pole upward).
- Carefully close the Item Locator.



Unwanted Tracking Detection:

If your iPhone detects that an unknown Item Locator is traveling with you, it will send you a notification. A sound will start playing so you will be able to find it. These alerts are only activated when an Item Locator is not connected to its owner's phone, so your partner's Item Locator will not trigger a sound if they are with you.

Button function

1.Power on (Findmy function is on). Press the function button once to turn it on, it should a ringing chime indicating it is powered on.

If the product is not paired, it will be closed within 10 minutes. You need to trigger the findmy function again to continue pairing.

2.Power off (Findmy function is off). When the device is turned on, press the button 5 times within 2 seconds, and the device will emit a prompt sound, entering the shutdown sleep mode.

3.How to query serial number Press the button 6 times in a row within 2 seconds, the device will emit a prompt sound, and the device will enter the serial number reading state.

4.Restore factory settings (reset the device locally and restore it to pairing status) After the device is turned on, click the device button 4 times in a row, and the device will emit a prompt sound. When you hear the device prompt sound, continue holding down the button for about 8 seconds until the device rings again, release the button, and at this point, the factory reset is complete.

A reset operation is required to enable the device to enter the pairing state again (synchronization of Findmy also requires simultaneous unbinding) and rebind the new Apple Id account.



Important tips:

- When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following action is recommended: 1. Change the phone's network, such as switching between WiFi and mobile. The first pairing may takes a long time, please wait patiently. 2. Reset your item. 3.Repair with Findmy APP.
- When "Lost Mode" is enable, DO NOT REMOVE ITEM in the APP. Your Item Locator will be locked and cannot be paired to a new device.
- The battery usage time varies depending on personal usage habits. Frequent use of the call function can accelerate battery consumption.

Regulatory Safety Information

Warning: The battery must be kept out of the reach of children. Due to chemical burns and potential esophageal perforation, swallowing may cause serious injury or death. If the child accidentally swallows the button battery, please call the rescue phone immediately and seek medical advice in time.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee

that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2BQIT-TG105

