

Age 5+

User Manual

How to Use Fartzilla

1. Charge It Up

Plug the included USB-C cable into Fartzilla and charge via computer, power bank, or USB wall adapter (not included).

A red light means it's charging. When the light turns green, charging is complete.

2. Let It Rip

Once charged, Fartzilla is ready for up to 5 hours of farting (not necessarily in one sitting... please pace yourself).

3. Hide and Blast

Place Fartzilla anywhere you like and turn it on. Then grab the wireless remote and press a button to trigger one of 26 gut-busting fart sounds.

4. Remote-Controlled Mayhem

The wireless remote is powered by a CR2032 battery (included). Use it to sneakily set off stink bomb sounds from across the room (range is approx. 49 feet or 15 meters).

5. Pro Tips

- Turn off Fartzilla when not in use to save battery.
- If the remote isn't working, try using it closer to Fartzilla.
- Still no luck? Replace the CR2032 battery in the remote.

Battery & Charging Info

- Fartzilla Monster: Rechargeable Li-ion 300mAh battery (included)
- Remote Control: Requires one CR2032 battery (included)
- Charging: USB-C cable included. Wall adapter not included.

Let Fartzilla roar and bring on the hilarity—just remember to blame the monster.

Battery Safety

- Do not disassemble the battery.
- Keep away from fire and water.
- Adult supervision is recommended during charging.

Battery replacement requires adult assembly. To install, remove or replace the batteries, use a screwdriver to open the battery door on the bottom of the product. Install new batteries. When removing exhausted batteries, dispose of them immediately in accordance with local regulations. Insert new batteries carefully matching the + and – polarity markings in the Sounds Box. Replace the battery door and secure with the screw.

Use only alkaline batteries. Do not mix different battery types. Do not mix old and new batteries. Do not use rechargeable batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not short-circuit the supply terminals. Keep new and used batteries away from children.

Remove batteries if product is not to be used for a long time. Retain this information for your records.

WARNING!

Contains Button Battery

Button batteries are hazardous and can cause serious injuries if swallowed or placed inside any part of the body.

Keep batteries away from children whether new or used. Dispose of used batteries immediately.

If you think that batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

© 2025 Continuum Games, Inc. Indianapolis, IN 46219. Fartzilla, Remote Control Flatulator, Continuum Games and their logos are trademarks of Continuum Games, Inc. in the U.S.A. and other countries. All Rights Reserved. Manufactured by Continuum Games, Inc. 1240 Brookville Way, Suite J, Indianapolis, IN 46239. Made in Ningbo China.

www.ContinuumGames.com 317-869-4000 NH061520250524

Battery: Li-300mAH
Tested to comply with FCC Standards: Part 15





OPEN SPACE FOR OTHER INFO/ DIAGRAMS

Back of unit

91.90

72.00

ContinuumGames.com
Indianapolis, IN 46219 USA
Fartzilla Remote Control Flatulator
CG0524
Made in Ningbo China
NH06152025
Battery: Li-300mAH
Tested to comply with FCC Standards: Part 15

Front of unit

ART

29.50

Top of unit

67.00

36.95

Bottom of unit

15.00

20.00

ContinuumGames.com
Indianapolis, IN 46219 USA
Fartzilla Remote Control Flatulator
CG0524
Made in Ningbo China
NH06152025
Battery: CR0032
FCC ID: 7777
Tested to comply with FCC Standards: Part 15