




材质:80G书写纸 单黑印刷 风琴折

 OWS OPEN WIRELESS EARBUDS  Instruction manual Please read the instruction manual before use	 PACKING LIST <table> <tr> <td>Charging case</td> <td>Earbuds</td> <td>USB</td> </tr> </table>    Instructions color box	Charging case	Earbuds	USB	 Product specification - Product specification - Product specification - Horn hole - Charging pin - Indicator lights - Type-C 	 Product parameter <table> <tr> <td>Transmission distance: 10m</td> <td>Charging box battery capacity: 200mAh 3.7V</td> </tr> <tr> <td>Horn diameter: Φ11mm</td> <td>Earbuds battery capacity: 35mAh 3.7V</td> </tr> <tr> <td>Horn impedance: 32Ω ± 15%</td> <td>Charging time of charging box: ≈1.5 hours</td> </tr> <tr> <td>Sensitivity: 96 ± 3.0dB</td> <td>Total playing time: ≈17 hours</td> </tr> <tr> <td>Frequency response range: 20Hz-20kHz</td> <td></td> </tr> </table>  Product operation instructions Power on Method 1: Press and hold for 5 seconds to turn on the headphones. Method 2: Open the charging case and remove the earphones. The earphones will automatically turn on.	Transmission distance: 10m	Charging box battery capacity: 200mAh 3.7V	Horn diameter: Φ11mm	Earbuds battery capacity: 35mAh 3.7V	Horn impedance: 32Ω ± 15%	Charging time of charging box: ≈1.5 hours	Sensitivity: 96 ± 3.0dB	Total playing time: ≈17 hours	Frequency response range: 20Hz-20kHz		 Power Off Method 1: Put the earphones back into the charging compartment and close the charging compartment. The earphones will automatically shut down. Method 2: Press and hold the multifunction key for 5 s seconds to shut down (not supported in connected state) Manual shutdown, automatic shutdown after 5 minutes of standby in an unconnected state. Bluetooth Step 1: Open the charging box cover, take out the left and right earbuds, earbuds automatically turn on and pair; Step 2: Open the Bluetooth list of smart devices and search for "PoPo Air " to pair.  Note: * Fully charge the headphones and power off befo * Unplug the charging cable after charging.	 Operating instructions Play/Pause: Double click on the left/right earphones Answering/hanging up calls: Double click on the left/right earphones (default answer and hang up for call status UI operation) Reject incoming call: Long press the multifunction key for 3 seconds (default rejection for call status UI operation) Next song: Long press the left headphone multifunction button for 3 seconds Previous song: Long press the right headphone multifunction button for 3 seconds Volume increase: phone control Volume reduction: phone control Activate Siri: 3 clicks on the left/right earphones (requires support from the connected smart device), 3 clicks on either side of the earphones to exit.  Restore Factory settings Mode 1: Any earbud disconnect with the Bluetooth Device when turn on, click the MFB 5 times to clear the previous Pairing information and turn off.	 Precautions - Charging every 15 days will extend battery life when not in use often. Cleaning off dirt on the charging contacts by cotton swabs with alcohol will maintain a good Contact for charging. - Keep battery (battery pack) away from inflamm ables or excessive heat such as direct sunlight.Do not disassemble, impact extrusion or put into the fire! If severe Swelling occurs, do not continue to use. Do not expose to high temperatures. Do not use after soaking water - Intermittent is normal during play back for wireless products due to environmental factors,device brand, users' behavior, etc.  Name and content of harmful substances in products	<table> <tr> <th rowspan="2">Name of the Parts</th><th colspan="6">Hazardous Substances</th></tr> <tr> <th>Pb</th><th>Hg</th><th>Cd</th><th>Cr(VI)</th><th>PBB</th><th>PBDE</th></tr> <tr> <td>printed circuit assembly</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> <tr> <td>Shell and other structural parts</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td><td>○</td></tr> </table> This table is compiled according to SJ/T 11364. O: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572. X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572. The parts marked "X" in the form cannot be replaced by harmful substances due to the limitation of global technological development level. Printed circuit board components *: including printed circuit boards and their components, electronic components, etc. Depending on the product model, the product you purchased may not contain all of the above components  Electronic and electrical products sold within the territory of the People's Republic of China must be marked with this mark, the number in the mark represents the environmental protection life of the product under normal use.	Name of the Parts	Hazardous Substances						Pb	Hg	Cd	Cr(VI)	PBB	PBDE	printed circuit assembly	○	○	○	○	○	○	Shell and other structural parts	○	○	○	○	○	○	FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
Charging case	Earbuds	USB																																														
Transmission distance: 10m	Charging box battery capacity: 200mAh 3.7V																																															
Horn diameter: Φ11mm	Earbuds battery capacity: 35mAh 3.7V																																															
Horn impedance: 32Ω ± 15%	Charging time of charging box: ≈1.5 hours																																															
Sensitivity: 96 ± 3.0dB	Total playing time: ≈17 hours																																															
Frequency response range: 20Hz-20kHz																																																
Name of the Parts	Hazardous Substances																																															
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE																																										
printed circuit assembly	○	○	○	○	○	○																																										
Shell and other structural parts	○	○	○	○	○	○																																										