

Manual

1. Product Overview

Thank you for choosing our **Bluetooth Speaker**. This portable speaker delivers high-quality sound with wireless convenience, perfect for indoor and outdoor use. Features include Bluetooth connectivity, built-in microphone for hands-free calls, and a rechargeable battery.

2. Key Features

- **Wireless Bluetooth 5.0** – Stable connection up to 10 meters (33 feet).
- **Playtime** – Up to 12 hours (varies by volume and usage).
- **Built-in Mic** – Supports hands-free calls.

3. Getting Started

3.1 Charging the Speaker

- Connect the included USB cable to the speaker's charging port and a power source (e.g., adapter or computer).

- The **LED indicator** will turn red during charging and turn off when fully charged (~3 hours).

⚠ **Note:** Use only the provided cable or a certified adapter (5V/1A).

4.2 Power On/Off

- **Power On:** Press and hold the **Power button ()** for 2 seconds. The LED will blink blue.
- **Power Off:** Press and hold the **Power button** for 3 seconds.

5. Bluetooth Pairing

1. Turn on the speaker. The LED will blink blue, indicating pairing mode.
2. Enable Bluetooth on your device (phone/tablet/PC) and select “[Speaker Model]” from the list.
3. Once connected, you’ll hear a confirmation sound, and the LED will stay solid blue.

Reconnecting : The speaker will auto-reconnect to the last paired device when powered on.

6. Playback Controls

- **Play/Pause** : Press the **Play button ()** once.

- **Volume +/-** : Press the **Volume buttons (▲/▼)** .
- **Next/Previous Track** : Press the **Volume buttons (▲/▼)** twice quickly.
- **Answer/End Call** : Press the **Play button** during an incoming call.

7. Troubleshooting

Issue	Solution
No power	Charge the battery or check the power button.
Bluetooth not connecting	Reset the speaker or delete old pairings on your device.
Poor sound quality	Ensure the speaker and device are within range (10m).
Short battery life	Lower volume or disable extra features.

8. Specifications

- **Charging Time** : ~3 hours
- **Bluetooth Version** : 5.0
- **Range** : 10m (33ft)
- **Waterproof Rating** : IPX5

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction