

Tuya Smart Camera

TC295 Product Manual

Scan the QR code below to download the "Tuya Smart" APP and complete the installation



smartapp.tuya.com/tuyasmart

Dear users, thank you for using our products. Before using our products, please read the operation manual carefully and save this operation manual for future reference

1.1. Register and log in

1.1 Open the App (Figure 1)

1.2 Click to register (Figure 2)

1.3 Follow the prompts to enter the correct information to complete the registration (Figure 3)




figure 1




figure 2




figure 3

2. Add device

2.1 Please connect your phone to the WiFi in your environment and confirm that the WiFi network signal is normal, then proceed to the next step

2.2 Click the "+" at the top right of the main interface (Figure 4)

2.3 Select "Security & Video Surv" and click "Smart Camera WiFi" (Figure 5)

2.4 Click "Confirm that the indicator light flashes quickly or hear a prompt tone" and then click "Next" (Figure 6)




figure 4



figure 5




figure 6

2.5 After entering the correct WiFi password, click "Next" (Figure 7)

2.6 Please align the QR code on the mobile phone with the camera lens (15-20CM) Until the camera emits a "beep" sound, click "hear the prompt tone" (Figure 8)

2.7 Please wait a moment (Figure 9) is adding equipment until the screen jump to Figure 10 page

2.8 After adding the device successfully, click "Finish" to view the monitoring screen (as shown in Figure 10). The adding step is now complete




figure 7




figure 8




figure 9

figure 10

FAQ

1. Can't connect after scanning the QR code?

(Please check the WiFi password and make sure it is correct)

2.The camera does not support 5G WiFi, if it is connected, please

switch to 2.4G WiFi

3.The camera prompts that the card is not inserted?

(Please check whether the memory card is inserted in the correct direction)

4.The camera is offline?

(Please check whether the WiFi network and the power supply is normal)

5.How to change the network connection ?

(Press and hold the RESET button of the camera for 3 seconds until the camera beeps and the green light flashes quickly to reconnect)

For more frequently asked questions, please go to APP My-Frequently Asked Questions and Feedback

warranty card

client's name--your name:_____

Purchase time--shopping time:_____

contact details:_____

cause of issue:_____

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.