

使用说明书

S7



骨传导无线耳机

健康 · 舒适 · 释放双耳

按键功能概述



释放双耳,放心自由,听音乐的同时还能聆听外界的声音;听音乐,打电话,玩游戏,立体声音,真质音效,清晰震撼;是您办公、外出、驾驶的最佳选择!

控制说明

- 开 机** : 耳机处于关机状态,长按开关机按键,保持2秒,提示音:开机;
- 关 机** : 耳机处于开机状态,长按开关机按键,保持3秒,提示音:关机;
- 连 接 B T** : 开机后进入配对状态,红白灯闪烁,手机、台式电脑,笔记本电脑设备搜索到S7,手动点击连接;
- 配对成功** : 开机状态下,耳机自动进入蓝牙搜索配对模式,首次开启蓝牙需手动点击连接,耳机提示音:蓝牙已连接;
- 断开蓝牙** : 手机蓝牙设置中 主动断开蓝牙;
- 暂停/播放** : 蓝牙连接状态下,单击开机键播放/暂停;
音乐播放状态下,单击开机键播放/暂停;
- 接听/挂断/拒接** : 来电状态下,长按2秒开机按键为拒接;通话状态下,单击开机按键为挂断;
- 音量增加** : 音乐和通话状态下,单击"+"号按键,音量加一格;
- 音量减小** : 音乐和通话状态下,单击"-"号按键,音量减一格;
- 下 一 曲** : 音乐状态下,长按"+"号按键2秒播放下一曲;
- 上 一 曲** : 音乐状态下,长按"-"号按键2秒播放上一曲;
- 语音助手** : (连接蓝牙后,未拨打电话)连续按3下开机按键进入语音模式,再3下开机键 退出;(注意:开关siri, android需要在语音助手中打开"蓝牙耳机按键启动", ios需要关闭后台才打开siri功能);

产品规格

音乐播放时间-----标准状态:8小时	喇叭阻抗-----8Ω+3db
待机时间-----10天	麦克灵敏度-----42±2db
充电时间-----2.5小时	产品重量----- 26g
BT版本 -----5.4	容量-----32G

MP3功能:

- 1、开机任何状态下,双击开机按键切换蓝牙模式/音乐模式,听到提示音后表示切换成功;
- 2、蓝牙播放下,双击"开机"按键,转到MP3模式播放,/音乐模式提示音,表示切换成功;
- 3、MP3模式播放下,双击"开机"按键,转到蓝牙播放,同时伴有/蓝牙模式提示音;
- 4、耳机MP3功能只支持MP3/WVAV格式的音乐;

充电:

- 1、耳机使用 5V充电座充电时,耳机关机,也无法开机,红灯闪烁。2、充电时, 亮白灯代表已充电量以充满。

充电器和电池

充电器和电池

使用任何充电器给本耳机充电前,请先检查充电器的规格标注是否符合要求(建议充电器输出电压为:DC5V+/-0.25V,输出电流为:100mA-500mA),充电电压过高极有可能损坏蓝牙耳机。

警告:仅可使用经过认可与此配套的充电器,使用其它规格的充电器可能违反对设备的认可和保修条款,并可能导致危险.如果出厂是配充电线出货的,需连接通过3C认证的充电器。禁止对本产品严重碰撞,严重撞击有可能损坏电子主板及电池。

为电池充电

本耳机使用内置式不可拆卸充电电池,请勿尝试从耳机中取出电池,以免损坏耳机。长期不使用耳机时,请将其存放到干燥通风的地方,并每隔两个月给其充电一次。

- 1.当连接的耳机提示音提示电量低,,表示耳机电量不足。如果继续使用会自动关机,此时需要充电。
- 2.将充电器插到交流电源插座上。

给MP3拷贝歌曲

首先MP3开机，然后再把数据线插入充电盒底部的充电孔，另一端连接电脑。可以在电脑里发现U盘，即可以拷贝或删除歌曲。

此设备可以充当U盘使用。

此孔也是充电孔。充电时指示灯红灯缓慢闪烁，表示正在充电。充满后，红灯长亮。



重要说明

- 本款耳机扬声器的正确佩戴位置为耳朵前方的面颊骨处，请勿将扬声器置于耳内；
 - 长时间听大音量的音乐可能会带来不适感，请尽可能使用中等左右的音量，避免长时间使用大音量；
 - 无论音量大小，使用耳机都将影响您对周围环境的感知，使用耳机时多加注意；
 - 切勿抛扔、坐压耳机或将其浸入盐水中；耳机应远离火和高压设备；
 - 不适合三岁以下儿童使用，包含小零件；
 - 请勿将其归类为生活垃圾，而将其送往当地相应的电器电子设备回收站
- ★若用户因违反以上警告内容造成的人身财产损失，本公司不承担任何责任。

FCC 注意事项：

本设备符合 FCC 规则第 15 部分的规定。操作须符合以下两个条件：

- (1) 本设备不得造成有害干扰；
- (2) 本设备必须接受任何接收到的干扰，包括可能导致意外操作的干扰。

任何未经合规责任方明确批准的更改或修改都可能导致用户操作设备的授权失效。

注：本设备已经过测试，符合 FCC 规则第 15 部分规定的 B 类数字设备限制。这些限制旨在为住宅安装提供合理保护，防止有害干扰。本设备会产生、使用和辐射无线电频率能量，如果不按照说明安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定的安装环境中不会产生干扰。如果本设备确实对无线电或电视接收造成有害干扰（可通过关闭和打开设备来确定），建议用户尝试采取以下一项或多项措施来消除干扰：

- 重新调整接收天线的方向或位置。
 - 增加设备与接收器之间的距离。
 - 将设备连接到不同于接收器所连接电路的插座上。
- 将设备连接到与接收器连接的电路不同的插座上。
- 咨询经销商或有经验的无线电/电视专家。

合格证

产品名称 骨传导无线耳机
产品型号 S9
生产日期 _____
检 验 合格
检 验 员 _____

user's manual


S7



Bone Conduction Wireless Headphones

Healthy - Comfortable - Free Your Ears

Key Function Overview



Release both ears, rest assured that freedom, listening to music at the same time can also listen to the outside world; listening to music, phone calls, play games, three-dimensional sound, true quality sound, clear shock; is your office, go out, driving the best choice!

Description of controls

Booting	: The headset is in the off state, long press the on/off button, hold it for 2 seconds, beep: power on.
Switch off	: The headset is in the on state, long press the on/off button, hold it for 3 seconds, beep: Off
Connect BT	: Power on the device and enter the pairing state, red and white lights flashing, mobile phones, desktop computers, laptop devices to search for the S7, manually click on the connection
Pairing Successful	: Power on state, the headset automatically enter the Bluetooth search pairing mode the first time to open the Bluetooth need to be manually clicked to connect, headset tone: Bluetooth is connected.
Disconnect Bluetooth	: Unsolicited Bluetooth disconnection in mobile phone Bluetooth settings
Pause/Play	: Under Bluetooth connection, click the power on button to play/pause. Under the music playing status, click the power on button to play/pause.
Answer/hang up reject	: Under incoming call status, long press the on button for 2 seconds to reject: under call status, click the on button to hang up.
Volume Increase	: During music and call status, click the '+' button to increase the volume by one bar.
Volume down	: In music and call mode, click the '-' button, the volume will be reduced by one bar.
next song	: In music mode, press and hold the '+' button for 2 seconds to play the next song.
previous song	: In music mode, press and hold the '-' button for 2 seconds to play the previous song.
Audio Assistants	: (After connecting the Bluetooth, not make a call) Continuously press the on button to enter the voice mode, and then 3 on button to exit; (Note: switch siri, android need to open the "Bluetooth headset button start" in the voice assistant, ios need to turn off the background to open the siri function)

Product Specification

Music playback time -Standard: 8 hours	Speaker Impedance----- $8\Omega+3\text{db}$
Standby time ----- 10 days	Microphone Sensitivity----- $42\pm 2\text{db}$
Charging time -----2.5 hours	Product Weight----- 26g
BT version ----- 5.4	Capacity ----- 32G

Description of controls

1. Power on any state, double-click the power on button to switch Bluetooth mode/music mode, after hearing the tone indicates that the switch is successful.
2. Bluetooth playback, double-click the 'power on' button, go to MP3 mode playback, / music mode tone, said switching success.
3. MP3 mode playback, double-click the 'power on' button, to Bluetooth playback, accompanied by / Bluetooth mode tone.
4. headset MP function only supports MP up / WAV format music

Charge.

1. When the headset is charging with the 5V charging stand, the headset is switched off and can't be switched on, the red light is flashing.
2. While charging, the white light represents that the charging capacity is full.

Description of controls

Chargers and batteries

Before using any charger to charge the headset, please check whether the specification of the charger is in line with the requirements (recommended charger output voltage: **DC5V +/-0.25V**, output current: **100mA-500mA**), charging voltage is too high may damage the Bluetooth headset.

WARNING: Use only approved chargers with this product, use of other chargers may violate the approval and warranty terms of the device and may result in a hazardous condition, if shipped with a charging cable, connect to a C-certified charger. This product should not be subjected to severe impacts, which may damage the electronic motherboard and battery.

Charging the battery

This headset uses built-in non-removable rechargeable batteries, please do not try to remove the batteries from the headset to avoid damage to the headset.

When the headset is not in use for a long period of time, please store it in a dry and ventilated place and charge it every two months.

1. When the connected headset beeps to indicate low battery,, indicating that the headset is low on power . If you continue to use it, it will automatically switch off and need to be recharged at this time.
2. Plug the charger into an AC outlet.

Copying songs to MP3

Firstly the MP3 is switched on, then the data cable is inserted into the charging hole at the bottom of the charging case, and the other end is connected to the computer.

You can find the USB stick in the computer, which means you can copy or delete songs.

This device can be used as a USB stick.

This hole is also the charging hole. When charging, the indicator light flashes red slowly to indicate that it is charging. When fully charged, the red light is on for a long time.



Important notes

-The correct position for wearing the speakers of this headset is in front of the ear at the cheekbone, do not place the speakers in the ear; -The correct position for wearing the speakers of this headset is in front of the ear at the cheekbone, do not place the speakers in the ear.

-Listening to loud music for a long period of time may cause discomfort, so please use a moderate volume if possible, and avoid using a loud volume for a long period of time; -Listening to loud music for a long period of time may cause discomfort, so please avoid using a loud volume if possible.

-Use of headphones, regardless of volume, will affect your perception of your surroundings, so be careful when using headphones.

-Do not throw, sit on or immerse the headset in salt water; keep the headset away from fire and high-voltage equipment.

-Not suitable for children under 3 years of age, includes small parts.

-Do not classify it as household waste, but take it to the appropriate local recycling centre for electrical and electronic equipment.

★The Company shall not be liable for any loss of life or property caused by the user's violation of the above warnings.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.