Note
• To reject a call, press and hold PLAY/PAUSE button for 2 seconds.
• The speakerphone feature of this speaker can be used only in the bluetooth function.

Voice Control with a Bluetooth Mobile Phone
You can use your mobile phone's voice control function with this speaker.
1. Connect your Bluetooth-enabled mobile phone with this speaker.
Turn on your mobile phone's voice control function.
2. Double press the PLAY/PAUSE button of this speaker to access the voice control on your mobile phone. Your mobile device's voice control starts. Speak out loud and describe what you want your smartphone to do or what you want it to search for.

Indicators

Unit status	Indicator
Pairing	Blue LED flashes
Pairing success	Blue LED light on
Playing music	Blue LED flash slowly
Charging	Red LED flashes
Fully charged	Red LED goes off

Control buttons

Button	Operation	Operation details
⏻	Double press	Change Bluetooth/TF card mode
	Long press	Long press 2 seconds for Power On/Off
▶	Short press	1: Answer a call 2: End a call 3: Play/Pause the music
	Triple press	Start TWS/ Disconnect TWS mode
	Long press	Long press 2 second to go to pairing mode
	Long press	Long press 2 second to reject a call
	Double press	Access Voice control
−	Short press	Volume -
	Long press	Previous song
+	Short press	Volume +
	Long press	Next song

Specifications

Bluetooth section:
- Bluetooth version: 5.4
- Wireless equipment Classification: CLASS 2
- Support profile: A2DP, AVRCP, HFP, HSP
- Frequency range: 2.402-2.480 GHz (2.4 GHz ISM Segment)
- Service distance: up to 10m

General:
- Frequency response: 80hz-18kHZ
- Power output: 8W RMS
- Battery: Li-ion 3.7V 2000mah
- Charge time: around 4 hours
- Charging input: TYPE-C 5V / 1A
- Operation time: up to 10hours (80% volume level)
- Unit size: 95 x 84 x 53mm
- Unit weight: 293g
- Accessories: Type-C Charging cable x 1, User manual x 1

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
RF Exposure Information
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

COBALTPITCH

Portable Wireless S peaker

USER MANUAL

IPX7 Water Proof

Super Bass 8W Output Power

WARNING
• Stop using the device immediately in case of an abnormality or failure.
• Remove the USB cable immediately when water or any foreign object enters the interior of the device. It may cause a fire or electric shock. Remove the USB cable immediately, and contact your dealer for a repair.

To reduce the risk of fire, electric shock or product damage,
• Do not disassemble, repair, or modify the unit . Refer servicing to qualified service personnel.
• Do not step on, throw, or drop battery or the power supply or unit, or expose them to a strong shock.
• Do not throw the unit into fire. The battery could explode causing injury or death.
• Do not install this unit in a confined or built-in space such as a book case or similar unit, and keep a well-ventilated conditions. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
• Do not expose this unit to rain, moisture, dripping or splashing.
• Do not place objects filled with liquids, such as vases, on this unit.
CAUTION
To reduce the risk of fire, electric shock or product damage,
• Do not attempt to replace the battery by yourself, it is built-in and is not changeable.
• Do not heat, disassemble, or short-circuit the battery. Doing so may cause the battery and power supply to generate heat, rupture, or ignite.
• Charge the battery only in an ambient temperature between 5 and 35 degrees Celsius. Otherwise, the electrolyte solution might leak, battery performance might deteriorate and the battery life might be shortened.
• Do not continue charging the battery if it does not reach full charge within the specified charging time. Overcharging may cause the battery to become hot, rupture, or ignite.
• Do not expose the battery to excessive heat such as under the sun or near the fire or the like.
Overheat, leakage, or rupture may occur, resulting in burns or injury.
If you touch the battery fluid, rinse it off with water and consult with the doctor. If the battery fluid spills over the device, wipe it off without touching the fluid.

Controls and Indicators





Turning on/off the power
Powering on:
1. Press and hold the Power button for 2 seconds to power ON the unit, the Blue indicator will flash or light up. The Blue indicator flashes for Bluetooth pairing.
Powering off:
Press and hold the Power button for 2 seconds to power OFF.

Bluetooth connection
- Press and hold the Power button 2 seconds to power ON.
Bluetooth function will go into pairing mode and the blue indicator will keep flashing.
- Following the instructions in your device's user manual, activate Bluetooth on your device and search for other devices.
Once you have found "COBALTPITCH", pair with the speaker. The function indicatol lights up when the devices have been paired correctly.

Playing Bluetooth Music:
Once your device and the speaker are paired, you can play music on this speaker through Bluetooth.
1. Press the PLAY/PAUSE button either on your device or this speaker to play or pause music.
2. Adjust the volume level either on your device or this speaker by pressing the "+" or "-" button.
Notes
• Press and hold the "+" button 2 seconds to play the next track.
• Press and hold the "-" button 2 seconds to play the previous track.

Pairing for the second time or later
The speaker start pairing automatically with the last-paired device when the power is turn ON at the second time or later.

Disconnecting the Bluetooth device currently connected and connecting another Bluetooth device
Press and hold the PLAY/PAUSE button 2 seconds to disconnect the currently connected Bluetooth device. The speaker is in the pairing waiting mode at the time. To connect with another device, follow Step 2 of the "Bluetooth connection" procedure.

TWS Function
If you have two COBALTPITCH units, the dual pairing function allows you to connect two speakers to one device. As soon as you start playing music on your device the two paired speakers play the left and right audio channels, so you can enjoy stereo music.

1. Turn on two speakers and make sure there is no Bluetooth connection with a device.
2. When the speakers enter Bluetooth mode, press and hold the PLAY button on any of the speaker to start the TWS connection. The Blue indicators flashes.
3. When the two speakers are successfully paired with each other, the Blue indicator of the main speaker will blink, while the indicator on the other speaker will light on.
4. Go to the BT settings on your Bluetooth device to search and select "COBALTPITCH"The Blue indicator lights up when the devices have been paired correctly.

Playing TF Card Music
1. When the TF Card is inserted to the TF card slot, this speaker will switch to TF card function and plays music automatically. The Blue indicator flashed while playing and keep light on while pause playing.
Notes
1. Press the Play/Pause button to pause and play
2. Press the "+" / "-" buttons to adjust the volume level.
3. Press and hold the "+" / "-" buttons to play next/previous track.

Speakerphone with a Bluetooth Mobile phone
Before the speakerphone feature of this speaker can be used, you will need to pair and connect your Bluetooth-enabled phone with this speaker. Please refer to "Bluetooth connection".
Answer a call:
1. To answer a call, press the PLAY/PAUSE button. You can then use this speaker as a speaker phone.
2. Speak into the built-in microphone of the speaker and use the "+" / "-" buttons on this speaker to adjust the call volume.
3. To end the call, press the PLAY/PAUSE button.